






# Viper 7146V 1-Way Remote User Guide

Thank you for purchasing this Viper Remote Transmitter. This guide provides a general description of operations for Viper Remote Start Systems.




Feature	Description
Internal Antenna	Used for transmitting information
Transmit LED	Active when transmitting information
Command buttons (4)	Used to perform:
	Locking
	Unlocking
	Remote Start
	Silent mode/Auxiliary channel

## Remote Pairing

The following Learn Routine is used to program this replacement remote control to your system.

### Prepare the vehicle system for pairing

- 1. Door.** Open a door.
- 2. Key.** Turn the key to the ON position.
- 3. Choose.** Within 5 seconds press and release the Valet/Program button the number of times corresponding to the table below. Then, press the Valet/program button once more and hold it. The LED flashes the same number of times as the channel selected and the siren/horn sounds (if connected) to confirm the selected channel. DO NOT release the valet/program button.
- 4. Transmit.** While holding the Valet/Program button, press the  button on the remote. The siren/horn sounds (if connected) to confirm that the remote has been paired to the receiver.
- 5. Release.** Now that the remote control has been paired, you can release the valet/program button and remove the key.

**Note:** Refer to owner's guide for remote control operation.

## Government Regulations

This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesirable operation.

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television, which can be determined by turning the equipment OFF and ON, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

### Canada Statements


This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.





Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Les changements ou modifications non approuvés expressément par la partie responsable de la conformité pourrait annuler l'autorité de l'utilisateur à faire fonctionner l'équipement

# Automate 7145A 1-Way Remote User Guide

Thank you for purchasing this Automate Remote Transmitter. This guide provides a general description of operations for Automate Remote Start Systems.




Feature	Description
Internal Antenna	Used for transmitting information
Transmit LED	Active when transmitting information
Command buttons (4)	Used to perform:
	Locking
	Unlocking
	Remote Start
	Silent mode/Auxiliary channel

## Remote Pairing

The following Learn Routine is used to program this replacement remote control to your system.

### Prepare the vehicle system for pairing

- 1. Door.** Open a door.
- 2. Key.** Turn the key to the ON position.
- 3. Choose.** Within 5 seconds press and release the Valet/Program button the number of times corresponding to the table below. Then, press the Valet/program button once more and hold it. The LED flashes the same number of times as the channel selected and the siren/horn sounds (if connected) to confirm the selected channel. DO NOT release the valet/program button.
- 4. Transmit.** While holding the Valet/Program button, press the  button on the remote. The siren/horn sounds (if connected) to confirm that the remote has been paired to the receiver.
- 5. Release.** Now that the remote control has been paired, you can release the valet/program button and remove the key.

**Note:** Refer to owner's guide for remote control operation.

## Government Regulations

This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesirable operation.

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television, which can be determined by turning the equipment OFF and ON, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

### Canada Statements

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Les changements ou modifications non approuvés expressément par la partie responsable de la conformité pourrait annuler l'autorité de l'utilisateur à faire fonctionner l'équipement