



# HD77

Wireless speaker



## User's Manual

Please read this  
manual before  
using the product

## Thank you for choosing TREBLAB HD77!

This speaker provides superior sound quality and mobility, combined with rugged construction and the convenience of hands-free wireless operation.

### WHAT'S IN THE BOX





# HD77

1. TREBLAB HD77 speaker
2. User's manual
3. Charging cable
4. Round TREBLAB logo sticker
5. Carrying strap
6. Carabiner
7. 3.5 mm audio cable



## BUTTONS AND PARTS



| <b>Function</b>                              | <b>Operation</b>                                                                                               |
|----------------------------------------------|----------------------------------------------------------------------------------------------------------------|
| Power ON                                     | Press and hold the <b>POWER</b> button for 3 seconds.                                                          |
| Power OFF                                    | Press and hold the <b>POWER</b> button for 3 seconds.                                                          |
| Play / Pause                                 | Press the <b>PLAY / PAUSE</b> button.                                                                          |
| Volume +                                     | Press the <b>VOLUME +</b> button.                                                                              |
| Volume -                                     | Press the <b>VOLUME -</b> button.                                                                              |
| Answer a phone call                          | Press the <b>PLAY / PAUSE</b> button.                                                                          |
| Reject a phone call                          | Press and hold the <b>PLAY / PAUSE</b> button for 2 seconds.                                                   |
| End a phone call (hang up)                   | Press the <b>PLAY / PAUSE</b> button.                                                                          |
| Redial                                       | Press and hold the <b>PLAY / PAUSE</b> button for 3 seconds.                                                   |
| Next track                                   | Press and hold the <b>VOLUME +</b> button for 2 seconds.                                                       |
| Previous track                               | Press and hold the <b>VOLUME -</b> button for 2 seconds.                                                       |
| Switch between Wireless / 3.5 mm audio cable | Press the <b>POWER</b> button.                                                                                 |
| Disconnect                                   | Press and hold the <b>VOLUME +</b> and the <b>VOLUME -</b> buttons for 5 seconds when connected to device.     |
| Factory reset                                | Press and hold the <b>VOLUME +</b> and the <b>VOLUME -</b> buttons for 5 seconds when not connected to device. |
| Hard reset                                   | Press the <b>HARD RESET</b> button under the rubber cover                                                      |

## SETTING UP YOUR HD77

### Turn ON

Press and hold the **POWER** button for 3 seconds. You will hear the sound cue, and the BLUE LED light will start flashing.

### Turn OFF

Press and hold the **POWER** button for 3 seconds. You will hear the sound cue, and the RED LED will light up and go OFF.

## WIRELESS PAIRING

Make sure **TREBLAB HD77** is fully charged and that the AUX cable is not plugged in.

1. Turn ON your speaker by pressing and holding the **POWER** button for 3 seconds. You will hear the sound cue and the LED will start flashing BLUE, indicating that the speaker is in pairing mode.
2. Activate the Bluetooth mode on your device (smartphone, tablet, laptop).
3. Select **TREBLAB HD77** from the Bluetooth devices list. Keep it within 3 feet 1 meter of the speaker while pairing.
4. If necessary, enter passcode 0000.
5. Once **HD77** is successfully paired and connected, the LED will stop flashing and stay BLUE.

## REPAIRING

After the initial pairing, the speaker will automatically connect to the previously paired device when turned ON again. If reconnection does not happen automatically, the speaker will start looking for any other previously paired device within the effective distance range. **TREBLAB HD77** can remember up to 8 recently paired devices.

## TRUE WIRELESS STEREO (TWS) - PAIRING TWO SPEAKERS

The TWS technology allows you to use two speakers paired wirelessly to create a wireless dual-channel system, delivering a true stereo sound effect. While using this function, one speaker (Master, left channel) is paired with a smart device, the other (Slave, right channel) speaker is paired with the Master speaker.

1. Select the Master speaker and pair it to the smart device following the steps from the WIRELESS PAIRING section. Then turn this speaker OFF.
2. Turn OFF the Bluetooth on the smart device.
3. Place the Master and Slave speakers near each other (the distance should not be over 3 feet /1 meter).
4. Turn ON both speakers.
5. Double click the **POWER** button on the Master speaker. The LED indicators will start flashing BLUE and GREEN, indicating pairing with the Slave speaker.
6. Turn On the Bluetooth on the smart device. The speakers will connect

automatically.

7. Once paired, the Master speaker's LED indicators will slowly flash BLUE.

To connect in TWS using the AUX cable, perform the steps 3-6 from above and plug in the AUX cable into the Master speaker. The LEDs on both speakers should turn green.

To disable the TWS function and disconnect the Master and Slave speakers, press and hold the **VOLUME +** and **VOLUME -** buttons simultaneously on the Slave speaker for 5 seconds until the BLUE LED lights flash, indicating the connection is lost.

## **AUDIO PLAYBACK**

To pause and resume playback when connected wirelessly, press the **PLAY** button.

To adjust the volume, press the **VOLUME +** or the **VOLUME -** button while listening to music.

To change the track on the **HD77**, press and hold the **VOLUME +** or the **VOLUME -** button for 2 seconds.

## **3.5 MM AUDIO CABLE CONNECTION**

You can connect **TREBLAB HD77** to compatible devices using the supplied 3.5 mm audio cable.

Plug one end of the 3.5 mm audio cable into the 3.5 mm cable port on the side of the speaker (under the rubber cover). Plug the other end into the 3.5 mm jack on your device.

Turn the speaker ON. You will hear the sound cue and the LED light will turn GREEN. Now you can play music and audio.

**NOTE:** On-device control is not supported for the NEXT, PREVIOUS and PAUSE functions when using the 3.5 mm audio cable. Phone calls management using the **PLAY / PAUSE** button is not supported as well. You will need to make adjustments using your smart device.

## PHONE CALLS

**TREBLAB HD77** can be used to make and receive phone calls when connected wirelessly. Audio playback will be paused during calls.

To answer / end a call:

Press the **PLAY / PAUSE** button.

To reject a call:

Press and hold the **PLAY / PAUSE** button for 2 seconds.

To redial:

Press and hold the **PLAY / PAUSE** button for 3 seconds.

**NOTE:** For better call quality, face the microphone when you speak.

## TROUBLESHOOTING

| Problem                | Solution                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Not powering on</b> | <p>Make sure the speaker is fully charged.<br/>Charge for 2 hours, if necessary.<br/>Press and hold the <b>POWER</b> button for 3 seconds.</p>                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Not pairing</b>     | <p>Make sure the 3.5 mm audio cable is not plugged in.<br/>Make sure the speaker is not paired with any other device, as it can only pair with one device at a time.<br/>Press the <b>VOLUME +</b> and <b>VOLUME -</b> buttons simultaneously and hold for 3-5 seconds when not connected to the device. This will force the speaker to forget previously paired devices. Repeat the steps for pairing as previously described.<br/>Alternatively, disconnect the device from your speaker and remove <b>HD77</b> from your device's pairing list. Try to pair again.</p> |

**Not finding  
a wireless driver  
on your laptop**

Make sure your laptop supports wireless connections. If it doesn't, you will need an external wireless USB adapter compatible with your laptop. For further details, consult with your laptop manufacturer.

**Frequent  
disconnection  
and noise**

Ensure that the distance between your device and the speaker is less than 30 feet / 10 meters.

Ensure that nothing is blocking the signal between your device and the **HD77**.

Check if the speaker is running out of power.

## CHARGING

One full battery charge provides up to 9 hours of playing time at maximum volume, and up to 12 hours at medium volume. When the battery is running low, you will hear a sound signal.

**TREBLAB HD77** may be used while charging in both Wireless Mode and 3.5 mm audio cable modes.

To charge the speaker, plug one end of the supplied cable into the Type-C charging port under the rubber cover at the side of the speaker. Plug the other end of the charging cable into a standard USB port. It takes up to 4 hours to fully charge.

If the speaker is turned OFF, the LED light will turn on RED. If the speaker is turned ON and connected to the device, the PURPLE LED will light up. The RED light will turn GREEN or the PURPLE light will go BLUE when the speaker is charged.

Be sure to use a 5V DC, 0.5-2 A adaptor or charger. Using the power source with lower power will increase the overall charging time. Maximize the battery lifespan by charging your speaker through a computer's USB port.

Unplug **HD77** from the charging cable and the cable itself from the power source when not in use.

If the speaker is left unused, even the fully charged battery will lose its charge over time.

We recommend fully charging the **HD77** speaker at least twice a month to maintain sufficient battery life.

## **SAFETY RULES**

- ✔ Don't disassemble or modify your speaker for any reason. Doing this may cause the speaker to malfunction or become combustible. The damage to your device can void the manufacturer's warranty.
- ✔ Do not let your device get wet – liquids can cause serious damage. Water damage to your device can void the manufacturer's warranty.
- ✔ Make sure the speaker is completely dry before charging.
- ✔ Clean only with a dry cloth.
- ✔ Avoid exposing **TREBLAB HD77** to extreme temperatures (below 37°F / 3°C or above 112°F / 45°C). Extreme temperatures can cause the deformation of the **HD77** components and reduce the battery life and the lifespan of your new speaker.
- ✔ Don't put the device's LED lights close to humans' or animals' eyes.
- ✔ Do not use **HD77** during a thunderstorm. Thunderstorms can cause serious malfunction and increase the risk of electric shock.

## SPECIFICATIONS

|                            |                                                                                                                                  |
|----------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| <b>Battery:</b>            | Up to 20 hours playtime (35% volume)<br>Up to 9 hours (100% volume)<br>5200mAh 3.7V, rechargeable<br>Li-Ion Input 5V / 0.5A - 2A |
| <b>Charging time:</b>      | 4 hours                                                                                                                          |
| <b>Bluetooth version:</b>  | 5.0                                                                                                                              |
| <b>Supported profiles:</b> | HFP, A2DP, AVRCP, GAVDP, AVDTP,<br>SPP, AVCTP                                                                                    |
| <b>Frequency response:</b> | 100 Hz -16 KHz                                                                                                                   |
| <b>Signal range:</b>       | 33 ft / 10 m                                                                                                                     |
| <b>Output power:</b>       | 12.5W x 2                                                                                                                        |
| <b>Water resistance:</b>   | IPX6                                                                                                                             |
| <b>Charging port:</b>      | Type-C                                                                                                                           |
| <b>Audio port:</b>         | 3.5 mm jack                                                                                                                      |
| <b>Dimensions:</b>         | 3 x 3 x 7.3 inches / 78 x 78 x 186 mm                                                                                            |
| <b>Weight:</b>             | 1.37 lbs / 620 g                                                                                                                 |

## RECYCLING

The speakers can be recycled, and they should be in order to keep our planet clean. Where should you bring them?

In the **US**, there are a couple of options:

**1.** Best Buy has a recycling program. Just take the broken speaker with you next time you visit a Best Buy store.

This link will help you find the best location: <https://www.bestbuy.com/site/store-locator/>

**2.** Check for other possible locations next to you on these websites (just enter your ZIP to find a location):

<https://www.call2recycle.org>

<https://search.earth911.com>

<https://recyclenation.com/find>

<https://www.cta.tech/Consumer-Resources/Greener-Gadgets>

In **Canada**, please visit the links below:

<https://thinkreuse.net>

<https://www.call2recycle.ca>

In the **UK**, please visit the links below:

<https://www.recycle-more.co.uk/>

<https://www.recyclenow.com/local-recycling>

## THANK YOU

We truly appreciate that you chose **TREBLAB** as your trusted brand of wireless speakers and sincerely hope you enjoy the great sound and seamless usability **TREBLAB HD77** provides. We love making our customers happy by providing true value with our products. If for any reason you are not completely satisfied with your purchase or have any questions, please visit [https://treblab.com/contact\\_us](https://treblab.com/contact_us). We care about our customers most of all and are always here to help you.



TREBLAB

**1 YEAR WARRANTY**  
**Parts and Labor Warranty**

Please visit [www.treblab.com](http://www.treblab.com)  
to register YOUR product.

Manufactured by Productech

**HD77**

WIRELESS SPEAKER

Made in China

**RoHS** **CE** **FC**  



**WARNING:** Cancer and Reproductive  
Harm - [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)



Federal Communications Commission (FCC) Statement. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received,

including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide Reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by **SHENZHEN WEIKING TECHNOLOGY CO., LTD** may void the FCC authorization to operate this device. Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

**RF exposure statement:**

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The device is installed and operated without restriction.