

User's Manual

IMPORTANT: Please go to www.korfx.com/start; To learn how to use your vest and Watch our setup videos.

Box

BIND KEY

- Press will enter bind mode. LED will flash.
- Press again will exit bind mode.

POWER SWITCH

- POWER ON/OFF

LINE IN (3.5mm phone jack)

- Connect to any standed 3.5mm audio source.

VOLUME knob (beside LINE IN)

- You can adjust the input volume level by the volume key beside the LINE IN
- .

LINE OUT (3.5mm phone jack)

- Standed 3.5mm audio output port

VOLUME knob (beside LINE OUT)

- You can adjust the output volume level by the volume key beside the LINE IN.

Vest

BIND KEY

- Press and hold for 1.5 seconds will enter bind mode. LED will flash.
- Press again will exit bind mode.

UP KEY

- Press and release in short time will increase vibration amplitude. Speaker will output "up" or "tone". (Center tone or maximum tone)
- Press and hold for 2 seconds will enter L/R balance adjustment mode. Speaker will output two continue tone.
- In L/R balance adjustment mode, press and release UP KEY will increase R-Channel vibration for 2% but will decrease L-Channel vibration for 2% at the same time. Speaker will output a tone. If reach maximum adjustment (10% increase for R and 10% decrease for left) will output another tone.
- In L/R balance adjustment mode, press and hold for 2 seconds will exit that mode. Speaker will output two continue tone.

DOWN KEY

- Press and release will decrease vibration amplitude. Speaker will output "down" or "tone"/ (Center tone or maximum tone)
- In L/R balance adjustment mode, press and release DOWN Key will decrease R-Channel vibration for 2% but will increase L-Channel vibration for 2% at the same time. Speaker will output a tone. If reach maximum adjustment (10% decrease for R and 10% increase for left) will output another tone.

Mode KEY

- Press and release in short time will change the filter. (Filter1 - 0Hz-300Hz), (Filter2 - 0Hz-300Hz + 1KHz-1.5KHz), (Filter3 - 0Hz-300Hz + 1.5KHz-2KHz). Speaker will output Filter1, Filter2 and Filter3.
- Press and Hold for 2 seconds will output vibration for L and R.
- Press again will stop vibration.

POWER KEY

- Press and release in short time will enable / disable channel enhancement. Speaker will output "Effect on", "tone", "tone", "tone", "Effect off"
- Press and hold for 2 seconds will power off the unit. Speaker will output "OFF".
- Press and hold for 2 seconds will power on the unit. Speaker will output "ON".
-

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance

could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.