

User Manual (For FCC Certification)

Product Serial Num:

Product Name: **LO8**

File Serial Num: _ edition:

Summary

The picture below is LO8 real product photo. There is a battery compartment in both sides, in which you can put batteries after screwing up the cover at the bottom. All the batteries should be put with **positive pole in the outside**. Open the SD card holder, you can see a **reset key**, a **mini USB** and a **SD cart slot**.



LO8 real product photo



Battery compartment filled with batteries



SD card slot

UI mode



(PIC 1)



(PIC 2)

Long press the POWER button to boot up, and go to the interface in(PIC 1). Press OK to go to the interface in(PIC 2). Press UP/DOWN/LEFT/RIGHT button to choose the third option IMAGE TYPE, press OK to the setting mode. You can press LEFT/RIGHT button to make the option STILL(take photos) or VIDEO(take videos) highlighted. Then press OK to save the setting and go to next setting.

You can set other options in the same way.

Introductions for setting the options

The table below shows the options which can be set by users. The options with ■ are the default settings after reset the machine.

Settings	Options and default settings	notes
Time	■ 12:00 AM	12-hour clock
Date	■ 01/01/2012	Month/day/year The range of calendar is from 12:00 AM 01/01/2010 to 11:59 PM 12/31/2030
Location	■ _ _ _ _ _ _ _ _ (8 Blanks)	You can set from "A" to "Z", "0" to "9" and a blank" ". After reset ,it will be 8 blanks. A blank is showed as "_" on TFT, but nothing on the photos.
Trigger	■ PIR Mode <input type="checkbox"/> Flextime <input type="checkbox"/> Both	Choose the trigger pattern. It can be PIR Flextime ,or both of them.
Flexitime	<input type="checkbox"/> P1 <input type="checkbox"/> P2 <input type="checkbox"/> Interval	
PIR Mode	■ Still <input type="checkbox"/> Video	
PIR Active	■ 24Hr	



User Manual (For FCC Certification)

Product Serial Num: Product Name: **LO8** File Serial Num: _ edition:

	<input type="checkbox"/> Day <input type="checkbox"/> Night	
PIR Sense	<input type="checkbox"/> Hi <input checked="" type="checkbox"/> Med <input type="checkbox"/> Lo	PIR sensitivity.
Picture	<input checked="" type="checkbox"/> Regular <input type="checkbox"/> Wide	The length-width ratio of the photos to be taken. Regular is 4:3; Wide is 16:9.
Still Res	<input checked="" type="checkbox"/> Hi <input type="checkbox"/> Med <input type="checkbox"/> Lo	The resolution ratio of the photos: When set the Picture to be Regular: Hi --- 8M (3264*2448) Med --- 6M (2816*2112) Lo --- 4M (2272*1704) When set the Picture to be Wide: Hi --- 8M (3840*2160) Med --- 6M (3200*1800) Lo --- 4M (2560*1440)
Video Res	<input type="checkbox"/> HD <input checked="" type="checkbox"/> Regular	HD represent 720P@30fps , Regular represent 640*480@30fps(both with sound)
Video	<input checked="" type="checkbox"/> 15s <input type="checkbox"/> 30s <input type="checkbox"/> 1m <input type="checkbox"/> 2m	The length of the video. S means second, m means minute.
PIR Delay	<input checked="" type="checkbox"/> 15s <input type="checkbox"/> 30s <input type="checkbox"/> 1min <input type="checkbox"/> 2min <input type="checkbox"/> 5min <input type="checkbox"/> 10min	The length of the video. S means second, min means minute.
Flexitime Delay	<input checked="" type="checkbox"/> 1min <input type="checkbox"/> 2min <input type="checkbox"/> 5min <input type="checkbox"/> 10min <input type="checkbox"/> 15min <input type="checkbox"/> 20min <input type="checkbox"/> 25min <input type="checkbox"/> 30min	The length of the video. S means second, min means minute.

still/video mode

If no key pressed in a continuous 30 seconds in UI mode, the TFT of LO8 will be turned off after showing "save set", and then go to the idle mode. Trigger the infrared sensor, the camera will take photos or videos as

User Manual (For FCC Certification)

Product Serial Num: Product Name: **LO8** File Serial Num: _ edition:
you set in the UI mode.

Tip: Pressing the RESET button to reset the camera, it will take photos after going to the standby mode .
You can take videos if only change the PIR Mode to Video.

Attention:

1. You should plug in the SD card before taking photos or videos.
2. The red LED will flash if you trigger the infrared sensor in the first 1.5 minutes of this mode. After 1.5 minute, the function will be off.

USB mode

In this mode ,you can read the files in the SD card.

The ways to go into this mode:

1. When the machine is turned off, connect the camera to PC with USB cable, and then long press the POWER button to turn on the camera.
2. In UI mode, connect the camera to PC with USB cable.

FCC STATEMENT

Product Name: Game Trail Camera
Trade Name: Wildgame Innovations
Model# LO8

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two criteria: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Compiled by JNan Lao Apr 6th,2012

Reviewed by Stephen Apr 6th, 2012