

## PACKING LIST

- 1 x WorkForce Wi-Fi Dongle
- 1 x Type-C adapter

*Note: The dongle support starts from WorkForce firmware v. 65.145.0.220.*

## SAFETY INFORMATION


<https://www.wildix.com/safety-information/>

## WI-FI DONGLE CONNECTION

1. Connect WorkForce Wi-Fi Dongle to Type-C adapter
2. Plug the Wi-Fi Dongle into WorkForce USB Type-C port
3. The Wi-Fi Dongle connection LED indicator turns steady blue when connected

*Notes:*

- *Wi-Fi Bridge mode is not supported*
- *WorkForce with a connected dongle requires at least 5V 2A power source*



## NETWORK CONNECTION

To connect WorkForce to a Wi-Fi network:

1. Press **Menu** soft key on WorkForce
2. Go to **Network** menu and select **WLAN** option
3. Enable Wi-Fi connection: use **Navigation** keys or press **Switch** soft key to change Wi-Fi connection status from *Disable* to *Enable*; press **Save** soft key
4. Searching for Wi-Fi Networks is in progress. After it is completed, there is a list of all available networks
5. Select a Wi-Fi network from the list and press **Connect** soft key
6. Enter password and press **Save** soft key
7. WorkForce is now connected to the Wi-Fi network

Full guide online:



[www.wildix.com](http://www.wildix.com)

## Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

## RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 10mm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter