

**Exhibit I: Users Manual**  
**Wireless Computing**  
**RF-015 Compact Receiver**

# HANDHELD M O U S E

## RF-150

### INSTRUCTIONS

1. **Install Battery.** Insert one AA alkaline battery (included) in the handheld's battery compartment.
2. **Connect Receiver.** Plug the black receiver into your computer's USB port. If you see a series of dialog boxes about USB drivers, press Enter repeatedly to accept the standard USB drivers in Windows.

Tip: Do not place receiver in an equipment cabinet or near other strong EMI sources.

3. **Set Address.** Press and release the address button on the bottom of the receiver. While the green LED blinks, simultaneously press the handheld's left and right buttons. Repeat until the green LED on the handheld blinks. This matches the address in the handheld to the address in the receiver.

### OPERATION

The RF-150 will operate PowerPoint slideshows and other mouse-controllable computer applications. When you press the mousedisk or click a button, both the handheld and receiver's green LEDs should blink.

The RF-150 is designed to transmit reliably at a distance of 100 feet (31 meters). Operating

range will vary depending on receiver and handheld positioning, nearby sources of interference, and other factors.

To protect the battery from accidental discharge, the handheld stops transmitting if a mouse button, or the mousedisk, is held down for more than 60 seconds.

### TO USE MORE THAN ONE HANDHELD OR KEYBOARD ON A COMPUTER

If desired, you can set multiple RF-150s and RF-250 Wireless Keyboards to operate the same computer.

1. Connect one receiver to the computer.
2. Press and release the address button on the bottom of the receiver.
3. While the green LED on the receiver blinks, on every RF-150, simultaneously press the left and right mouse buttons to set their addresses.

Next, press the **Addr** key on each RF-250 to set its address. After a handheld or keyboard retrieves an address, the receiver LED continues blinking for another 30 seconds.



## TROUBLESHOOTING

### Green LED on receiver is not lit

- Ensure computer is powered on and receiver's USB cable is connected to USB port.
- Unplug the receiver's USB cable and plug it into the computer again.

### Button presses don't get through

- If neither the green nor red LED on the handheld flashes when you press a button, replace the battery.
- If the red LED flashes when you press a button, reposition the receiver and check that the handheld and receiver are within 100 feet of each other. If the problem persists, reset the address.
- If the green LED flashes on the handheld, and yet the mouse cursor doesn't move, unplug the receiver from the computer and plug it in again.

### Cursor moves by itself, or keystrokes appear "from nowhere"

- The address of your receiver may be the same as the address of another RF-150 Handheld Mouse or RF-250 Wireless Keyboard within radio range. Reset your receiver's address.

## FOR FURTHER ASSISTANCE

Please visit our online customer support page:

**[www.wireless-computing.com/support](http://www.wireless-computing.com/support)**

Or call customer support at **512.858.4400**  
between 8:30-5:30 Central Time.

## FCC INFORMATION

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Consult the dealer or a Wireless Computing technician for help.

The radio module has been evaluated under FCC bulletin OET 65C and found compliant to the requirements as set forth in CFR 47 sections 2.1049, 15.203, 15.209 and 15.249 addressing RF exposure from radio frequency devices.

Tested to comply with FCC standards.

FCC ID:    L7MR150    RF-150 Handheld Mouse  
              L7MR015    RF-015 Compact Receiver

## ADDITIONAL INFORMATION

For use with UL Listed, CSA approved personal computers. Not intended for use in machinery, medical or industrial applications. Do not use in aircraft or hazardous locations.

**Caution:** Any changes or modifications not expressly approved by Wireless Computing could void your authority to operate this device. No user serviceable parts.