

BAUHN®

BLUETOOTH® SPEAKER
BAUHN SPK





Contents

General Safety Instructions	3
Parts	4
Instructions	6
Specifications	9
Troubleshooting	10



Information

INCLUDED IN CARTON:

- Bluetooth speaker
- Micro USB cable
- Aux cable
- Warranty card
- User guide

The BLE Bluetooth® Speaker adopts a digital signal processing technique and is ideal for the office, home and similar environments. You can wirelessly connect your mobile phone, laptop/computer and more via the Bluetooth function to play high quality music.



General Safety Instructions

Read this manual thoroughly before first use and keep it in a safe place for future reference, along with the completed warranty card, purchase receipt and carton. The safety precautions enclosed herein reduce the risk of fire, electric shock and injury when correctly adhered to.

In order to maintain good performance, do not use the speaker in cold, hot, dusty or wet environments, especially under the following conditions:

- **Protect from moisture:** To protect against electric shock and damage, do not immerse the cord, plug or the speaker itself in water or any other liquid and do not expose the electrical connections to water.
- **Avoid overheating:** Do not place speaker in direct sunlight, near heaters or hot environments.
- **Unstable locations:** Keep speaker on a flat surface in a secure location.
- **Do not dismantle:** Any attempt to dismantle the unit will void the warranty.
- **Children:** Young children should be supervised when using Bluetooth speaker.
- **Liability:** Only use this product as described in the instructions in this manual. We assume no liability for damages or injury caused by misuse of the product or non-compliance with these instructions.




Parts


Parts of the speaker

Refer to illustration below for parts:

Top:




Bottom:






Parts

Back:



Front:



- | | |
|---------------------------|------------------|
| 1. Answer/End call button | 2. Microphone |
| 3. Mode indicator | 4. Volume - |
| 5. Play/Pause | 6. Volume + |
| 7. Charging indicator | 8. Aux connector |
| 9. Charging connector | 10. Power switch |



Instructions

Charging

Use the included USB cable to connect the speaker to your computer or USB power adaptor for charging.

Set up

1. Move Power switch to 'ON' to turn on the speaker
2. The mode indicator turns on in blue and starts blinking while the speaker is searching for Bluetooth devices.
3. Turn on your Bluetooth device, select "BAUHN SPK" to pair and connect for the first time. If your Bluetooth device prompts you for a passcode, enter "0000" (four zeros). If "BAUHN SPK" is not in the Bluetooth device list, scan available Bluetooth devices.
4. When connecting is complete, the mode indicator's blinking interval changes from short to long.
5. The speaker and your Bluetooth device store paired devices in memory. When the speaker is turned on, the speaker attempts to connect to the last connected Bluetooth device. If the last connected device is not available, the speaker attempts to connect to devices in memory one by one. The speaker stays in searching if there is no available paired device.



Instructions

Control buttons

Press 'VOL+' button to increase the speaker volume.

Press 'VOL-' button to decrease the speaker volume.

Press 'Play/Pause' button on the speaker to play or pause the audio.

Control buttons on your Bluetooth device can be used too.

Hands-free function

Press  to answer incoming calls. Streaming audio pauses.

Press  to end calls. Streaming audio resumes.



Instructions

Using Aux input

1. Connect your audio device and the speaker using a 3.5mm audio cable (Aux cable).
2. The speaker switches to Aux mode automatically. The mode indicator changes to solid red light.
3. Only 'VOL-' and 'VOL+' buttons work for controlling the audio in Aux mode.

Mode indicator

INDICATOR	STATUS
Solid blue light	Powering on
Blinking blue light (short interval)	Searching for Bluetooth devices
Blinking blue light (long interval)	Connected to a Bluetooth device
Solid red light	Connected to an Aux device



Specifications

Bluetooth range	Up to 10 metres
Rated output	1.5W
Operating frequency range	2.402GHz - 2.480GHz unlicensed ISM band
Supported profiles	Bluetooth v2.1, A2DP function
Built-in lithium battery	Built-in rechargeable lithium ion battery 3.7V 500mA Battery life: upto 3hrs (Volume at 50%)



Troubleshooting

Symptom	Possible problem and Solution
Bluetooth pairing cannot be accomplished.	<ul style="list-style-type: none">• Make sure your device's Bluetooth function is turned on and the device is discoverable.• If there are too many Bluetooth devices near the speaker, turn unused devices off to avoid interference.
The sound is too soft.	<ul style="list-style-type: none">• Check the volume setting on both the speaker and your Bluetooth device and adjust the volume to a suitable level.
Poor sound quality or distorted sound in Bluetooth mode	<ul style="list-style-type: none">• Make sure your Bluetooth device is within the speaker's Bluetooth range. Move your Bluetooth device closer to the speaker.



FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

