




Unpacking

Check to make sure that all of the items shown below are included with your Floating Speaker.

- 1. 1 speaker
- 2. 915 MHz transmitter
- 3. 1 AC adaptor for transmitter
- 4. 1 Remote
- 5. 3.5mm Audio Cable
- 6. 1 User's manual

1

Introduction of the speaker buttons



- A1. "VOL-" Press the "VOL-" to decrease the volume of the speaker.
- A2. "Power" Press to turn on/off the speaker, the indicator light will illuminate when speaker is on.
- A3. "VOL+" Press "VOL+" to increase the volume of the speaker.

2

90-DAY LIMITED WARRANTY


EXCALIBUR ELECTRONICS, INC., warrants to the original consumer that its products are free from any electrical or mechanical defects for a period of 90 DAYS from the date of purchase. If any such defect is discovered within the warranty period, EXCALIBUR ELECTRONICS, INC., will repair or replace the unit free of charge upon receipt of the unit, shipped postage prepaid and insured to the factory address below.

The warranty covers normal consumer use and does not cover damage that occurs in shipment or failure that results from alterations, accident, misuse, abuse, neglect, wear and tear, inadequate maintenance, commercial use, or unreasonable use of the unit. This warranty does not cover cost of repairs made or attempted outside of the factory.

Any applicable implied warranties, including warranties of merchantability and fitness, are hereby limited to 90 DAYS from the date of purchase. Consequential or incidental damages resulting from a breach of any applicable express or implied warranties are hereby excluded. Some states do not allow limitations on the duration of LIMITED 90-DAY WARRANTY implied warranties and do not allow exclusion of incidental or consequential damages, so the above limitations and exclusions in these instances may not apply.

3

Introduction of the transmitter ports



- B1. 3.5mm Audio Output port: Output for analog stereo audio signal.
- B2. DC jack: Input for 9V DC power supply.

4

Introduction of the Remote Control



- STANDBY:** Turns the transmitter on and off
- PLAY/PAUSE:** Press to begin playing or pause during play
- MENU:** Takes you into iPod Menu
- ENTER:** Press to select a function
- PREV:** Press to return to the previous track
- NEXT:** Press to move on to the next track
- DOWN:** Use to move down through a menu
- UP:** Use to move up through a menu
- VOL-:** Press the "VOL-" to decrease the volume
- VOL+:** Press "VOL+" to increase the volume

5

Playing your iPod via 915 MHz transmitter

- 1. Insert the iPod into the transmitter's dock.
- 2. Connect the 9V DC power supply to the "DC IN" port for the transmitter, press "STANDBY" button on the remote to switch the transmitter on, an indicator light will illuminate.
- 3. Put 1-9V battery into the speaker battery compartment, press the "POWER" button to turn the speaker on, the indicator light will illuminate.
- 4. Press the "PLAY" button on iPod or remote control to play track.
- 5. Use "VOL-/+ " to decrease/increase the volume.

Reminder: To conserve battery life, turn the unit off when not in use.

6

Playing from an auxiliary audio source

- 1. Connect one end of 3.5mm audio cable to the audio output of auxiliary audio equipment (MP3, CD player, etc), and connect the other end of 3.5 mm audio cable to aux audio input jack.
- 2. Connect the 9V DC power supply to the "DC IN" port for the transmitter, press the "STANDBY" button on the remote to switch the transmitter on, an indicator will illuminate.
- 3. Put 1-9V battery into the speaker battery compartment, press and hold the "POWER" button to turn the speaker on, the indicator will illuminate.
- 4. Press the "PLAY" button on audio source or remote control to play.
- 5. Use "VOL-/+ " to decrease/increase the volume.

Reminder: When an auxiliary audio source is connected, your iPod will not play.

7

FCC Statement This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

8

The only authorized service center in the United States is:

Excalibur Electronics, Inc.
13755 SW 119th Ave
Miami, Florida 33186 U.S.A.
Phone: 305.477.8080
Fax: 305.477.9516
www.ExcaliburElectronics.com

Ship the unit carefully packed, preferably in the original carton, and send it prepaid, and adequately insured. Include a letter, detailing the complaint and including your daytime telephone number, inside the shipping carton. If your warranty has expired and you want an estimated fee for service, write to the above address, specifying the model and the problem.

NOTE: Please do not send your unit without first receiving an estimate for servicing from EXCALIBUR ELECTRONICS, INC. Contact us before sending your unit. We cannot store your unit!

Please Visit Us @ www.ExcaliburElectronics.com



9