

User Manual

Product: DISC LOCK ALARM

Model(s): XX6, XX10, XX14, XX15, XZZ6L

Your Xena Lock is Bluetooth enabled so that connect to your Smartphone and adjust the alarm settings using the Xena BLE Lock app available for both Android and IOS.

If you do not wish to use the app simply insert the battery as normal and use can use lock as a conventional Xena alarmed lock.

Using the App.

- 1] Download and install the “Xena BLE Lock” App.
- 2] Insert battery into the alarm module. You will hear a confirmation “beep” once battery is correctly inserted. Replace the battery door.
- 3] Insert module into the lock and fit base plate.
- 4] Open the Xena App and follow the instructions on the App. Once you have named your device and set a password you can adjust the settings and check your battery status. You can choose the user language in the settings menu.
- 5] After initial setup up, the Bluetooth connection will only be active once the lock is placed on a disc. If your app is closed or interrupted after setup you will need to place you lock on a disc to reconnect the App.
- 6] Your Xena alarm will be paired to your Smartphone so there will be no need to enter your password once the device is set up.
- 7] When you remove the battery the password and device will be reset.
- 8] If you use another device to connect to your lock you will need to enter the password again.
- 9] You can select the user language in the settings menu.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and

used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.