

PS3 BLUETOOTH HEADSET

USER MANUAL

Thank You for purchasing the PS3 Bluetooth Headset. products are built to the highest manufacturing standards and tested throughout its development. Please read through this manual before using the PS3 Bluetooth Headset.

BRIEF INTRODUCTION

This PS3 Bluetooth Headset is designed for PS3 platform, also compatible with other Bluetooth device.

PRODUCT INTRODUCTION

1. PS3 Bluetooth Headset 1PCS
2. USB Charging Cable 1PCS


PRODUCT FEATURES

1. Bluetooth Headset 2.0 technology designed specifically for PlayStation 3

2. Works with most cell phones that support Bluetooth 2.0
3. Compact ergonomic fit stays comfortably on your ear all day
4. Noise reducing microphone

BATTERY CHARGING

1. Insert the USB Charging cable into the charging socket, and connect the USB cable to PS3 or PC.
2. When charging, the LED indicator will turn RED. If the battery is flat, the LED indicator might need 1 minute to turn RED.
3. Full Battery charge can take upto 2 hours.
4. When fully charged, the LED indicator will turn Green.



OPERATION INSTRUCTION (PS3 PLATFORM)

1. Turn on PS3 console, select (Accessory Settings) under (Settings)

2. in the home menu.
2. Select [Manage Bluetooth Devices]. If you have registered one or more Bluetooth devices, a list of registered devices will be displayed.
3. Hold the "P button" for 5 seconds until the LED indicator turns Purple. Then extend the microphone whilst continuing to hold down the P button.
4. If the LED indicator flashes Blue after extending the microphone, please repeat step 3.
5. Select [Register New Device]. If you have not registered any Bluetooth devices, you will be asked if you want to register the device. Select [Yes] to continue.
6. Select [Start Scanning]. Your PS3 console will display a list of Bluetooth devices within range of the system.
7. Select the " PS3 Bluetooth Headset", Complete registration by entering the pass key (0000), using the X key to edit.
8. After success pairing, go back to the (Accessory Settings), select (Audio Device Settings) to test the headset. Change "Input Device" and "Output Device" to " PS3 Bluetooth Headset". Try speaking and watch the "Microphone Level" move. To test the Headset mute function touch the P button to un-mute touch the P button again.
9. If the connection between the PS3 console and a Bluetooth device is lost, you can reestablish the connection. Select [Input Device] or [Output Device], press ▲ button, and then select [Connect] from the options menu to connect the devices

PRECAUTION AND MAINTENANCE

Please review the following guidelines to ensure optimal performance of the product.

1. Please make sure there is no extreme pressure put on this product.
2. Don't dismantle this product without permission.
3. This product should be situated away from heat sources such as radiators and heaters.
4. Keep this product dry and avoid contacting with damp or wet areas.

Playstation3/PS3 is a registered trademark of SONY Inc.

This product is not approved, sponsored or endorsed by SONY Inc.

This product is not manufactured for SONY Inc.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to

operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help.