
BLUETOOTH® SPEAKER USER MANUAL YM-308



^{*}The picture is only provided for reference. Please refer to the actual unit!

GETTING STARTED

To make a correct use of the functions and know well about the system connection and usage, please read this user's manual carefully before using the product. Keep this manual in a safe place for future

INTRODUCTION

INTRODUCTION

This Bluetooth® speaker will allow you to listen to your music wirelessly from your mobile phone, tablet or other Bluetooth® enabled device. It delivers powerful and clear sound. The built-in microphone allows you to answer calls from mobile phone.

SAFETY INSTRUCTIONS
Do not insert any metal object in the device.
To avoid a static charge, do not use the device in an extremely dry


To avoid a static charge, do not use the device in an extensity dry climate.

Do not attempt to open or repair the device yourself.

Avoid heavy shocks to the product and do not drop it.

Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

INTRODUCTION OF PRODUCT PANEL AND FUNCTIONS



- 1. Vol +/NEXT
- 2. Vol-/PREV
- 3. Mode button : Switch between Bluetooth and AUX playing
- 4. Play/Pause/Phone.
- 5. On/Off switch
- 6. Micro USB charging port
- 7. AUX input

Box content

YM-308 Speaker Micro USB charging cable AUX input cable User's manual

CHARGING THE BLUETOOTH® SPEAKER

Connect the micro USB port of the USB charging cable into the USB port on the side of the speaker. Connect the other end of the USB cable to your computer's USB port or an USB wall charger (not

The LED indicator turns RED, indicating the battery is being charged. The LED indicator will turn off when the speaker is fully charged. (Approximately 3 hours).

PAIRING THE SPEAKER WITH A BLUETOOTH® ENABLED DEVICE

ENABLED DEVICE
Keep your Bluetooth® Speaker and Bluetooth® enabled device within I meter of each other during the pairing process.
Turn on your Bluetooth® Speaker. The LED light on the front of the speaker flashes. Your speaker is now in Pairing Mode.

Set your Bluetooth® enabled device to search for Bluetooth® devices.

When the device finds the YM-308, select it. Select "Pair" to connect the Bluetooth® Speaker to your bluetooth enabled device.

Depending on which device you are trying to connect the speaker to, it may be necessary to enter a passcode. Enter passcode "0000" if

prompted by the device.

Your Bluetooth® enabled device will confirm that the pairing was completed, and prompt you to accept the connection. Please respond YES to connect the Bluetooth® Speaker to your Bluetooth® enabled

Note : Once the speaker is paired and connected to your Bluetooth® device, it will automatically connect the next time as long as the Bluetooth® on your device is turned on.

USING YOUR BLUETOOTH® SPEAKER

PLAYING MUSIC

FLATING MUSIC

To enjoy wireless music on your Bluetooth® Speaker, make sure you are connected to a Bluetooth® enabled device. Once connected you can press PLAY on your Bluetooth® device or you can press the Phone button on the YM-308 speaker. Once the music is playing, you can control it from the control buttons of the YM-308 speaker.

Volume controlPress and hold the "+" or the "-" button to adjust the volume in the desired level.

Play/Pause

Press the Phone button to pause the music. To resume the music, press this button again.

Changing Songs (with devices that have AVRCP Bluetooth® profile) Short press the "+" button to go to the next song. Short press the "-" button to go to the previous song.

TELEPHONE BUTTON FUNCTIONS

Note: You may answer & end call while listening to music. The music will stop when a call is answered, and will restart when the call is

Answer / End a call:
To answer a call, short press the Phone button.
To end a call, short press the Phone button again.
To redial the last number called: Press the Phone button twice quickly. The last number called will be redialed.

TECHNICAL SPECIFICATIONS

Bluetooth® version: 2.1+EDR

Working distance: up to 10 meters in open space

Supporting Profiles: AVRCP, A2DP, Hands-Free Profile (HFP)

and Headset Profile (HSP)

Frequency range: 2.4-2.48Ghz Output power: 2x3Watts Distortion: ≤ 1.0%

Frequency response: 180Hz – 20Khz

Hands-free function for answering calls from mobile

Microphone sensitivity: -40dB

Playback time: Music time 4-6 hours, talk time 8-10 hours

Charging input power: DC 5V (micro USB)
Charging time: Approx 3 hours
Unit size: 145 x 45 x 60 mm
Unit weight: approx. 320g.

Note: Battery life & charging time may vary, based on usage & types of devices used.

The product design and specifications may be changed without prior notice!

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular

installation. If this equipment does cause harmful interference to radio ortelevision reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

 $Note: Modifications \ to \ this \ product \ will \ void \ the \ user's \ authority \ to \ operate \ this \ equipment.$