


Yealink

USB Speakerphone

CP900



English | 简体中文

Quick Start Guide (V1.0)

www.yealink.com

Package Contents



CP900




Zipper Bag



Quick Start Guide

Charging Your CP900

Connect the CP900 to a USB power source. The CP900 battery lasts for up to 12 hours of talk time and 3 hours to fully charge.




Viewing the Battery Status


Tap  to view the battery status.

Connecting Your CP900

Connect to the mobile phone

Hold the Bluetooth button  for 2 seconds and pair to your smartphone. The bluetooth range is 10m.



To disconnect or reconnect, tap the Bluetooth button  again.

Connect to PC via Bluetooth


Connect the CP900 into a USB port on your PC. The CP900 and the BT50 are pre-paired and ready to use out of the box. The bluetooth range is 30m.

For the CP900 to work correctly you may need to set the CP900 as the playback device in your operating system's audio settings.




Connect to PC via USB Cable

For the CP900 to work correctly you may need to set the CP900 as the playback device in your operating system's audio settings.













Place Your CP900

Position the speakerphone in the center of the table, up to 2m/6ft from each participant. A single CP900 is ideal for up to 6 people.



Using Your CP900

Task	Do
Power on or off	Long tap  for 3 seconds
Answer a call	Tap 
End or reject a call	Tap 
Volume up/down	During a call, tap  / 
Mute/unmute microphone	During a call, tap 
Hold a call	During a call, tap 
Connect Bluetooth device	Tap 
Reset to the factory	Hold  and  for 6 seconds.

包装清单



CP900




拉链包



快速入门指南

充电

使用USB线缆把CP900接入USB电源。CP900电池可支持12小时通话时长，充满电大约需要3小时。




检查电量


按  查看电池电量状态。

连接CP900

连接至移动电话

长按蓝牙键  2S，蓝牙处于配对模式，然后与手机进行配对。蓝牙距离为10米。



如果要断开蓝牙连接或重新连接，再按蓝牙键 。

通过蓝牙连接至PC


将BT50插入电脑的USB接口。BT50与CP900已预先配对，开箱即可使用。蓝牙距离为30米。

注意你需要在操作系统的音频设置中将CP900设为播放设备。




通过USB线连接至PC

注意你需要在操作系统的音频设置中将CP900设为播放设备。



摆放位置

将CP900放在桌子中间，与每名与会者的距离不超过 2 米/6 英尺。一台 CP900可供 6 人使用。



使用CP900

任务	操作
开机/关机	长按电源键  3秒
接听电话	按接听电话键 
挂断/拒接电话	按挂断电话键 
音量调高/调低	通话中，按音量调高  /调低键 
麦克风静音/取消静音	通话中，按静音键 
通话保持	通话中，按接听电话键 
连接到蓝牙	按蓝牙键 
恢复出厂	按住接听电话键  和挂断电话键  6秒钟

Regulatory Notices

Operating Ambient Temperatures

- Operating temperature: +32 to 104°F (0 to 40°C)
- Relative humidity: 5% to 90%, noncondensing
- Storage temperature: -22 to +160°F (-30 to +70°C)

Warranty

Our product warranty is limited only to the unit itself, when used normally in accordance with the operating instructions and the system environment. We are not liable for damage or loss resulting from the use of this product, or for any claim from a third party. We are not liable for problems with Yealink device arising from the use of this product; we are not liable for financial damages, lost profits, claims from third parties, etc., arising from the use of this product.

Explanation of the symbols

● DC symbol

— is the DC voltage symbol.

● WEEE Warning symbol

To avoid the potential effects on the environment and human health as a result of the presence of hazardous substances in electrical and electronic equipment, end users of electrical and electronic equipment should understand the meaning of the crossed-out wheeled bin symbol. Do not dispose of WEEE as unsorted municipal waste and have to collect such WEEE separately.

Restriction of Hazardous Substances Directive (RoHS)

This device complies with the requirements of the EU RoHS Directive. Statements of compliance can be obtained by contacting support@yealink.com.

Safety Instructions

Save these instructions. Read these safety instructions before use!

⚠ General Requirements

- Before you install and use the device, read the safety instructions carefully and observe the situation during operation.
- During the process of storage, transportation, and operation, please always keep the device dry and clean, avoid collision and crash.
- Please attempt not to dismantle the device by yourself. In case of any discrepancy, please contact the appointed maintenance center for repair.
- Please refer to the relevant laws and statutes while using the device. Legal rights of others should be respected as well.

⚠ Environmental Requirements

- Place the device at a well-ventilated place. Do not expose the device under direct sunlight.
- Keep the device dry and free of dusts.
- Do not place the device on or near any inflammable or fire-vulnerable object, such as rubber-made materials.
- Keep the device away from any heat source or bare fire, such as a candle or an electric heater.

⚠ Operating Requirements

- Do not let a child operate the device without guidance.
- Do not let a child play with the device or any accessory in case of accidental swallowing.
- Please use the accessories provided or authorized by the manufacturer only.
- The power supply of the device shall meet the requirements of the input voltage of the device. Please use the provided surge protection power socket only.
- Before plugging or unplugging any cable, make sure that your hands are completely dry.
- Do not spill liquid of any kind on the product or use the equipment near water, for example, near a bathtub, washbowl, kitchen sink, wet basement or near a swimming pool.
- During a thunderstorm, stop using the device and disconnect it from the power supply. Unplug the power plug and the Asymmetric Digital Subscriber Line (ADSL) twisted pair (the radio frequency cable) to avoid lightning strike.

About Yealink

Yealink is a global leading provider of enterprise communication and collaboration solutions, offering video conferencing service to worldwide enterprises. Focusing on research and development, Yealink also insists on innovation and creation. With the outstanding technical patents of cloud computing, audio, video and image processing technology, Yealink has built up a panoramic collaboration solution of audio and video conferencing by merging its cloud services with a series of endpoints products. As one of the best providers in more than 140 countries and regions including the US, the UK and Australia, Yealink ranks No.1 in the global market share of SIP phones shipments.

Technical Support

Visit Yealink WIKI (<http://support.yealink.com/>) for the latest firmware, guides, FAQ, Product documents, and more. For better service, we sincerely recommend you to use Yealink Ticketing system (<https://ticket.yealink.com>) to submit all your technical issues.

- If the device is left unused for a rather long time, disconnect it from the power supply and unplug the power plug.
- When there is smoke emitted from the device, or some abnormal noise or smell, disconnect the device from the power supply, and unplug the power plug immediately.
- Contact the specified maintenance center for repair.
- Do not insert any object into equipment slots that is not part of the product or auxiliary product.
- Before connecting a cable, connect the grounding cable of the device first. Do not disconnect the grounding cable until you disconnect all other cables.

CAUTION: Risk of explosion if battery is replaced by an incorrect type.

Warning:

To avoid replacement of a battery with an incorrect type

Don't disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a Battery.

Don't leaving a battery in an extremely high temperature surrounding environment

To avoid battery subjected to extremely low air pressure.

The marking information is located at the bottom of apparatus

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following

two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver. to which the receiver is connected.
- Connect the equipment into an outlet on a circuit different from that
- Consult the dealer or an experienced radio/TV technician for help.

IC Statement

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

(1) this device may not cause interference; and
(2) this device must accept any interference, including interference that may cause undesired operation of the device. CAN ICES-3(B)

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage;
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. NMB-3(B)

Radiation Exposure Statement

This equipment complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 centimètres entre le radiateur et votre corps.



CP900-EN-CN



YEALINK(XIAMEN) NETWORK TECHNOLOGY CO.,LTD.

Web: www.yealink.com

Copyright ©2019 YEALINK(XIAMEN) NETWORK

TECHNOLOGY CO.,LTD.All rights reserved.