



正面:




Thank you for choosing YI Discovery Action Camera

1. Camera kit




2. Getting to know the camera



3. Insert/remove MicroSD Card (Sold Separately)

1) To insert microSD card:
Slide card into the card slot with the label facing the front of the battery. The card will click into place when fully inserted.

2) To remove microSD card:
Press finger against edge of card and lightly push into camera. The card will pop up to be removed.




4. Battery Insertion and Removal

To open the battery cover, pull from the slot following the arrow direction.


1) To insert the battery:
1. Insert the battery into the battery slot, following the direction of the arrow.
2. To close the battery cover, press and slide the cover in the opposite direction of the printed arrow. Make sure to press firmly to ensure proper closure.

2) To remove the battery:
Use the tab to pull the battery from the slot.




5. Battery Charging

1. Connect the camera to a power source or computer via the MicroUSB cable.
2. Using a computer to charge, make sure the camera is powered off.
3. The red status light remains ON while the battery is charging.
4. The red status light will turn OFF when the battery is fully charged.



背面:


6. How to Use the Camera



1) Powering ON and OFF:
To power on: Press the Power/Shutter Button. The screen will turn on, followed by a sound indication.
To power off: Long press the Power/Shutter Button. The screen will turn off, followed by a sound indication.

2) Connecting to the YI Action Camera APP

Scan the following QR code to download YI Action Camera App and install to your smartphone or tablet. Or, you can find the App in the App Store® or Google Play by searching for "YI Action". After opening the YI Action Camera APP, you will see the connection interface as shown in the picture below. View the tutorial to connect the app to the YI Discovery Action Camera.



Tip: After pairing you can use the app to control, download and playback your videos or photos.

3) Updating Firmware

After you connect your camera to the YI Action Camera APP for the first time, the app will automatically download the latest firmware and guide you to update the camera's firmware to the latest version. To update from the app, make sure the camera is connected to a power source or has more than 50% battery remaining.



7. Customer support

Please visit www.yitechnology.com/support or email support@yitechnology.com. Find us on social networks: www.facebook.com/YITechnologyOfficial, www.google.com/+YIcamera, www.instagram.com/yitechnology.

IMPORTANT SAFETY GUIDELINES

1. READ this user manual carefully.
2. CLEAN ONLY with a dry cloth.
3. DO NOT use near any heat sources such as radiators, heaters, stoves, or other apparatus (including amplifiers) that produce heat.
4. ONLY USE attachments/accessories specified by the manufacturer.
5. For the best results please check our site regularly for the latest version of the app and firmware.

Attention: It is illegal in many jurisdictions to record audio and/or video without the consent of all individuals. You must comply with all laws when using your YI Discovery Action Camera.

*Xiaoyi and "YI" logo are trademarks of Shanghai Xiaoyi Technology Co., Ltd.
WARNING: No naked flame sources - such as candles - should be placed on the product.
Manufacturer: Factory Shanghai Xiaoyi Technology Co., Ltd.
Address of Manufacturer: Factory 2F, Building E No. 2888, Lujiu Road, Shanghai, China
Importer: XXXXX
Address of Importer: XXXXX

Thank you for choosing YI Discovery Action Camera. Please read this manual carefully and save it for future needs.

WIFI	
Model	Y1900
Operation Frequency	802.11a/B/G: 11g/802.11n/HT20: 24.12MHz~2483.5MHz 802.11n(HT40)/2422MHz~2454MHz
Battery (Rechargeable Li-Ion Battery)	
Model	Y1900
Capacity	900mAh
Nominal Voltage	3.7V
Watt-hour	3.33Wh
Manufacturer	Shenzhen Shunwang Electronic Technology Co., Ltd.
Address of Manufacturer F17, Building E, Huafeng Industrial Park, Hangcheng Avenue, Qutou, Xiangyang Town, Sarhan District, Shengzhou City, Guizhou, China	

Here by, We Shanghai Xiaoyi Technology Co., Ltd. declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU

This product can be used across EU member states



This device complies with Part 15 of the FCC Rules / Industry Canada licence-exempt RSS (standard). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users of the antenna type and its gain should be no chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'égard des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.


CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Le remplacement incorrect de la batterie est susceptible d'entraîner un risque d'explosion. Veuillez jeter les batteries usagées selon les instructions.



FCC ID: 2AF1B-YAS2217

折叠图:



印刷公差 ≤ 0.5mm
SCALE 1:1

- 切刀
- 压线
- 齿刀
- 开槽
- 半穿
- 粘合

审核人员

- 设计主管 ▶
- 产品经理 ▶
- 质量工程 ▶
- 认证工程 ▶
- 软件测试 ▶
- 部门总监 ▶

通知人员

- 项目经理 ▶
- 采购经理 ▶

项目号 ▶ J22	项目名称 ▶ YI Discovery Action Camera	印刷颜色 ▶ PANTONE 1925C+ K PANTONE Cool Gray 11C	物料材质 ▶ 105g 无光铜	图号 ▶ J22
设计于 ▶ 王伟	物料名称 ▶ 说明书(英文版)	成品尺寸 ▶ 90 × 90mm	特种工艺 ▶ 风琴折	料号 ▶ 609