


Quick User Guide



Button Description



Package Contents



**Anti-lost
device**



Button cells

Other accessories: Quick User Guide

1. Usage



When the anti-lost device is connected with your mobile phone, it alarms if your phone is carried 10 meters away.



Press this button to turn off alarm.

2. APP Installation and Connection

- (1) Install the Key fob application.



- (2) Turn on the Bluetooth on iPhone/iPad.



(3) Run the Key Fob application.



(4) Search for Key Fob device.



(5) Connect the device.



- (6) The device should alarm at the first connection, and your mobile phone volume will automatically be adjusted to the maximum by the Key Fob application.



Important Notice

The device contains tiny parts, and is not suitable for children under 3 years old. Please keep it out of children's reach.

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.