

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS OR CHANGE TO THIS EQUIPMENT. SUCH MODIFICATIONS OR CHANGE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Drivers: 6mm **Resistance:** 16 Ohms \pm 15% **Sensitivity:** 102dB \pm 3dB **Frequency:** 50Hz - 20KHz **Working Time:** 5+25hrs

Charging Time: 1.5-2h

Warranty information available at www.zagg.com/warranty-policies

©2020 ZAGG Inc All Rights Reserved | NASDAQ: ZAGG | MADE IN CHINA

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by ZAGG Inc is under license.

USB-C is a trademark of USB Implementers Forum.

Other trademarks are property of ZAGG.

*All hours usage and charging claims are estimates based on internal testing and will vary based on individual usage.



314-0465-A | 06/04/20



AIRTIME LUXE 2(Pro 2)

TRULY WIRELESS EARBUDS

FCC ID: QTG-IFAYTWSP2

Quick Start Guide

Introduction

Welcome to truly wireless audio with 30 hours' of combined battery life and quick charging case.

Pairing the Wireless Earbuds with Your Device

- Simply open the case and remove the earbuds. A pairing signal will be sent to your Bluetooth® device. The earbuds will flash red and white, indicating pairing mode.
- On your device, go to Bluetooth under Settings and select IFROGZ® Airtime Luxe 2.
- Complete any additional steps your device may require. The lights on the earbuds will flash white and then turn off, indicating that pairing was successful.

Turning Earbuds On/Off

To turn the earbuds on, simply remove the buds from the case. To turn the earbuds off, simply return them to the case.

If you'd like to turn an individual bud on, press and hold the touch sensor on the earbud for 3 seconds. It will flash white until it's connected to a device. It will turn off if not paired within 60 seconds.

You can also tap and hold the IFROGZ icon on the earbud for 10 seconds to turn it off; it will flash red, indicating the power is off.

The earbuds will go into hibernation mode if not used for 20 minutes.

Using the Earbuds

Airtime Luxe 2 true wireless earbuds have built-in touch navigational controls. Just tap on the end of the earbud (on the IFROGZ logo) to navigate.

Music Controls

Left Bud	Actions	Right Bud
▶ Play / Pause	● Quick Tap	▶ Play / Pause
◀◀ Previous Track	●● 2x Taps	▶▶ Next Track
◀) Decrease Volume	☰ Tap & Hold	◀)) Increase Volume

Call Controls

📞 Answer Call / End Call	● Quick Tap	📞 Answer Call / End Call
📞 Cancel Call	☰ Tap & Hold	📞 Cancel Call
🗣️ Siri / Voice Command	●●● 3x Taps	🗣️ Siri / Voice Command

Charging the Wireless Earbuds

The case carries enough power to charge the earbuds up to 5 times'.

- Place the earbuds in the charging case. You'll feel them magnetically click into place.
- A red light on the earbuds will indicate charging. A white light will illuminate for 60 seconds, then turn off when earbuds are fully charged.

Charging the Case

Your case comes charged and ready to go. You can re-charge the case wirelessly using a wireless charging pad, or charge the case manually using the included USB-C® cable.

Wireless Charging

- Simply drop the charging case on a compatible wireless charging pad.
- The Battery Indicator light will flash according to its current battery level. This indicates your case is charging. When the case is fully charged, all four lights will illuminate for 20 seconds then turn off.

Manual Charging

- Connect the included USB-C charging cable to the port on the side of your case.
- Connect the USB-A end of the cable to your preferred 5V USB outlet.
- The Battery Indicator light will flash according to its current battery level. This indicates your case is charging. When the case is fully charged, all four lights will illuminate and then turn off.
- Disconnect the charging cable.

Quick Charge Feature

Get one more hour of playtime by nesting the earbuds in the charging case for ten minutes.

Checking the Battery Level

Your case carries enough power to charge your wireless earbuds 5 times for a total of 25 hours. To check how much power your case still has, place the earbuds in the case. The LED on the front of the case will illuminate, indicating how much battery remains in the case:

- If it lights up completely, 75% or more remains
- If it lights up ¾ of the way, between 50-74% remains
- If it lights up ½ of the way, between 25-49% remains
- If it lights up ¼ of the way, less than 24% remains.

Factory Reset

If you have functionality issues, a factory reset can help. Here's how to perform one.

- Place both buds in the case.
- Reset the right bud.
 - Remove the right bud from the case.
 - Tap and hold for 10 seconds until light flashes red and turns off.
 - Tap and hold for five seconds until light turns on and flashes red and white.
 - Quickly tap the bud six times; the light will turn off.
 - Return the bud to the case.
- Reset the left bud.
 - Remove left bud from the case.
 - Quickly tap the bud six times, the light will turn off.
 - Return the bud to the case.
- Connect the left and right earbuds by removing them from the case and allowing them to connect to each other for about five seconds.
- The buds are now reset to the factory settings. Go into your device's Bluetooth settings and remove the Airtime Luxe 2 earbuds. Then re-pair them with your device.