








SA-H0018 烟雾报警器 快操 REV-A00

尺寸：75\*90mm（成品尺寸）

材质:105g双铜+双面印刷4C +折页

<div><div>zmodo™</div><div>Quick Start Guide Smoke Detector</div></div>	<p>The Zmodo Smart Accessories Kit provides a full solution to monitor your home. All devices can be connected and controlled through the Zmodo app. The following describes the main features of this system.</p> <p>Smoke Detector: When paired with a Beam, the smoke detector alerts you with audible warning sounds and a phone notification when smoke is detected.</p> <p><b>1. Mount and Connect your Smoke Detector</b></p> <p>Find a suitable location to install your smoke detector, and follow the instructions for installation.</p> <p>Tips:</p> <ul style="list-style-type: none"><li>• If you are installing in the basement, the detector should be installed on the ceiling at the bottom of the stairs leading to the next floor.</li><li>• Install at least 10 feet away from cooking appliances to minimize false alarms.</li></ul> <div>1</div>	<ul style="list-style-type: none"><li>• Mount your detector high on walls or ceilings.</li><li>• Wall-mounted detectors should be installed no further than 12 inches away from the ceiling.</li><li>• In order to optimize performance, do NOT install near windows, doors, or vents.</li></ul> <p>1 Turn the smoke detector clockwise and separate it from the mounting bracket.</p>  <div>2</div>	<p>2 Insert one CR123A Battery (included) into the battery compartment.</p>  <p><i>Note: The Status Light will blink red when the smoke detector has low battery.</i></p> <div>3</div>	<p>3 In order to connect the smoke detector, access your smart hub's Device Settings and select the "Accessories" option. Select the + Add Accessory option, follow the on-screen instructions, and when prompted, press and hold the button on the detector for 3 seconds. When the status light is blinking red and the alarm sounds, release the button, and the detector will be paired with your Beam.</p>  <p>Press here</p> <div>4</div>
<p>4 Referring to the placement tips, find a suitable location for your smoke detector and install the mounting bracket with the provided screws.</p>  <p><i>Note: The line shown in red will be parallel to the edge of the smoke detector when the smoke detector is placed onto the mounting bracket. Make sure that this edge is parallel or perpendicular to the wall for aesthetic purposes.</i></p> <div>5</div>	<p>5 Fasten the smoke detector onto the mounting bracket.</p> <p>When in use and working properly, the status light will blink red every 48 seconds. When smoke is detected, the light will blink red, the alarm will sound, and you will receive a notification on your phone. You can deactivate the alarm from the mobile app or by pressing the button on the smoke detector.</p>  <div>6</div>	<p><b>2. Support</b></p> <p><b>Having difficulty?</b></p> <p>For more instructions, troubleshooting, support, and other resources, please visit:</p> <p><a href="http://www.zmodo.com/support">www.zmodo.com/support</a></p> <div>7</div>	<p><b>3. Connect with us!</b></p> <p>Like us on Facebook.com/Zmodo Scan the QR-code!</p>  <p>Follow us on Twitter @Zmodo Scan the QR-code!</p>  <div>8</div>	<p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.</p> <p>If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"><li>- Reorient or relocate the receiving antenna.</li><li>- Increase the separation between the equipment and receiver.</li><li>- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</li><li>- Consult the dealer or an experienced radio/TV technician for help.</li></ul> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <div>9</div> <div>REV-A00</div>