

CAPTURE THE MAGIC

PHONE & FEATURE GUIDE

Z079584508303

Tomorrow never waits

ZTEUSA.COM

Setting Up Your Phone

Installing a microSDXC™ Card (Not Included) and a Nano-SIM Card

Power off your phone before installing or removing the microSDXC card or the nano-SIM card. Unmount the microSDXC card before removing it.

NOTE: Your phone will come with the SIM card already installed.

1. Insert the tip of the tray ejection tool into the hole next to the card tray and pull the tray out.

2. Place the microSDXC card and nano-SIM card on the tray, as shown.

3. Carefully slide the tray back into place.

Charging the Battery

Your phone's battery should have enough power for the phone to turn on, find a signal, and make a few calls. You should fully charge the battery as soon as possible.

WARNING! Use only ZTE-approved chargers and USB Type-C cables. The use of unapproved accessories could damage your phone or cause the battery to explode.

1. Connect the adapter to the charging port.
2. Connect the charger to a standard AC wall outlet. If the phone is on, you'll see a charging icon, such as or appear in the Status Bar.
3. Disconnect the charger when the battery is fully charged.

This device contains a nonremovable battery. Attempting to remove will void your warranty and could cause serious injury. Do not damage, alter, or try to remove the battery.

Getting to Know Your Phone



*Customizable. See Touch Screen and Navigation Keys panel.

Notifications

The status bar at the top of the home screen provides phone and service status icons, and notification icons.

Phone and Service Status Icons

	2G connected		Alarm set
	4G/3G connected		No signal
	4G LTE™ connected		Signal strength
	Do not disturb mode on (Alarms only or Priority only)		Airplane mode
	Do not disturb mode on (Total silence)		Bluetooth on
	Ringer off		Connected to a Wi-Fi network
	Vibration on		Wi-Fi in use
	Battery low		Portable Wi-Fi hotspot is on
	Battery full		Mobile data in use
	Battery charging		Speaker on
	GPS on		Phone microphone off
	GPS on		GPS on

Notification Icons

	New SMS / MMS		Song playing
	New email message(s)		Upcoming event
	New Gmail message(s)		New Wi-Fi network detected
	Missed call		Downloading / sending data
	Call in progress / Call on hold		USB connected
	microSDXC card mounted		Wired headset connected

QSG Z079584508303

Touch Screen and Navigation Keys

- **Power/Lock Key:** Press and hold to power on, restart the phone, turn on/off airplane mode, or power off. Press to turn on/off the screen display.
- **Home Key:** Press to return to the home screen from any application or screen. Press and hold to access Google Now™.
- **Recent Apps Key:** Press to view recently used apps.
- **Back Key:** Press to go to the previous screen.
- **Volume Key:** Press to turn the volume up or down or to enable silent mode/vibration mode.

Opening Applications

1. Press if the current screen is not the home screen.
2. Tap .
3. Swipe up or down on the screen and tap an app to open it.

Personalize

You can exchange the positions of the Back Key and Recent Apps Key.

Press > > **Navigation key** and select an option.

Internet

Connecting with Wi-Fi®

1. From the home screen, tap > **Wi-Fi**.
2. Slide the on/off switch if Wi-Fi is off. Your phone automatically searches for Wi-Fi networks in range and displays their names and security settings. Your phone also connects to previously linked networks when they are in range.
3. Tap a network name to connect to it.
4. If the network is secured, enter a password or other credentials (ask your network administrator for details) and tap **CONNECT**.

Connecting via Mobile Network

1. From the home screen, tap > **Data usage**.
2. Slide next to **Mobile data** to enable mobile data.

Calling and Voicemail

Making a Call

1. From the home screen, tap > **Phone**.
2. Enter the phone number with the on-screen keypad. Tap to delete incorrect digits.
3. Tap to place the call.

NOTE: To call a contact, press > > **CONTACTS** and tap .

Checking Voicemail

1. From the home screen, tap > **Phone**.
2. Press and hold the **1 Key**. If prompted, enter your voicemail password.
3. Follow the voice prompts to listen to and manage your voicemail messages.

NOTE: To set your voicemail service, tap > **Settings** > **Call settings** > **Voicemail** and tap the voicemail settings you want to change. For detailed information, please contact the service provider.

Address Book

Creating a New Contact

1. From the home screen, tap > **CONTACTS**.
2. Tap .
3. Enter the contact name, phone numbers, email addresses, and other information, as shown.
4. Tap to save the contact.

Importing Contacts in Batches

1. From the home screen, tap > **CONTACTS**.
2. Tap > **Import from storage**.
3. If prompted, select an account in which to save the contacts.
4. If prompted, choose to import one, multiple, or all vCard files.

Text Messaging

1. From the home screen, tap > **Messages**.
2. Enter the recipient(s) and message text. If you want to send an MMS, tap to add attachments.
3. Tap or **SEND** to send the message.

Please don't text and drive.

Email

Setting Up Gmail™

1. From the home screen, tap > **Mail**.
NOTE: If you have already entered a Google™ account (e.g., during initial phone setup), tap **TAKE ME TO GMAIL**. If you'd like to add another Gmail account, tap **Add another email address** and follow instructions.
2. Tap **Add an email address** > **Google** > **NEXT**.
3. Enter your existing Google email or tap **Or create a new account**.
4. Follow the instructions on the screen to set up the account.

Setting Up Email

1. From the home screen, tap and select an email server.
NOTE: If another email account is already set up, press > > **Accounts** > **Add account** and select the type of account you need.
2. Enter the email address.
3. Enter the password, tap **NEXT**, and follow the on-screen instructions.

Customizing Home Screens

You can customize your home screen by adding shortcuts, folders, widgets, and more.

Adding Widgets

1. Press and hold an empty spot on a home screen.
2. Tap **Widgets**.
3. Press and hold a widget and drag it to the desired home screen.
4. Tap to place the call.

NOTE: To add a shortcut to a home screen, press and hold the app from the App Tray and drag it to a home screen.

Removing Widgets or Shortcuts

1. Press and hold a widget or shortcut on the home screen.
2. Drag it to to remove it.

Organizing Shortcuts With Folders

1. Press and hold a shortcut.
2. Drag it to at the top of the screen. A new folder is created.
3. If needed, drag more shortcuts and drop them into the folder.

Applying New Wallpapers

1. Press and hold an empty spot on a home screen.
2. Tap **Wallpapers**.
3. Tap a wallpaper thumbnail image, or select a source (**GALLERY** or **LIVE WALLPAPER**) and then choose an image or animation.
4. Follow the instructions on the screen.

Camera and Video


Taking a Photo

1. From the home screen, tap > **PHOTO**.
2. Aim the camera at the subject and make any necessary adjustments.
3. Tap .

Recording a Video


1. From the home screen, tap > **VIDEO**.
2. Aim the camera at the subject and make any necessary adjustments.
3. Tap to start and to stop recording.

TIP: While the recording is in progress, you can tap / to pause or resume recording, or tap to save the frame as a photo.



Playing Music

1. From the home screen, tap > **Music**.
2. Tap **All Songs**.
3. Tap a song to play it.



Connectivity

Connecting With a Bluetooth® Headset

Turn on the *Bluetooth* headset (or any other device you want to pair with your phone) and switch it to pairing mode. Refer to the headset's user guide for more information.

1. From the home screen, tap > **Bluetooth**.
2. Slide the on/off switch if *Bluetooth* is off. When *Bluetooth* is on, the icon appears in the status bar.
NOTE: Your phone automatically scans for and displays the IDs of all available *Bluetooth* devices in range. You can tap > **Refresh** to scan again.
3. Tap the ID of the headset. Enter a passcode if prompted.
4. If necessary, tap the ID of the paired headset to connect with it.

TIP: Tap the headset ID and then tap **OK** to end the connection.

Google Play™

Google Play has tens of thousands of games and applications for you to enjoy. Before you begin, make sure that you are signed in to your Google account.

1. From the home screen, tap .
2. Find the apps you need either by category or by typing in the search field.
3. Tap the app to see a more detailed description.
4. Tap **INSTALL** (free apps) or the price (paid apps).
5. Read the app permissions and tap **ACCEPT**.
6. For paid apps, follow additional on-screen instructions for payment.
7. Wait for the app to be downloaded and installed automatically. Payment needs to be authorized before paid apps start downloading.
8. The app is successfully installed when the icon appears in the status bar. You can find the new app after pressing > .

NOTE: The content you can access in the Play Store depends on your region and your service provider.

For Your Safety (continued)

communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Hearing Aid Compatibility (HAC) Regulations for Mobile Phones

In 2003, the FCC adopted rules to make digital wireless telephones compatible with hearing aids and cochlear implants. Although analog wireless phones do not usually cause interference with hearing aids or cochlear implants, digital wireless phones sometimes do because of electromagnetic energy emitted by the phone's antenna, backlight, or other components. Your phone is compliant with FCC HAC regulations (ANSI C63.19-2011). While some wireless phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate. The wireless telephone industry has developed ratings for some of their mobile phones to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that have been rated have a label on the box. These ratings are not guaranteed. Results will vary depending on the level of immunity of your hearing device and the degree of your hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.

M-Ratings: Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference with hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings. (Note that not all hearing devices contain telecoil.)

T-Ratings: Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device's telecoil ("T Switch" or "Telephone Switch") than unrated phones. T4 is the better/higher of the two ratings. (Note that not all hearing devices contain telecoil.)

Your **Z986DL** has been tested for hearing aid device compatibility and has an **M4/T3** rating.

For additional information about the FCC's actions with regard to hearing aid compatible wireless devices and other steps the FCC has taken to ensure that individuals with disabilities have access to telecommunications services, please go to www.fcc.gov/cgb/dra.

CTIA Requirements

- Do not disassemble or open, crush, bend or deform, puncture, or shred the battery.
- Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard.
- Only use the battery for the system for which it is specified.
- Only use the battery with a charging system that has been qualified with the system per CTIA Certification Requirements for Battery System Compliance to IEEE 1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.
- Do not short-circuit a battery or allow metallic conductive objects to contact battery terminals.
- Replace the battery only with another battery that has been qualified with the system per this standard, IEEE-Std-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard.
- Promptly dispose of used batteries in accordance with local regulations.
- Battery usage by children should be supervised.
- Avoid dropping the phone or battery. If the phone or battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.
- Improper battery use may result in a fire, explosion, or other hazard.
- The phone shall only be connected to CTIA certified adapters, products that bear the USB-IF logo or products that have completed the USB-IF compliance program.

Distraction

Driving

Full attention must be given to driving at all times in order to reduce the risk of an accident. Using a phone while driving (even with a hands free kit) can cause distraction and lead to an accident. You must comply with local laws and regulations restricting the use of wireless devices while driving.

Operating Machinery

Full attention must be given to operating machinery in order to reduce the risk of an accident.

Product Handling

General Statement on Handling and Use

- You alone are responsible for how you use your phone and any consequences of its use.
- You must always turn off your phone wherever the use of a phone is prohibited. Use of your phone is subject to safety measures designed to protect users and their equipment.
- Always treat your phone and its accessories with care and keep it in a clean place.
- Keep the screen and camera lens clean. Undeclared screen or camera lens may slow down the phone's reaction to your operations or lower image quality.
- Clean the device and its accessories with a soft material such as cleaning cloth for eyeglass lenses. Do not use alcohol or other corrosive substances for cleaning or allow them to get inside.
- Do not expose your phone or its accessories to open flames or lit tobacco products.
- Do not expose your phone or its accessories to liquid, moisture or high humidity.
- Do not drop, throw or try to bend your phone or its accessories.
- Do not use harsh chemicals, cleaning solvents, or aerosols to clean the device or its accessories.
- Do not paint your phone or its accessories.
- Do not attempt to disassemble your phone or its accessories. Only authorized personnel can do so.
- Do not expose or use your phone or its accessories in an environment with or that can reach extreme temperatures, minimum 23°F (-5°C) and maximum 122°F (+50°C).
- Do not place your phone inside or near heating equipment or high-pressure containers, such as water heaters, microwave ovens, or hot cooking utensils. Otherwise, your phone may be damaged.
- Please check local regulations for disposal of electronic products.
- Do not carry your phone in your back pocket as it could break when you sit down.

Small Children

Do not leave your phone and its accessories within the reach of small children or allow them to play with it. They could hurt themselves or others, or could accidentally damage your phone. Your phone contains small parts with sharp edges that may cause an injury or may become detached and create a choking hazard.

Demagnetization

To avoid the risk of demagnetization, do not allow electronic devices or magnetic media to be close to your phone for a long time.

Electrostatic Discharge (ESD)

Do not touch the nano-SIM/SD card's metal connectors.

Antenna

Do not touch the antenna unnecessarily.

Normal Use Position

When placing or receiving a phone call, hold your phone to your ear, with the bottom towards your mouth.

Air Bags

Do not place a phone in the area over an air bag or in the air bag deployment area as an airbag inflates with great force and serious injury could result. Store the phone safely before driving your vehicle.

Seizures/Blackouts

The phone can produce a bright or flashing light. A small percentage of people may be susceptible to blackouts or seizures (even if they have never had one before) when exposed to bright lights or light patterns such as when playing games or watching video. If you have experienced seizures or blackouts or have a family history of such occurrences, please consult a physician. To reduce the risk of blackouts or seizures, you can use your phone in a well-lit room and take frequent breaks.

Repetitive Strain Injuries

To minimize the risk of Repetitive Strain Injury (RSI) when texting or playing games with your phone:

- Do not grip the phone too tightly.
- Press the buttons lightly.
- Use the special features that are designed to minimize the times of pressing buttons, such as Message Templates and Predictive Text.
- Take many breaks to stretch and relax.

Emergency Calls

This phone, like any wireless phone, operates using radio signals, which cannot guarantee connection in all conditions. Therefore, you must never rely solely on any wireless phone for emergency communications.

Load Noise

This phone is capable of producing loud noises, which may damage your hearing. Turn down the volume before using headphones, *Bluetooth* stereo headsets or other audio devices.

Phone Heating

Your phone may become warm during charging and during normal use.

Electrical Safety

Accessories

Use only approved accessories. Do not connect with incompatible products or accessories. Take care not to touch or allow metal objects, such as coins or key rings, to contact or short-circuit the charging jack terminals. Never puncture the surface of the phone with sharp objects.

Connection to Vehicles

Seek professional advice when connecting a phone interface to the vehicle electrical system.

Faulty and Damaged Products

Do not attempt to disassemble the phone or its accessories. Only qualified personnel can service or repair the phone or its accessories. If your phone (or its accessories) has been submerged in water, punctured, or subjected to a severe fall, do not use it until you have taken it to be checked at an authorized service center.

Radio Frequency Interference

General Statement on Interference

Care must be taken when using the phone in close proximity to personal medical devices, such as pacemakers and hearing aids. Please consult your doctor and the device manufacturers to determine if the operation of your phone may interfere with the operation of your medical devices.

Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 15 cm be maintained between a mobile phone and a pacemaker to avoid potential interference with the pacemaker. To achieve this, use the phone on the opposite ear to your pacemaker and do not carry it in a breast pocket.

Hearing Aids

People with hearing aids or other cochlear implants may experience interfering noises when using wireless devices or when one is nearby. The level of interference will depend on the type of hearing device and the distance from the interference source. Increasing the separation between them may reduce the interference. You may also consult your hearing aid manufacturer to discuss alternatives.

Medical Equipment

Turn off your wireless device when requested to do so in hospitals, clinics or healthcare facilities. These requests are designed to prevent possible interference with sensitive medical equipment.

Aircraft

Turn off your wireless device whenever you are instructed to do so by airport or airline staff. Consult the airline staff about the use of wireless devices onboard the aircraft. If your device offers airplane mode, this must be enabled prior to boarding an aircraft.

Interference in Vehicles

Please note that because of possible interference with electronic equipment, some vehicle manufacturers forbid the use of mobile phones in their vehicles unless a hands-free kit with an external antenna is included in the installation.

Explosive Environments

Gas Stations and Explosive Atmospheres

In locations with potentially explosive atmospheres, there are potentially explosive atmospheres including fueling areas, below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles, such as grain, dust, or metal powders.

Blasting Caps and Areas

Power off your mobile phone or wireless device when in a blasting area or in areas posted power off "two-way radios" or "electronic devices" to avoid interfering with blasting operations.

WARNING: This product contains a chemical known to the State of California to cause cancer, birth defects or other reproductive harm.

Copyright © 2017 ZTE CORPORATION. All rights reserved. No part of this publication may be quoted, reproduced, translated or used in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE CORPORATION. ZTE Corporation reserves the right to make modifications on print errors or update specifications without prior notice. We offer self-service for our smart terminal device users. Please visit the ZTE official website (<http://www.zteusa.com>) for more information on self-service and supported product models. Information on the website takes precedence. ZTE Corporation expressly disclaims any liability for faults and damages caused by unauthorized modifications of the software, images and screenshots used in this guide may differ from the actual product. Content in this guide may differ from the actual product or software.

ZTE,