dtac

คู่มือทารใช้งาน

EAGLE 4.5






คู่มือการเริ่มต้นการใช้ โทรศัพท์มือถือ

Dtac Trinet Phone Joey Fit Selfie 4.5

รู้ จักการใช้งานโทรศัพท์



ช่องเสียบชาร์จ แบตเตอรี่/USB ช่องเสียบหูฟัง กล้อง ไฟแฟลช ลำโพง ฝาหลัง

ปุ่มเปิดปิดเครื่อง

กคเพื่อเปิดปิดการแสดงหน้าจอ การกดค้างจะเป็นการเปิดตัวเลือกเมนูสำหรับ โหมคการใช้งานบนเครื่องบิน หรือปิดเครื่อง กดเพื่อเปิดหรือปิดหน้าจอ

ปุ่มหน้าหลัก

กดเพื่อกลับไปหน้าจอหลักจากโปรแกรมหรือ หน้าจอ

ปุ่มเมนู

กคเพื่อเลือกหน้าจอปัจจุบัน กคค้างไว้เพื่อคูโปรแกรมที่เพิ่งใช้งาน

ปุ่มย้อนกลับ

กดเพื่อกลับสู่หน้าก่อนหน้า

ปุ่มปรับเสียง

กคค้างเพื่อปรับให้เพิ่มเสียงมากหรือลคเสียง ให้น้อย

การเริ่มต้นใช้งาน

ปิคโทรศัพท์ของคุณก่อนที่จะติดตั้งหรือเปลี่ยน แบตเตอรี่หรือซิมการ์ดการ์ด microSDHCTM สามารถเลือกได้และสามารถติดตั้งและลบ ออกในขณะที่โทรศัพท์เปิดอยู่ หยุดการติดตั้งการ์ด microSDHC ก่อนที่จะลบออก

 วางนิ้วมือในช่องที่ด้านล่างของฝาหลัง เปิดขึ้นและถอดฝาออก



2.หันซิมการ์คด้านตัดมุมตามรูปภาพข้างล่างและ ใสล่งในชองซิมการ์ค



3. ใส่การ์ด microSDHCหันด้านโลหะลง และใส่ การ์ดตามช่อง




4.หันขั้วแบคเตอรี่ตามภาพแล้วเลื่อนแบตเตอรี่ ลงในช่องจากนั้นก่อยๆกดแบตเตอรี่ลงจนกว่า จะแน่น



5.ปิดฝาหลังของโทรศัพท์และกดฝากรอบเข้า ตำแหน่งตรวจสอบให้แน่ใจว่าปิดเรียบร้อยและ ไม่มีช่องว่างในรอบฝากรอง

การชาร์จแบตเตอรี่

1.เชื่อมต่ออะแคปเตอร์เข้ากับช่องชาร์จ ตรวจสอบให้แน่ใจว่าอะแคปเตอร์หันค้วยทิส ทางที่ถูกต้อง อย่าพยายามฝืนเชื่อมต่อเข้าในช่องเสียบชาร์จ



การเปิดปิดโทรศัพท์


ตรวจสอบแบคเตอรี่ชาร์จก่อนที่จะเปิดเครื่อง
•กคปุ่มเปิดปิดเครื่องเพื่อเปิดโทรศัพท์
หากต้องการปิดเครื่องกดเปิดปิดเครื่องค้างไว้
เพื่อเปิดเมนูตัวเลือก
กด ปิดเครื่อง>ตกลง


ข้อมูลการใช้โทรศัพท์อย่างปลอดภัย

	ห้ามใช้มือถือขณะขับ รถ	A	อย่าใช้โทรศัพท์ในปั้ม น้ำมัน
A	เวลาใช้งาน ต้องห่างจากร่างกาย 15มิลลิเมตร		อปกรณ์นี้สามารถให้ แส่งสว่างหรือ กระพริบได้
	ชิ้นส่วนเล็กๆอาจก่อ ให้เกิดอันตรายสำ ลักได้	A	อย่าทิ้งในกองไฟ
₹	อุปกรณ์อาจก่อให้ เกิดเสียงดังได้	P	เพื่อป้องกันอันตราย จากการฟัง อย่าพังเลียงดังเป็น เวลานาน
B	หลีกเลี่ยงสัมผัสกับ สื่อแม่เหล็ก		หลีกเลี่ยงอุณหภูมิสูง
A	หลีกเลี่ยงเครื่องกระตุ้น หัวใจและอุปกรณ์ การแพทย์	Ā	หลีกเลี่ยงการสัมผัสกับ ของเหลวเก็บในที่แห้ง
4	ปิดเครื่องใน โรงพยาบาน และสถานที่ทางการ แพทย์	I	อย่าแยกถอดชิ้นส่วน ออก
4	ปิดเครื่องในขณะอยู่ บนเครื่องบิน	A	ใช้อุปกรณ์เสริมแท้ที่รับ รองเท่านั้น
<u>*</u>	ปิดเครื่องใน สภาพแวดล้อม ที่มีวัตถุไวไฟ	A	อย่าพึ่งพาอุปกรณ์นี้สำ หรับการสื่อสารในกรณี จุกเฉิน

Dtac Trinet Phone Joey Fit Selfie 4.5 Quick Start Guide

Getting to Know Your Phone





Power Key

- Press and hold to power on, select phone modes, turn on/off airplane mode, reboot your phone, or power off.
- Press to turn off or on the screen display.

Home Key

Touch to return to the home screen from any application or screen.

Menu Key

Touch to get the options for the current screen.

Touch and hold to see recently used applications.

Back Key

Touch to go to the previous screen.

Volume Key

Press or hold to turn the volume up or down.


Starting Up

Switch off your phone before installing or replacing the battery or the SIM card. The microSDHC™ card is optional and can be installed and removed while the phone is turned on. Unmount the microSDHC card before removing it.


 Place your finger in the slot at the bottom of the back cover to lift and remove the cover.




Hold the SIM card with its cut corner oriented as shown and slip it into the card holder.



Hold your microSDHC card with the metal contacts facing down and slide it into the microSDHC card slot.




4. Align the connectors on the phone and the battery and slide the battery into the compartment. Then gently press the battery down until it is secured.



 Align the back cover with the back of the phone and press the cover back into place. Make sure all the tabs are secure and there are no gaps around the cover.

Charging the Battery

 Connect the adapter to the charging jack. Ensure that the adapter is inserted with the correct orientation. Do not force the connector into the charging jack.



- 2. Connect the charger to a standard AC power outlet.
- 3. Disconnect the charger when the battery is fully charged.

Powering On/Off Your Phone

Make sure the battery is charged before powering on.

- Press and hold the **Power Key** to turn on your phone.
- To turn it off, press and hold the Power Key to open the options menu. Touch Power off > OK.

Product Safety Information

	Do not use hand-held while driving	
4	Do not use while re-fuelling	
	For body-worn operation maintain a separation of 15 mm	
*	This device may produce a bright or flashing light	
	Small parts may cause a choking hazard	
	Do not dispose of it in a fire	
	This device may produce a loud sound	

P	To prevent possible hearing damage, do not listen at high volume levels for long periods.	
	Avoid contact with magnetic media	
	Avoid Extreme Temperatures	
	Keep away from pacemakers and other personal medical devices	
	Avoid any contact with liquid, keep it dry	
4	Switch off when instructed in hospitals and medical facilities	
	Do not attempt to disassemble	
	Switch off when instructed in aircrafts and airports	



Only use approved accessories



Switch off in explosive environments



Do not rely on this device for emergency communications



FCC Regulations:

This mobile phone complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This mobile phone has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

FCC Note:

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Information (SAR)

This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the United States.

During SAR testing, this device was set to transmit at its highest certified power level in all tested frequency bands, and placed in positions that simulate RF exposure in usage against the head with no separation, and near the body with the separation of 10 mm. Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

The exposure standard for wireless devices employing a unit of measurement is known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg.

This device is complied with SAR for general population /uncontrolled exposure limits in ANSI/IEEE C95.1-1992 and had been tested in accordance with the measurement methods and procedures specified in IEEE1528. This device has been tested and meets the FCC RF exposure guidelines when tested with the device directly contacted to the body.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid after searching on FCC ID: SRQ-ZTEV831W.

For this device, the highest reported SAR value for usage against the head is 0.62 W/kg, for usage near the body is 0.99 W/kg.

While there may be differences between the SAR levels of various

phones and at various positions, they all meet the government requirements.

SAR compliance for body-worn operation is based on a separation distance of 10 mm between the unit and the human body. Carry this device at least 10 mm away from your body to ensure RF exposure level compliant or lower to the reported level. To support body-worn operation, choose the belt clips or holsters, which do not contain metallic components, to maintain a separation of 10 mm between this device and your body.

RF exposure compliance with any body-worn accessory, which contains metal, was not tested and certified, and use such body-worn accessory should be avoided.