

Battery Life

Extend battery life by switching off when not in use.

Interference

Advisable not to use vehicle close to high tension wires or CB radios.

Range

When vehicle goes beyond radio signal contact, loss of control or slowness will occur. Extend transmit antenna higher for re-contact. Ensure antenna is screwed on tightly.

HINTS FOR MAINTENANCE

Radio waves interference may affect behaviour of the vehicle. Special care for your vehicle is mentioned below. **Do not abuse your vehicle.**

Radio waves interference may affect behaviour of the vehicle. Special care for your vehicle is mentioned below. **Do not abuse your vehicle.**

- Avoid heat, water, sand and high impact collisions. Off road vehicles run easily on grassy surfaces.
- Avoid using vehicle on wet surfaces or rain.
- Avoid using vehicle on sandy or dusty areas.
- Avoid using vehicle for long periods under direct sunlight. Sunlight or excessive heat may damage sensitive / electronic instruments.
- Store vehicle transmitter in dry cool places away from heaters or warm areas.
- Collision with hard surface may damage vehicle.
- Vehicle will not perform on thick carpet or dusty floors.
- Avoid running two vehicles of the same frequency (Purchase two vehicles with different frequencies instead.)
- Always brush your vehicle after use to remove dust. Keep vehicle clean.
- Always wipe vehicle with soft rag or cloth. Avoid cleaning vehicle with water or any chemicals

TROUBLE SHOOTING AND CARE FOR R/C VEHICLES

PROBLEM! VEHICLE DOES NOT MOVE

- Are the + and -s contacts correctly matched in transmitter?
- Are the metal contact tabs touching, rusty or dirty in transmitter?
- Are there batteries in transmitter?
- Is the power switch on transmitter turned on?
- Is the battery weak or out of power?

TIME TO CHARGE!

Battery pack is uncharged when new. Batteries lose all power at once. Your vehicle will suddenly stop. If this is the case, the vehicle is not defective, it had just run out of power.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



CE 0197 !

printed in china
#8369 B

Another Quality Product From LUCKY QUALITY TOYS

NO.8369
©ZAP TOYS 2002
MADE IN CHINA

RADIO CONTROL FULL FUNCTION

27MHz

For over 5 years of age




MINI COOPER

Instruction Manual

PLEASE ENSURE TO REMOVE ALL ACCESSORIES AND COMPONENTS FROM THE PACKAGING

How to Operate:


Charger



Charging battery:


The car has built in rechargeable battery. Put 3 x 1.5V AAA batteries into the charger with correct polarity, then place the car in the charger. The LED light will be turned on and the car is now charging. Once the car is fully charged, the LED light will be turned off automatically. The car is now ready to run.

- Remarks:**
1. The charging time is 60 - 80 seconds.
 2. Recommend to use alkaline batteries for best performance.




LED Light

After charging, pull back the car and release



POWER ON / OFF INDICATION

LEFT / RIGHT STEERING



FORWARD
REVERSE

BELT CLIP

Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules and EMI Directive 1999/5/EC. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to the radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.

THIS PRODUCT IS FOR THE USE IN U.K., SPAIN, GERMANY, FRANCE, BELGIUM, ITALY, SWITZERLAND, THE NETHERLANDS, DENMARK, U.S. AND CANADA.


TRANSMITTER BATTERY INSTALLATION AND ASSEMBLY

A. Insert one 3X"AAA" battery PROVIDED matching + and - signs.


B. In a clockwise direction, screw the threaded end of antenna into cavity located on top of transmitter.

Ensure antenna is tightly screwed for good transmission.

3X"AAA" for transmitter not included



A.



B.

Use the controller as display stand.

