

Appendix 5

Prüfbericht - Nr.:
Test Report No.:

14027221 001

Seite 6 von 7
Page 6 of 7

User manual

95901

Instruction Manual



How to Play

Turn switch to "ON" position for power. You are set to run!

Please read through this instruction manual carefully before starting to operate.
Please ensure to remove all accessories and components from packaging.

What is required to play



Manual



Vehicle



Transmitter

Battery requirements

Recommended to use alkaline batteries for best performance.

Vehicle : 3 x 1.5V (AA) size batteries.

Transmitter : 1 x 9V (006P, 6F22) size battery.



Battery installation

Transmitter

1. Remove battery cover located at the back.
2. Insert 1 X 9V battery following the + / - marking.
3. Replace battery cover.

Vehicle

- Turn the toggle to release battery door.
- Insert 3 X 1.5V(AA) batteries into the battery cartridge following the + / - marking.
- Lock up to secure battery cartridge in position.



MAINTENANCE AND CARE


- Never run the vehicle on a wet floor, sand, in mud, rain or snow. Such surfaces may cause damage.
- Do not expose the vehicle to extreme temperatures.
- Be sure to remove the batteries from the vehicle and transmitter when storing the product.
- To protect the vehicle's wheel mechanism from lint, threads, hair, and dust particles. Use a small brush, tweezers or tie a small piece of cloth to the tip of a toothpick, or similar, and wipe off dirt.
- Always keep the vehicle clean, use a dampened cloth to clean, followed by a dry cloth to wipe water away. Never use chemical to clean the product.
- Avoid holding the wheels when rotating as this will cause the electronic components to short-circuit and overheat, resulting in malfunction.
- Long period of play time can generate high heat level which causes wear and tear. To extend product life, it is suggested to allow 10 minutes of cool down period after long period of time.
- Keep this instruction manual in place for future use.

HELPFUL HINTS

- If vehicle does not respond to the transmitter, move closer to the vehicle and try again.
- If the vehicle starts to lose locomotion, simply replace its batteries.
- If the vehicle only moves slowly, change the batteries and check the wheel mechanism for lint, threads, hair or dust.
- When the transmitter range decreases, replace the battery in the controller.
- If a CB is in use nearby, it may interfere with the control of the car. If this happens, move the car and transmitter away from the CB.

CAUTION

- Vehicle and transmitter are not shock resistant.
- Do not play in the thunderstorms.
- Do not touch the wheels when the switch is turned ON.
- Do not place the vehicle or transmitter near sources of heat or in direct sunlight for long periods of time.
- Do not operate the vehicle when small children are present.
- Do not mix old and new batteries together. Do not mix battery types or brands.
- Always select a safe place to play. Never run your vehicle on the street.
- Non-rechargeable batteries should not be recharged.
- Rechargeable batteries should be removed from the toy while being charged.
- Rechargeable batteries should only be charged under adult supervision.
- Only batteries of the same or compatible type as recommended should be used.
- Batteries should be inserted with the correct polarity.
- Exhausted batteries should be removed from the toy.
- The supply terminals should not be short-circuited.
- Do not touch the motor after play, as it may become hot after long operation time.
- The operation of the Radio Control Toy Car may be influenced by the nearby electromagnetic source in such a way that the RC car may stop running.



TROUBLE SHOOTING

Problem	Causes	Correction
Vehicle doesn't move	- Power switch is turned OFF. - Vehicle is too far away from the controller. - The metal tab in the battery cartridge is flattened and not touching the batteries installed.	- Turn the power switch ON. - Bring the vehicle closer to the controller. - Lift up the metal tab so that it touches the tip of the battery.
Vehicle drives slowly	- Weak batteries in the vehicle.	- Replace with batteries, following the + / - marking.
Poor range control	- Weak battery in the transmitter. - Strong interference at the surrounded area.	- Replace with new battery. - Move to a better location to drive your vehicle.

Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to the radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment has been tested and found to comply with R&TTE Directive 1999/5/EC.

THIS PRODUCT IS FOR THE USE IN EU COUNTRIES, U.S. CANADA.

This Category II radiocommunication device complies with Industry Canada Standard RSS-310.

Carrier frequency: 27.145 MHz

RF output power (or measured field strength at 3 meters): <20dBm

Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.



C E 0197

English
#95901
MADE IN CHINA
Printed in China

Appendix 5

Prüfbericht - Nr.:
Test Report No.:
14027221 001

Seite 7 von 7

Page 7 of 7

