




























Size : 560 x 110 mm

<p><b>AGES 14+</b></p>  <p><b>Instruction Manual</b></p> <p>Thank you for purchasing the Remote Control Double Shot Dual Function Shooting Vehicle. This manual provides more information about this RC Vehicle, please read the instructions before using.</p>  <p><b>WARNING: DO NOT AIM AT EYES OR FACE.</b></p>	<p><b>Product Overview</b></p>  <p>Remote Control Vehicle</p>  <p>Remote Controller</p>  <p>Dart Blaster</p>  <p>Water Blaster</p>  <p>20 x Ammunition Clip</p>  <p>24 x Suction Dart</p>  <p>Instruction Manual</p>  <p>Water Dropper</p>	<p><b>Package Contents</b></p> <p>INCLUDES:          1 (One) RC Double Shot Dual Function Shooting Vehicle          8.38in. x 9.45in. x 6.1in. (21.3cm x 24cm x 15.5cm).          SOME ASSEMBLY REQUIRED.          1 (One) Remote Controller 5.24in. x 3.58in. x 2.08in.          (13.3cm x 9.1cm x 5.3cm)          1 (One) Water Dropper 1.77in. x 3.74in. x 1.14in.          (4.5cm x 9.5cm x 2.9cm)          1 (One) Instruction Manual          24 (Twenty Four) Suction Darts          0.43in. x 1.97in. x 0.43in. each (1.1cm x 5cm x 1.1cm each)</p> <p><b>Specifications</b></p> <p>Power supply:          Double Shot Dual Function Shooting Vehicle:          5 (Five) AA 1.5V Alkaline Batteries (Not Included).          Remote Controller:          2 (Two) AA 1.5V Alkaline Batteries (Not Included).          Frequency: 2.4 GHz</p> <p><b>Remote Controller</b></p>  <p>Forward / Backward Control Pad          Bullet Fired Button          Left / Right Control Pad          Lever Up Button          Lever Down Button</p>	<p><b>Standard Control</b></p> <p>Note: To avoid losing control, always pay attention when controlling the Remote Control Vehicle.</p>  <p>Forward          Push the up arrow on control pad to move vehicle forward</p>  <p>Backward          Push the down arrow on control pad to move vehicle backward</p>	<p><b>Standard Control</b></p>  <p>Turn Left          Push the left or right arrow on control pad to move vehicle turn in left or right direction</p>  <p>Turn Right</p>	<p><b>Standard Control</b></p>  <p>Lever Up Front Wheels          Press the lever up button to make the Remote Control Vehicle front wheels lever up.</p>  <p>Lever Down Front Wheels          Press the lever down button to make the Remote Control Vehicle front wheels lever down.</p>	<p><b>Standard Control</b></p>  <p>Dart Blast Fired (Dart Blaster Mode)          Short press the bullet fired button to shoot, long press the button for continuous shooting.</p>  <p>Water Blast Fired (Water Blaster Mode)          Short press the bullet fired button to shoot, long press the button for continuous shooting.</p>	<p><b>Power On/Off</b></p> <p>Remote Control Vehicle:          Power On / Off Switch</p>  <p>Slide the ON/OFF Switch to ON to turn on the Remote Control Vehicle.          Slide the ON/OFF Switch to OFF to turn off the Remote Control Vehicle.</p> <p>Remote Controller:          The Remote Controller will be turned on automatically when the batteries have installed.</p> <p>**Remove batteries if product is not being used.</p>
<p><b>Batteries Installation</b></p> <p>For Remote Control Vehicle</p>  <p>5 x AA 1.5V Battery (Not Included)</p> <p>To install batteries into the Remote Control Vehicle, unscrew the screw on the battery box cover to open the cover. Insert 5 x AA 1.5V batteries (Not Included) into the battery box. Batteries should be placed as shown on the diagram. Replace battery box cover and tighten the screw.</p> <p>For Remote Controller</p>  <p>2 x AA 1.5V Battery (Not Included)</p> <p>To install batteries into the Remote Controller, unscrew the screw on the battery box cover to open the cover. Insert 2 x AA 1.5V batteries (Not Included) into the battery box. Batteries should be placed as shown on diagram. Replace battery box cover and tighten the screw.</p> <p>(Notice: When inserting the batteries, you must insert according to the correct polarity, the Remote Control Vehicle and the Remote Controller won't function if batteries are reversed.)</p>	<p><b>Dart Bullets Installation to the Blaster</b></p>  <ol style="list-style-type: none"> <li>Put the ammunition clips into the machine.</li> <li>Put the suction darts into the ammunition clips one by one, press the remote launch button to make the ammunition clips automatically enter (Please note the direction of the suction dart)</li> <li>Connect the ammunition clips with suction darts together to form a circle.</li> <li>When installing suction dart, load them to the end of the ammunition clip.</li> </ol>	<p><b>Dart Blaster Installation</b></p>  <ol style="list-style-type: none"> <li>Put the convex point on the side of the battery into the card slot with "A" mark on the vehicle, and then turn clockwise to the end. To remove the blaster, turn anti-clockwise to the end. Repeat the above steps to replace the water blaster.</li> <li>Put the convex point on the side of the battery into the card slot with "A" mark on the vehicle, and then turn clockwise to the end. To remove the blaster, turn anti-clockwise to the end. Repeat the above steps to replace the water blaster.</li> <li>Put the convex point on the side of the battery into the card slot with "A" mark on the vehicle, and then turn clockwise to the end. To remove the blaster, turn anti-clockwise to the end. Repeat the above steps to replace the water blaster.</li> <li>Put the convex point on the side of the battery into the card slot with "A" mark on the vehicle, and then turn clockwise to the end. To remove the blaster, turn anti-clockwise to the end. Repeat the above steps to replace the water blaster.</li> </ol>	<p><b>Dart Bullets Installation to the Blaster</b></p>  <ol style="list-style-type: none"> <li>Open the lid of the water blaster.</li> <li>Remove the cap by turn anti-clockwise.</li> <li>Use the water dropper to fill clean water into the blaster, replace the fitting and close it by turn clockwise.</li> <li>Then close the lid.</li> </ol> <p>(Pay attention to not fill the bottle when adding water, and do not spill water on the body to prevent circuit board short circuit.)</p>	<p><b>Dart Blaster Installation</b></p>  <ol style="list-style-type: none"> <li>Put the convex point on the side of the battery into the card slot with "A" mark on the vehicle, and then turn clockwise to the end. To remove the blaster, turn anti-clockwise to the end. Repeat the above steps to replace the dart blaster.</li> <li>Put the convex point on the side of the battery into the card slot with "A" mark on the vehicle, and then turn clockwise to the end. To remove the blaster, turn anti-clockwise to the end. Repeat the above steps to replace the dart blaster.</li> <li>Put the convex point on the side of the battery into the card slot with "A" mark on the vehicle, and then turn clockwise to the end. To remove the blaster, turn anti-clockwise to the end. Repeat the above steps to replace the dart blaster.</li> <li>Put the convex point on the side of the battery into the card slot with "A" mark on the vehicle, and then turn clockwise to the end. To remove the blaster, turn anti-clockwise to the end. Repeat the above steps to replace the dart blaster.</li> </ol>	<p><b>Performance Tips</b></p> <ol style="list-style-type: none"> <li>Do not drive the Remote Control Vehicle on grass, sand or go through water.</li> <li>Do not drive the Remote Control Vehicle in windy or rainy weather.</li> <li>Do not drive the Remote Control Vehicle into any sharp object.</li> <li>Keep fingers, hair and loose clothing away from Remote Control Vehicle.</li> </ol> <p><b>Care and Maintenance</b></p> <p>Always use dry and soft cloth to clean this product. Avoid this product from being exposed to sunlight or heat. Avoid immersing these toys in water, otherwise, the electronic parts may be damaged. Check the product regularly. If any damages are discovered, please stop using immediately, until it is completely repaired in good working condition.</p>	<p><b>IMPORTANT: BATTERY INFORMATION</b></p> <p><b>For AA Batteries</b></p> <p><b>WARNING: TO AVOID BATTERY LEAKAGE</b></p> <ol style="list-style-type: none"> <li>Be sure to insert the batteries correctly, and always follow the toy/game and battery manufacturers' instructions.</li> <li>Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.</li> <li>Always remove weak or dead batteries from the product.</li> <li>Remove the battery if the product is left unused for a long period of time.</li> </ol> <p><b>Warning</b></p> <p>This product is suitable for individuals with operating experience in remote toys or those aged 14 years old and above.</p> <p>Please do not put the product in your mouth to prevent choking hazards from small parts.</p> <p>Avoid inserting your fingers into available interspaces.</p> <p>Do not engage in rough play with the product, such as throwing, crashing or twisting it.</p> <p>Store smaller-sized product accessories in places that are out of reach of children to prevent accidents.</p> <p>Avoid placing batteries in areas with high temperatures or exposing them to heat.</p> <p>When young children are operating the product, it is essential to ensure that adults are guiding them and maintaining visual control of the toy for convenient control.</p> <p>When the product is not in use, please switch off the power supply and remove the batteries.</p> <p>Please note that we cannot be held responsible for any injuries, property damage, or loss resulting from incorrect operation during the assembly or use of this product.</p> <p>Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.</p>	<p><b>FCC Statement</b></p> <p>This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> <li>Reorient or relocate the receiving antenna.</li> <li>Increase the separation between the equipment and receiver.</li> <li>Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</li> <li>Consult the dealer or experienced radio/ TV technician for help.</li> </ul> <p>RF warning statement:          The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p> <p>FCC ID: 2ADM5-ET-0851A</p>  <p>Distributed by 1616 Holdings, Inc.          701 Market Street, Suite 200          Philadelphia, PA 19106</p> <p>Made In Shantou, China          Keep All Relevant Information for Future Reference</p> <p>Item# ET-0851A</p>