

50mm

86mm

**VIVITAR**

**BLUETOOTH HEADPHONE  
Instruction Manual**




ITEM #: VB50012BT



**Introduction**

Thank you for purchasing your Vivitar Bluetooth Headphone, item VB50012BT. You can use your headphone with iPads, iPhones, iPods and many other types of smartphones and Bluetooth devices to stream music and enjoy hands-free calling. In order to get the best results when using this device, please read this manual first before using.


**Package Contents**



**Specifications**

Bluetooth Version: 4.2  
Transmission Frequency Range: 20Hz-20KHz  
Bluetooth Range: Up to 32.8 feet (10 meters)  
Bluetooth Playing Time: 4 Hours  
Standby Time: 8 Hours  
Charge Time: Approximately 1.5-2 Hours  
Battery Type: 250mAh 3.7V Lithium-Ion Battery  
Driver Diameter: 40mm

**A Quick Look at Your Device**



**Charging Your Headphone**

Your headphone has a built-in, rechargeable lithium-ion battery. To avoid damage, do not attempt to remove the battery. The full performance of the battery is only achieved after a few charging-discharging cycles. Charge the battery fully before first use. To do so, follow the steps below:

1. Connect one end of the included Micro USB charging cable to the Micro USB charging port on your headphone. Then plug the other end of the Micro USB charging cable into a USB port on your computer or a suitable power adapter in order to recharge the internal rechargeable battery.

NOTE: The internal battery of your headphone takes approximately two hours to charge when completely drained. To maximize performance, it is recommended to charge the battery for six hours before initial use.

2. When the battery is charging, the LED indicator light will turn red. When the battery is fully charged LED indicator light will turn off. Unplug when charging is complete.

NOTE: Overcharging could reduce the life of the battery. A charged battery will lose its capacity if it is not used on a regular basis.

Important!  
To avoid a complete discharge of the battery, charge your headphone at least once every six months.

**Pairing Your Headphone**

Your headphone can be paired with most Bluetooth devices including iPads, iPhones, iPod Touches, and most smartphones, laptops and tablets. In order to pair your headphone with a phone, follow the steps below:

1. Press and hold the ON/OFF button until your headphone powers on. The LED indicator light on your headphone will flash blue, blinking rapidly. This indicates that your headphone is in pairing mode.
2. Go to the Bluetooth Manager of your Bluetooth device.
3. Search Bluetooth devices and select "VB50012BT BT Headphone" to start connecting.
4. Enter "0000" if your device asks for the PIN code.
5. Once paired, the LED indicator light will slowly blink blue every few seconds.

Note: If the headphone does not automatically enter into Bluetooth mode, press the Mode/Pair button to initiate pairing.

**Using Your Headphone**

**Powering Your Headphone On and OFF**

1. Press and hold the ON/OFF button in order to power on your headphone. If you have already paired your headphone to your Bluetooth device, they will automatically remain paired each time you power on your headphone.
2. Press and hold the ON/OFF button in order to power off your headphone.

**Listening to Music**

- Play/Pause Button: Press to play or pause a track.
- Quickly tap the "NEXT TRACK/VOLUME +" button to advance to the next song in a playlist.
- Quickly tap the "PREVIOUS TRACK/VOLUME -" button to go back to the previous song in a playlist.
- Press and hold the "NEXT TRACK/VOLUME +" button to increase the volume
- Press and hold the "PREVIOUS TRACK/VOLUME -" button to decrease the volume.

Note: You can also adjust volume and playback settings on your phone or connected audio device. When listening to music from a device that is connected to the headphone's Auxiliary Port, the buttons on the headphone may not function to advance to the next track or return to the previous track.

**Using the Phone Function**

- Answering a Call: Quickly press the button to answer an incoming call.
- Reject an Incoming Call: Press and hold the button to reject an incoming call.
- Ending a Call: Quickly press the button to end a call.

Note: The phone function can only be used when there is a Bluetooth connection between your headphone and phone.

**Maintenance and Care**

-Before using your headphone, inspect the ports and jacks to make sure that they are clear of dust and debris before charging or inserting an AUX cable.

-Use a soft cloth to clean your headphone. Never use any harsh chemicals or detergents. Make sure your headphone is dry before using.

-When your headphone is not in use, it should be stored in a cool, dry place.

-Never tug or yank on the USB cable or AUX cable while they are connected to your headphone. Connect and disconnect these cables as carefully as possible.

-Never expose your headphone to high temperatures, extreme cold, high humidity or excessive moisture or water.

-Please recycle or dispose of your headphone properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your headphone for further information.



**Important Safety Precautions**

When using your Vivitar Bluetooth Speaker, basic safety precautions should always be followed, including the following:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR HEADPHONE.
2. Do not use your headphone near water. Clean using a soft cloth or paper towel.
3. Do not place your headphone on any wet surfaces.
4. Do not allow children or the infirm to play with your headphone without adult supervision.
5. Do not expose your headphone to excessive heat, flames or fire.
6. Always press all buttons carefully. Do not manhandle your headphone.
7. Do not use in extremely dry environments, as this can lead to static discharge during usage.
8. Do not expose your headphone to temperatures above 40°C. Keep out of direct sunlight.
9. Do not attempt to repair this product yourself. Contact a qualified service center if your headphone is in need of service.
10. Do not drop, puncture or expose your headphone to excessive trauma.
11. Your headphone is not intended for commercial use.
12. Do not place near objects that generate a strong magnetic field.
13. Use only the supplied chargers and cables. Unplug this device when not in use for long periods of time or during lightning storms.

**FCC Statement**

This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/TV technician for help.

FCC ID: 2ADMS-VB50012BT

**Vivitar One Year Warranty**

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

**What is Not Covered by Warranty**

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

**To Obtain Warranty Service and Troubleshooting Information:**

Call 1-800-582-9541 in the U.S. or 0-900-917-4831 in the UK or visit our website at [www.vivitar.com](http://www.vivitar.com).

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unpaired.

**Vivitar One Year Warranty (cont.)**

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR, REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR, ITS MANUFACTURERS, OR SAKAR INT. BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT, EXCEPT AS STATED HEREIN. NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

This product is manufactured, distributed and sold by SAKAR International, Inc. All other trademarks are the property of the respective owner, who has not sponsored, endorsed or approved this product.

**VIVITAR**