

# BT540-3 BT540S-3



## BT Keyboard User's Manual

### Introduction

Congratulations on your purchase of a high-quality ZIPPY product. Your BT-540 Bluetooth® Keyboard represents the state of the art in wireless Bluetooth Keyboard design and is designed for reliable and trouble-free performance.

### Safety

Before getting started, read these instructions and save them for future reference.

- Do not drop or hit your Keyboard.
- Do not use your Keyboard in a location that is subject to strong vibrations because vibration may damage your Keyboard.
- Do not disassemble or modify the product in any way. Disassembly or modification may void your warranty and could damage your Keyboard leading to a fire or electric shock.

Do not use or store your Keyboard in damp locations. Liquid entering the product may cause damage or lead to fires or electric shock.

Do not insert metal objects, such as coins or paper clips, into your Keyboard.

Your Keyboard is for general device use. Do not use your Keyboard with a device that requires exceptional reliability, especially if a breakdown or malfunction of might jeopardize life or health, such as aerospace equipment, atomic power control



systems, traffic- related equipment, transportation equipment, industrial robotics, combustion equipment, safety devices, and life-support systems.

- Batteries may explode or leak if they are improperly recharged, inserted, disposed of in fire, or mixed with used batteries or different battery types. There is a risk of explosion if a battery is replaced incorrectly.
- Dispose of used batteries according to local regulations.
- Keep the battery compartment cover and the batteries out of the reach of small children.

## Features

- Bluetooth® 3.0 interface (compliant with Bluetooth 1.0).
- Communicate with smartphone device available.
- Certified for Telecom safety.
- Transmission range up to 10 meters.
- Ultra-thin Compact size and low power consumption.
- Memorize up to six Bluetooth hosts and fast switch up to each other.

## Keyboard components



	Component
1.	Top Cover
2.	Batt.Low
3.	Power switch and Pairing/ Reset button
4.	Foot pad
5.	Label

## LED indicators

Your keyboard has an LED indicator that indicates keyboard status.

- Flashing— battery low indicator.

## Package contents

- AAA alkaline batteries (2 PCS )
- Keyboard
- User Guide


## System requirements

Your device must meet these requirements:


- Microsoft Windows ME , Windows 2000, Windows XP x32/ x64, Windows Vista, Windows 7 operating system
- Bluetooth-enabled device
- Existing keyboard for setup

## Using your keyboard


- Installing the batteries
  1. Open the battery cover.



2. Insert the two pieces of AAA Alkaline batteries. Make sure they are installed properly.




3. Close the battery cover.



## Installing your keyboard



### ● Installing Bluetooth keyboard in first device or Bluetooth host

1. Turn on your device or Bluetooth host and make sure that your Bluetooth device is set to search mode.
2. Switch Bluetooth keyboard power to ON position.



3. Press “Fn” + “1” on the Bluetooth keyboard, and then, click the **RESET** to activate Bluetooth discovering and set the FIRST device as ID 1.

\* Indicator LED on the top of keyboard will blink during pairing stage.



6

4. Launch the Bluetooth program (ex, Microsoft Windows control panel) in the FIRST device.
5. Add (search) for new devices. You should be able to find a new device “Bluetooth Keyboard”.
6. During the connection process, it will provide a pass CODE for pairing. Enter the pass CODE from the keyboard.
7. Wait for adding a new HID device “Bluetooth Keyboard” into the system.

### ● Installing Bluetooth keyboard in second to sixth device or Bluetooth host


1. Press “Fn” + “2” ~ “6” on the Bluetooth keyboard, and then, click the **RESET** to activate Bluetooth discovering and set the devices as ID 2 ~ ID 6.
2. The rest steps are the same as you installed it in first device.

### ● Switching to the desired device

1. Press “Fn” + “1” ~ “6”, you can use Bluetooth keyboard in the paired device.

Or

2. Press “Fn” + “Tab” to return to the previous device.



7

## Troubleshooting

- Make sure that you have paired your keyboard with your device. For more information, see “Installing your keyboard” on page 6.
- Make sure that your operating system is compatible with your keyboard. For more information, see “System requirements” on page 4.
- Make sure that the anode(+) and cathode(–) symbols on the batteries match the anode(+) and cathode(–) symbols in the battery compartment.
- Low-Battery is indicated by the illumination of the Keyboard Top case "Batt.Low". Please replace the battery when the LED lights up.

## Specifications

<b>Dimension:</b>	Keyboard: 232.2 (L)* 112.3 (W)* 18.2 (H) mm
<b>Keys No:</b>	Keyboard: 84 keys(JA) / 80 keys(US)
<b>Weight:</b>	Keyboard: 320+-25g (w/o battery)
<b>Key Pitch:</b>	15.9 mm
<b>Interface:</b>	Bluetooth
<b>Compatibility:</b>	Windows ME, Windows 2000, Windows XP x32/ x64, Windows Vista, Windows 7
<b>Operating Temperature:</b>	32°F ~ 104°F (0°C ~ 40°C)
<b>Operating Humidity:</b>	85% RH or less
<b>Storage Temperature:</b>	5°F ~ 140°F (-15°C ~ 60°C)
<b>Storage Humidity:</b>	85% RH or less

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference and
- (2) this device must accept any interference received, including interference that may cause undesired operation