ZIPPY USER'S MANUAL

Bluetooth & Wired Combo Keyboard Model No.: BW7080

, <u>1</u> <u>1</u> <u>1</u> <u>1</u> <u>1</u>	aii 🖂
	ant Break
	Iome PgUp Num / * -
	End PgDn 7 8 9 + PsUp +
	4 5 6 ⊚
	t I 2 3 Enter End + PgDn Enter

Introduction

Congratulations on your purchase of a high-quality product. Your keyboard represents the state of the art in wireless keyboard design and is designed for reliable and trouble-free performance.

Safety

Before getting started, read these instructions and save them for future reference.

- Do not drop or hit your keyboard.
- Do not use your keyboard in a location that is subject to strong vibrations because vibration may damage your keyboard.
- Do not disassemble or modify the product in any way. Disassembly or modification may void your warranty and could damage your keyboard leading to a fire or electric shock.
- Do not use or store your keyboard in damp locations. Liquid entering the product may cause damage or lead to fires or electric shock.
- Do not insert metal objects, such as coins or paper clips, into your keyboard.
- Your keyboard is for general device use. Do not use your keyboard with a device that requires exceptional reliability, especially if a breakdown or malfunction of might jeopardize life or health, such as aerospace equipment, atomic power control system, traffic-related equipment, transportation equipment, industrial robotics,


combustion equipment, safety devices, and life-support systems.

- Batteries may explode or leak if they are improperly recharged, inserted disposed of in fire, or mixed with used batteries or different battery types. There is a risk of explosion if a battery is replaced incorrectly.
- Dispose of used batteries according to local regulations.
- Keep the battery compartment cover and the batteries out of the reach of small children.

Features

- Patented Wired USB and Bluetooth multi-link function that memorizes up to five Bluetooth devices and one USB device, and fast switch between each other.
- 6 LED Bluetooth device indicators inform the present device is connected.
- Multimedia function keys: Last Track, Play/ Pause, Next Track, Calculator, Vol+, Vol-, Mute.
- Specific iPad function key: Screen lock, Home, Search, Picture frame mode, On-screen keyboard.
- Assembled a separable 1.5-meter USB cable.
- Bluetooth 3.0 technology and auto sleep mode extend battery life.
- Reliable Bluetooth connection ranges up to 33 feet (10 meters).
- Patented Scissor-Key Structure provides 10 million service times, positive response and quiet typing.
- A pair of rubber foot enhances user comfort.





- 1. Devices Indicators
- 2. Bluetooth Function Keys
- 3. Media & iPad Hot Keys
- 4. NFC Detection Area
- 5. Bluetooth Pairing Button
- 6. Fn Key
- 7. Micro USB Slot
- 8. On/ OFF Switch

Package Contents

- Bluetooth and Wired Combo Keyboard
- Micro USB Cable
- AA Alkaline Batteries x2
- User's Manual

Operating System Support

- Windows XP
- Windows Vista (32-bit / 64-bit)
- Windows 7 (32-bit / 64-bit)
- Windows 8 (32-bit / 64-bit)
- Mac OS X v10.0 or later
- iOS 6 or later

* Media and iOS hot keys may not support at every OS and device.


Specifications

Keyboard


- Dimension: 451.3(L) x 152.3(W) x 26.0(H) mm
- Weight: 600 ± 20g (w/o battery)
- Interface: Bluetooth / USB
- Operating Distance: 10 Meters
- Key Number: 108 Keys (US) / 109 Keys (UK) / 112 Keys (JA) / 110 Keys (KO) (Incl. 4 Hotkeys)
- Battery: 2 x AA Alkaline Batteries
- Battery Life: 4 Months (base on average usage)

Installing Batteries


1. Open the battery cover.



2. Insert two AA alkaline batteries and make sure the batteries are installed properly.



3. Close the battery cover.




* You don't necessarily need to install batteies if you connect the keyboard with a powerd USB port by USB cable.

Installation Proccedure


Set Up Keyboard - Pair with 1st Bluetooth Compatible Device



2. Select a "Bluetooth" function key to assign 1st device to connect with the keyboard.




- 3. Hold "Fn" key and "Bluetooth Pairing" key to activate Bluetooth discovering.
- * The indicators above the "Bluetooth" keys will BLINK.




4. Complete Bluetooth pairing on the device.

Set Up Keyboard - Connect with device by USB cable

1. Connect the keyboard with a computer by the Micro-USB cable.




2. Select "USB" key to associate with device.* The indicators above the USB keys will be ON.



Switch among Paired Devices

- 1. Press "Bluetooth and USB" function key to select a device to use.
- * The indicators above the "Bluetooth and USB" function keys will be ON.



2. You can also hold "Fn" key and "Tab" to return to use previous device.



Hotkey Functions



- ▶ : Play/ Pause

- : Volume Down
- : Volume Up
- : On-Screen Keyboard (iOS Only)
- $\ensuremath{\mathtt{Q}}$: Search Mode
- \Box : Home Screen (iOS Only)
- Screen Lock (iOS Only)

Troubleshooting

- Make sure that you have paired your keyboard with your device. For more information, see "Installation Procedure" on page 6.
- Make sure that your operating system is compatible with your keyboard. For more information, see "Operating System Support" on page 4.
- Make sure that the anode(+) and cathode(-) symbols on the batteries match the anode(+) and cathode(-) symbols in the battery compartment.

Battery Low

- Low-battery is indicated by illumination on the top case of keyboard. Please replace the batteries when the indicator lights up.
- Do not mix old and new batteries, or mix different types of batteries. This can cause rupture or leakage, resulting in presonal injury or property damage.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference and

(2) this device must accept any interference received,

including interference that may cause undesired operation