


"2.4GHz All Around Freedom, Infinite Possibilities"

Aluminum Transport, RF-722

User Manual



System requirements

- IBM or compatible PC
- Windows Operating System
- Pentium-equivalent processor or above
- At least 10MB hard disk space
- One available USB port

OS support

- Windows XP
- Windows 2000/NT
- Windows ME

Introduction

Thank you for your patronage of purchasing our cordless keyboard and Laser mouse. For your own safety, please read this manual thoroughly before using this product. After you have read this manual, please keep it in place for reference when necessary.

Contents in the package

The following items are included in the package. Please make sure all items are accounted for as you open the package. If there was any item missing or damaged, please contact the reseller where the product was purchased or our support center.

- Wireless Keyboard x 1
- Wireless Laser Mouse x 1
- USB 2.4GHz dongle receiver x 1
- Installation CD x 1
- Manual x 1
- Alkaline batteries x4
(2 AAA for keyboard, 2 AAA for Mouse)

Warning

Any malfunction, damage or personal injury caused by the malfunctioning or damage of the user's personal computer or misuse of this product.

Any attempt to dismantle, change or modify this product in any manner.

Warning

Please do not use this product in ash, wet, or oily environments. Failure to do so may shorten the life of this product and may cause bodily harm. Please keep this product as far away from Radio Frequency interruption areas as possible.

This is not an outdoor product. Exposing this product to the elements may cause damages to the product and bodily harm to its users. Please do not use petroleum, benzene or thinner-based solution to clean this product.

Laser Mouse

International standards and safety. This Laser device complies with International Standard IEC 60825-1:2001-08, Class 1 Laser Product, and also complies with 21 CFR 1040.10 and 1040.11, except for deviations pursuant to Laser Notice No. 50, dated July 26, 2001: 1) Emission of a parallel beam of infrared user-invisible light; 2) Maximum Power of 716 microwatts CW, wavelength range 832-865 nanometers; 3) Operating temperature between 0°C (32°F) to 40°C (104°F).

CAUTION: This Laser device has no serviceable parts. Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

Safety and Usage Guidelines

- Do not point infrared beam at eye.
- In the absence of proper operation and if customer-initiated troubleshooting is unsuccessful, switch off device and call technical support.
- Do not disassemble your product or expose it to liquid, humidity, moisture, or temperatures outside the specified operating range of 0°C (32°F) to 40°C (104°F). 4) If your product is exposed to out-of-range temperatures, switch it off and allow the temperature to return to the normal operating range.

Warranty Information

This product is backed by a One-Year Manufacturer's Warranty, starting from the date of purchase. The warranty covers for free repair in accordance with the contents stated herein but does not cover wear and tear and any malfunction or damages as results of improper usage as stated in this manual.

Specifications

Keyboard

- Dimensions: 430 x 162 x 25 mm
- Weight: 620 +/- 20g (with Battery)
- Key Number: 104 Keys (By language)
- Battery: 2 x AAA batteries
- Battery Life: 3 Month (Base on average usage)
- Channel: 78 Channels automatically switch.
- ID: unique ID for each keyboard
- Radio Frequency: 2.4 GHz
- Hot Keys: previous page, next page, WWW home, stop, refresh, my favorite, search, e-mail, mute, previous, play/pause, next, stop, volume down, volume up, wake up, sleep, power

Mouse

- Dimensions: L 105 x W 55.5 x H 35.5 mm
- Weight: 80.7 +/- 25g (with Battery)
- Key Number: 3 Keys
(Wheel button on middle button)
- Battery: 2 x AAA batteries
- Battery Life: 1 Month (Base on average usage)
- Channel: 78 Channels
- ID: Unique ID for mouse
- Radio Frequency: 2.4 GHz

Dongle Receiver

- Dimensions: L70 x W22.7 x H12.3 mm
- Weight: 10.9g +/- 25g
- Interface: USB 1.1

Installation Procedure

Before installing this product please make sure you have one available USB port reserved for the dongle receiver.

A. Setting up the Dongle Receiver

- Plug the dongle receiver (FIG. 3) into an available USB port.
- Wait for Windows to install drivers for the dongle receiver, keyboard and mouse.
- When the dongle receiver has been properly initialized, its LED light will stay alit.

B. Setting up the Keyboard and Mouse

- Open the keyboard's battery compartment cover and insert the two pieces of AAA Alkaline batteries. Make sure they are properly installed. (FIG. 1)
- Replace the keyboard battery compartment cover.
- Open the mouse's battery compartment cover and insert the two pieces of AAA Alkaline batteries. Make sure they are properly installed and Switch on the switch at the bottom case. (FIG. 2)
- Replace the mouse battery compartment cover.
- Usually the keyboard and mouse have bind in the factory, if the system cannot recognize the keyboard and mouse, please follow step 6~8 to bind keyboard and mouse.
- Let Keyboard right corner and Mouse to close the Dongle to 0~15cm.
- To press any key of keyboard and any button of mouse, the system will automatically recognize the keyboard & mouse.
- The LED indicator on the dongle receiver will show green light when the connecting have been properly set and the keyboard and mouse are working.

Battery Low

- Low-Battery is indicated by the illumination of the mouse Top case. Please replace the battery when the LED lights up.
- While the mouse is in sleep mode, please press any button or move the scroll wheel to wake it up.
- We recommend using alkaline batteries for the keyboard.
- You may need to reset the ID's after replacing new batteries for the keyboard and mouse.

Warning

Please be careful when resetting the ID's for the keyboard, mouse and dongle receiver. Objects with sharp point may break and leave behind shards.

To remove batteries, please repeat steps 4 to 3 or 2 to 1 in reverse order.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions

- This device may not cause harmful interference and
- This device must accept any interference received, including interference that may cause undesired operation

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

Function description

Keyboard






FIG.1

9

Hotkey Functions

There are 18 built-in hotkeys for the RF-722 for quick access under the Windows operating system. Please refer to the following section on their functions.



- 🏠 Home page : Start the WWW browser.
- ✉ E-mail : Start the e-mail application.
- ⏪ Previous : Go back to the previous page of the internet.
- ⏩ Next : Proceed to the next page of the internet.
- 🔍 Search : [Search] button of the internet browser.
- 🔄 Refresh : Reload web page.
- 📌 My favorite : [My favorite] button of the internet browser.
- 🛑 Stop : Stop download of the web page.
- 🔊 Volume down : Turn down the volume.
- 🔊 Volume up : Turn up the volume.
- 🔇 Mute : Toggle the on/off of the sound.
- 🎵 Stop : Stop the play of the CD.
- ⏮ Previous : Return to the previous track of the CD.
- ⏸ Play/Pause : Toggle the play/pause of the CD.
- ⏭ Next : Proceed to the next track of the CD.
- 💤 SLEEP : Suspend Enter the Suspend mode.
- 🌅 Wake up: Wake up system when entering suspend mode.
- 🔌 POWER : Power off or Exit the computer.

10

Mouse




FIG.2

Receiver




FIG.3

11

How to install the software

The CD in the package provide the Number Lock, Scroll Lock, Cap Lock, hotkey information OSD (On Screen Display) function, For Windows 98SE/ 2000/ ME /XP system, the OSD driver should be installed before use, and to use the functions of the hotkeys under Windows 98SE, you must install the software from the CD-ROM. Please follow the steps below on how to install the Multimedia Keyboard software to your system.

1. Insert the CD disk, RF driver, into the CD-ROM drive.
2. The system will automatically run the setup.exe once after the disk is inserted. However, if the system fails to perform the procedure, simply double-click on the setup.exe of CD Disk to continue the installation procedure.
3. Follow all the on-screen instructions.

Attention

If the install screen does not run automatically, open [my computer] --> [CD-ROM] --> [Hot key driver] or [LED OSD driver] folder --> setup.exe icon. When you restart the computer, onscreen Slim Multimedia will show on the screen, and Slim Multimedia icon will show in the taskbar. You can drag the onscreen Slim Multimedia with the mouse to anywhere you want. To close onscreen Slim Multimedia, right click and left click [Finish] from the menu. When you right click Slim Multimedia icon, the menu will show and you can read the help or version information etc.

Number Lock, Scroll Lock, Cap Lock indication software

After install keyboard status indication software, you will find 3 small icon in your task bar as follows:



When you lock up the Number pad, cap or scroll the light will show green color, otherwise it will show the gray color.

Uninstall the Hot Key driver

Click [Start]-->[Program]-->[RF Status]--> uninstall, and uninstall according to the directions on the screen.

Uninstall the OSD driver

Click [Start]-->[Program]-->[wireless]--> uninstall RF keyboard 1.0, and uninstall according to the directions on the screen.

12

FCC Statement on CLASS B

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

13

Mandatory repair charges are required for the following conditions, even within the guarantee period:

- (1) Malfunction or damage is due to misuse or improper alteration or repair.
- (2) Malfunction or damage is caused by the movement or fall during installation after the purchase.
- (3) Malfunction or damage is caused by a fire, salt, gas, earthquake, lightning, wind, water or other natural calamities, or abnormal voltage.
- (4) The manual is not presented.
- (5) Date of purchase, customer's name, name of the shop are not filled in or are altered.
- (6) Malfunction or damage is caused by other devices connected to the RF-722.
To get the repair service, please disconnect RF-722 from other devices connected.

Date	Contents of service
Person in charge	
Person in charge	

14

Warning

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

All brand names, trademarks and logos are the properties of their respective owners.

15