

Quick Reference Manual

Airwave *FM Transmitter*

Technical Specifications:

- I FM band (98.0 – 107.8 MHz)
- I Channel selection up (1 or 0.1MHz)
- I Excellent sound quality
- I LCD display
- I Back light
- I External power source (5V DC 200mA , centre negative)



Note : AC adaptor is **NOT** included

Operation Steps

1. Plug **Air-Wave** to any music source
2. Press and hold (+) buttons 2 sec. to switch on the **Air-Wave**
3. Tune your FM radio to an used frequency
4. Tune Air-Wave to match that frequency
 - (+) button - press once for up 0.1MHz, press and hold 2 sec. for up 1MHz
 - (-) button - press once for down 0.1MHz
5. Press and hold (-) button 2 sec. to switch off the **Air-Wave**

On-line Technical Support

If you have accessed to the World Wide Web, be sure to visit the Zoltrix home page at:

<http://www.zoltrix.com>

FCC Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This Device may not cause harmful interface, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for CLASS B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:

- 1.1. Reorient or relocate the receiving antenna.
- 1.2. Increase the separation between the equipment and receiver.
- 1.3. Connect the equipment into an outlet on a circuit different from that to which receiver is connected.
- 1.4. Consult the dealer or experienced radio/TV technician for help.

WARNING

Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.