



EX1-RT




BLUETOOTH
HEADSET

INSTRUCTION
MANUAL

FITTING YOUR HEADSET




CONNECTING TO YOUR PHONE



EX1-RT

Power / Answer /
Reconnect



Volume Increase

Volume Decrease / Mute

FUNCTIONALITY



POWER ON : Hold for 2 secs until all LED's turn Red.

[Voice Prompt: Power On]

POWER OFF : Hold for 3 secs until LED turns Red, then off.

[Voice Prompt: Power Off]

TAKE A CALL : Press once.

REJECT A CALL : Hold 2 secs.

END A CALL : Press once.

REDIAL : Press twice.

(Re-dialing is only available for the first device if two are connected.)

VOICE-DIALING :

Press once then say 'Call' along with the name of the person you want to ring.

(Voice Dialing is only available for the first device if two are connected.)

For further details on voice dialing, refer to your phone manual).

CALL-WAITING

END CURRENT CALL :

Press once.

PUT CURRENT CALL ON HOLD :

Hold for 2 seconds.

This can also be used during multi-connection of 2 devices.

LOW BATTERY

All LED's will flash Red once every minute.

[Voice Prompt: Battery Low]



VOLUME INCREASE

Tap to increase the volume in increments.



VOLUME DECREASE

Tap to decrease the volume in increments.

MUTE

Hold down for 2 seconds. A tone will sound every 10 seconds when in mute mode. Repeat to un-mute.


IMPORTANT:

Please ensure you read the 'For your Safety' section before using this product.

For technical assistance:

[www.gioteck.com/
contact-support](http://www.gioteck.com/contact-support)

DISTANCE





The EX1-RT headset has a range up to 10 metres (33 ft) from a device before audio degrades or loses connection.


The Bluetooth word mark and logos are owned by the Bluetooth sig, inc. and any use of such marks by Giateck is under licence.


Complies with
IDA Standards
DB100398



CHARGING



 The Power LED will be red during charging and all LED's will light when charged.

 Charging indication will be delayed if the headset has not been used for a long time.

CONNECTING DEVICES

To use the headset for the first time you must pair it with a Bluetooth® enabled device.

1. Ensure the headset is within **1 meter** of the device.
2. **Activate Bluetooth** on the device (Settings >Bluetooth > ON)
3. With the EX1-RT Off, **hold the Power button for 3 secs** until all the LED's illuminate to a solid state. *[Voice Prompt: Pairing]*
4. Select '**EX1-RT**' from the list of Bluetooth devices, or select '**Scan for new devices**'.
5. If the device asks for a **passcode**, enter four zeros (0000).
6. The LEDs will flash every 3 seconds once pairing is successful. *[Voice Prompt: Pairing Successful] [Voice Prompt: Phone Connected]*

The headset will now connect to your device automatically.



If pairing is not completed within 2 minutes the headset will turn off. If this happens, please repeat the pairing process.



The headset will turn off automatically after 10 minutes of inactivity.

MULTI-CONNECTION TO 2 DEVICES

Follow the instructions above to pair the EX1-RT to 2 devices. Switch the headset off and on again, and it will connect to both devices automatically. When the headset is turned on, it will connect to the last device you were connected to.

STREAMING AUDIO

Audio will stream automatically once the EX1-RT is wirelessly connected to a device. Streaming will pause during an incoming/outgoing call and resume when the call ends.

FOR YOUR SAFETY

To help ensure risk-free operation please read these Operational and Safety Guidelines before use:

- Contains small parts. Not suitable for children under 3 years of age.
- Store in a dry and dust free area.
- Do not store in areas of extreme low (0°C) or high (40°C) temperatures.
- Avoid direct sunlight and heat sources.
- Do not allow the product to get wet or dirty; doing so may cause damage.
- Do not clean with benzene, paint thinner, acetone, alcohol, or other such solvents.
- Do not take the product apart; doing so will void your warranty and may cause electrical shock or damage to internal components.
- Do not allow the battery or battery compartment to get into contact with metal objects such as keys or coins.
- Charge the product as specified and only use the charger supplied.
- Avoid charging the product while unattended.
- Check local laws regarding using a headset while driving.
- Keep earbuds clean and free of ear wax to maintain product performance.



Exposure to high volume sound levels may cause temporary or permanent damage to your hearing. You should always set your volume to moderate levels and avoid long exposure to high volume levels.



Please help to conserve the environment by recycling the packaging of this product.



This product should NOT be disposed of in normal household waste. Please take it to an electrical waste collection point.

This product is covered by a one [1] year warranty. For full Terms and Conditions, and for Technical Assistance, go to :

[www.gioteck.com/
contact-support](http://www.gioteck.com/contact-support)

LEGAL

This product complies with the following legal regulations.
For further information go to www.gioteck.com

This device complies with Industry Canada RSS 210 standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Gioteck hereby declares that this product is in compliance with the essential requirements and other provisions of Directive 2004/108/EC and R&TTE 1999/5/EC. To view the full version of the Declaration of Conformity please go online to doc.gioteck.com

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for

a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.



Technical Assistance:

gioteck.com/contact-support

gioteck ™
COME GET SOME