

100mm

500X480mm



i.Lady Bluetooth Headset

User Guide 用户手册(繁體) 用户手册(简体) Bluetooth

Contents

About Your i.Lady Bluetooth Headset 2 Product Specifications 3 i.Lady Overview 4 i.Lady's Accessories 5 Getting Started 5 Charging Your Headset 6-7 Turning Your Headset On and Off 8 Pairing Your Headset with a Mobile Phone 9-10 Pairing Your Headset with Two Mobile Phones 11 Using Your Headset 11-14 Resetting Your Headset / Removing the Pairing History 14 Troubleshooting 15-16 Safety Information 16-17 Care and Maintenance 18-19 Declaration of Conformity 20

About Your i.Lady Bluetooth Headset


Designed to meet with ladies' lifestyle in mind, the i.Tech i.Lady Bluetooth Headset has impressive outlook design, accompany with user-friendly applications, plus fashionable lanyard bundled, in a desirable packaging design. All elements are matched with the taste of lady users. The stylish feminine design likes a water drop. The product also comes with innovative nano technology anti-bacterial coating for users' peace of mind. For maximum convenience, users can wear it on either ear or even carry it with the bundled headset lanyard.

Product Specifications

Bluetooth Specification: v2.0 Class 2 Headset and Handsfree Bluetooth Profiles Supported: 2.4GHz spectrum Range of Frequency: Within 3 hours Nominal Charging Time: Up to 4 hours Talk Time*: Up to 100 hours Standby Time*: 44.2 (L) x 21 (W) x 20.9 (H) mm Dimensions: 8.4 grams Weight:

* may vary due to the user's habit, different modes of operation, and mobile phone settings.


i.Lady Overview



- 1. Multi-function Button (MFB)
• Power On / Off
• Pair with mobile phone
• Answer / End a call
2. Speaker
3. Volume Up Key
4. Volume Down Key
5. Status Indicator
6. Built-in Rechargeable Battery
7. Built-in Microphone
8. Charging Socket
9. Earbud

60mm

i.Lady's Replaceable Earbud



Getting Started

To use your i.Lady Bluetooth headset ("headset"), please follow the steps below:
1. Ensure your headset is fully charged.
2. Pair your charged headset with a Bluetooth-enabled mobile phone.

Charging Your Headset



The headset comes with a built-in rechargeable battery. Prior to using the headset for the first time, it is recommended to fully charge the battery. Insert the charger's plug into the headset's charging socket (see fig.2) and plug the mains charger to an AC wall outlet. The headset's status indicator will stay red during charging. IMPORTANT: Charging indication will be delayed for a few seconds if the headset has not been used for a long time or the battery is drained.

Charging Your Headset (cont'd)

Normal Charging Time
It takes about three hours to fully charge the battery. When the battery is fully charged, the status indicator will turn blue and will remain on. Unplug the mains charger from the AC wall outlet and the charger's plug from the headset. Press and hold the MFB (see fig.1) for two seconds to turn on the headset. Please refer to "Turning Your Headset On and Off" on the next page for further details.

Talk and Standby Time
A fully charged battery can offer up to 4 hours of talk time and up to 100 hours of standby time. The headset remains in standby mode after being turned on.

Battery Low Indication
When the headset is on and the battery has become low, the status indicator will flash red and the headset will emit a beep every minute. Please follow the instructions described above to recharge the battery.

Turning Your Headset On and Off


Turning On the Headset
Press and hold the MFB (see fig.1) for two seconds until you hear a short beep. The status indicator will then flash blue.

IMPORTANT: If your headset is paired with your mobile phone, press the MFB once more to re-activate pairing and ensure the connection between them is resumed. For pairing, please refer to "Pairing Your Headset" of this user guide.

Turning Off the Headset
Press and hold the MFB for two seconds until you hear a long beep. The status indicator will turn red and the headset will turn off.
IMPORTANT: If you do not plan to use the headset for a while, it is recommended to turn off the Bluetooth function of your mobile phone as well.

Pairing Your Headset with a Mobile Phone

The headset works with Bluetooth-enabled mobile phones only. Prior to using and pairing your headset for the first time, please check if your mobile phone is Bluetooth-enabled. This information will normally feature on the packaging or user guide that is provided with your mobile phone.



Pairing is only required the first time you use the headset with your mobile phone. Below are the pairing instructions for a typical Bluetooth-enabled mobile phone. The headset pairing procedure will vary depending on the model of your mobile phone. Please refer to your mobile phone user guide for pairing instructions.

- 1. Place the headset and the mobile phone where they are no more than one metre apart.
2. Ensure the headset is off, i.e. the status indicator is unlit and should not be flashing.
3. Press and hold the MFB until the headset's status indicator flashes blue and red alternately.
4. Activate your mobile phone's Bluetooth function by referring to your mobile phone user guide for details.

Pairing Your Headset with a Mobile Phone (cont'd)

5. Set the mobile phone to search for all Bluetooth devices within one metre range, and select "i.Lady" from the list of devices shown.
6. Enter the passkey "0000" and press "OK" to pair your headset with the mobile phone. When the pairing is completed, the headset's status indicator will flash blue rapidly for five times followed by a long beep.
7. If prompted by the mobile phone to connect, select "Yes" (this will vary between mobile phones).
8. Go back to your mobile phone's main menu. For certain mobile phone models, once the headset is activated a headset icon will be displayed on the screen. You should now be able to make and receive calls using your headset.

IMPORTANT: If the pairing cannot be completed within three minutes after the pairing mode has been activated, the headset's status indicator will flash purple accompanied by three beeps. The headset will then turn off. Please repeat steps 2 to 8 above to pair the headset and the mobile phone again.

Pairing Your Headset with Two Mobile Phones (Multipoint)

i.Lady supports a Multipoint function to allow simultaneous pairing of the headset with two mobile phones. Follow the pairing procedure as instructed in "Pairing Your Headset with a Mobile Phone" to pair the headset with the first mobile phone and then repeat the pairing procedure for the second mobile phone. When you have completed the pairings, on the first mobile phone's menu activate its Bluetooth connection with the headset.

Using Your Headset

Answering a Call
When there is an incoming call, you will hear the ring tone through the headset. Press the MFB once to accept the call, or answer the call via your mobile phone in the normal way.
Answering a Second Call Intended for Your Other Mobile Phone While Engaged in a Call
This feature is only applicable if you have paired the headset with two mobile phones. When you are on the first call and there is a second call intended for your other mobile phone, first press the MFB once to terminate the first call, then press the MFB once again to answer the second call.
Ending a Call
Press the MFB once to end your call, or end the call via your mobile phone in the normal way.

Using Your Headset (cont'd)

Rejecting a Call
When you hear a ring tone through the headset, press and hold the Volume Up Key to reject the incoming call.
Rejecting a Second Call Intended for Your Other Mobile Phone While Engaged in a Call
This feature is only applicable if you have paired the headset with two mobile phones. When you are on the first call and there is a second call intended for your other mobile phone, press and hold the Volume Up Key to reject the second call.
Transferring a Call
While speaking, press and hold the Volume Up Key for two seconds to transfer the call from your headset to mobile phone.
To transfer the call from the mobile phone to headset, press the MFB once.
Call Muting during the Call
While speaking, press and hold the Volume Down Key for two seconds to mute the built-in microphone. When the mute function is activated, you will hear a short beep every five seconds and the headset's status indicator will flash red every five seconds.
To deactivate the muting function, press and hold the Volume Down Key for two seconds during the call.

Using Your Headset (cont'd)

Adjusting the Volume
While speaking, press the Volume Up or Down Key once to increase or decrease the volume by one level; press repeatedly until you reach the desired volume level. You can also adjust the headset's volume on your mobile phone by pressing the volume keys.
Dialing from Your Mobile Phone
Simply make calls on your mobile phone in the normal way.
Voice Dialing from Your Headset
This feature is only applicable to mobile phone with Bluetooth handsfree profile. If your mobile phone is equipped with the voice dialing function, simply press the MFB on your headset, and when you hear a beep say the voice tag. The headset will always make the call from the last mobile phone used.
IMPORTANT: You must record the voice tag (the person's name) into your mobile phone prior to using the voice dialing function on the headset. Please refer to your mobile phone user guide on how to record the voice tag.

Using Your Headset (cont'd)

Last Number Redialing from Your Headset
This feature is only applicable to mobile phone with Bluetooth handsfree profile. Two quick presses on the MFB will re-dial the last phone number used.
Resetting Your Headset / Removing the Pairing History
You may reset the headset to its default settings. Resetting will also remove the pairing settings of your headset with the mobile phone.
1. Insert the charger's plug into the headset's charging socket. The status indicator will stay red.
2. Press and hold either volume key for ten seconds until the status indicator flashes purple and red alternately.
3. Release the volume key.
4. Press and hold either volume key again until the status indicator flashes purple and then release the volume key.
5. The status indicator will stay red again and the headset is reset.
i.Tech Bluetooth headset is designed to work with Bluetooth devices. Due to large variability between different Bluetooth devices from different manufacturers, interoperability between the headset and all Bluetooth-enabled products is not guaranteed.

Troubleshooting

I can hear crackling noise.
To receive the best audio quality, it is recommended to wear your headset on the same side of the body as your mobile phone.
I can't hear anything in my headset.
• Ensure the headset is turned on and is properly charged.
• Ensure the headset is properly paired with the mobile phone.
• Make sure that the mobile phone is connected with the headset - if it does not connect, either refer to the mobile phone's Bluetooth menu or by pressing the MFB once (see "Turning On the Headset" and "Pairing Your Headset with a Mobile Phone").
I can't connect my headset with mobile phone.
• Ensure your headset is turned off and is properly charged.
• Ensure the headset is properly paired with your mobile phone.
• Ensure your mobile phone's Bluetooth feature is activated. Please refer to your mobile phone user guide for specific instruction.
• Ensure the headset is within ten metres range of your mobile phone and there are no obstructions, such as walls or other electronic devices in between.
If the above steps do not solve your problem, please recharge the headset and remove your mobile phone's battery for a while.

Troubleshooting (cont'd)

I can't turn off the headset.
Recharge the headset for two seconds then disconnect the charger from the headset. The headset now turns off.
Safety Information
• Check and observe local laws regarding the use of a mobile phone and a headset while driving. If you use the headset while driving, ensure your full attention and focus. It is your responsibility to drive safely. Consider to pull off the road before making or answering a call.
• Never leave your headset above any air bag deployment area inside your car as serious injury may result when an air bag deploys.
• Never allow children to play with the headset - small parts may be of choking hazard.
• Observe all signs and displays that require an electrical device or RF radio product to be switched off in designated areas. These could include hospitals, blasting areas, and potentially explosive atmospheres.
• Turn off your headset prior to boarding an aircraft. Do not use your headset inside an aircraft.
• To prevent damage to your hearing, please do not set the listening volume too high.
• Do not attempt to modify the headset.

Safety Information (cont'd)

• Never use the headset while taking a bath.
• Do not use the headset in a sauna or steam room.
• Do not keep the headset near a wash basin or other wet places.
• Do not use the headset outdoors in the rain.
• Do not clean the headset while it is being charged. Always disconnect the charger from the headset before cleaning.
• Do not attempt to force open the built-in battery.
• Dispose of the battery and the headset according to local regulations. Do not dispose of them as household waste.
FCC RF Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Care and Maintenance

Headset
• Turn off your headset before placing it in your pocket or bag. If the MFB is accidentally depressed, your mobile phone may place an unintended call.
• Do not expose the headset to liquid, moisture or humidity, or rain as it is not waterproof.
• Do not use abrasive cleaners to clean the headset.
• Do not expose the headset to extremely high or low temperatures.
• Do not leave the headset in direct sunlight for an extended period of time.
• Do not leave the headset near open flames such as cooking burners.
• Do not dispose of the headset in a fire as it will result in explosion.
• Do not bring the headset into contact with any sharp objects as this will cause scratches and damages.
• Do not stick anything inside the headset as this may damage internal components.
• Do not attempt to disassemble the headset as it does not contain serviceable components.
• If you do not plan to use the headset for a long period, please store it in a dry place that is free from extreme temperatures and dust.

Care and Maintenance (cont'd)

• Only charge the headset's built-in battery in accordance with the instructions described in this user guide.
• Avoid charging the headset in extremely high or low temperatures.
• Do not connect the headset to the charger while on an active call.
Built-in Battery
• Do not attempt to replace the headset's battery as it is in-built and is not changeable.
• Dispose of the battery according to local regulations. Do not dispose of the battery as household waste.
• Charge the battery in accordance with the instructions supplied with this user guide.
• Use only the charger supplied by the headset's original manufacturer to charge the battery.
Charger
• Use only the charger supplied by the headset's original manufacturer to charge the headset. Other chargers may look similar but using them could be dangerous and could damage the headset.
• Do not attempt to disassemble the charger as it may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the headset is subsequently used.
• Do not use the charger outdoors or in damp areas.

Declaration of Conformity

We, i.Tech Dynamic Limited, declare that the following product:
Product Name: i.Tech i.Lady
Model No.: CS1-B07003-XX
is in conformity with the following essential requirements of Council Directive 1999/5/EC (referred to as R&TTE Directive): Article 3.1.a, 3.1.b and 3.2. and the product is manufactured in accordance with Annex II of the above directive.
A copy of the Declaration of Conformity can be found at http://www.ittechdynamic.com.

i.Tech declares under our sole responsibility that the headset is in conformity with the provisions of the following Council Directives: 1999/5/EC.
Notes on Environmental Protection
After the implementation of the European Directive 2002/96/EU in the national legal system, the following applies: Electrical and electronic devices must not be disposed of with domestic waste. Consumers are obliged by law to return electrical and electronic devices at the end of their service lives to the public collection points that are set up for this purpose or designated points of sale. However, such details are defined by the national law of the respective country. This symbol on the product, the instruction manual or the packaging indicates that the product is subject to these regulations. By recycling, reusing the materials, or other forms of utilizing old devices, you are making an important contribution in protecting our environment.



Dispose of the packaging and this product in accordance with the latest provisions.

Federal Communications Commission (FCC) Statement

15.21
You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.
15.105(b)
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Operation is subject to the following two conditions:

1) this device may not cause interference and
2) this device must accept any interference, including interference that may cause undesired operation of the device.
©2007 Hutchison Harbour Ring Enterprises Limited
All rights in this publication are reserved and no part may be reproduced without the prior written permission of the publisher. The contents of this publication are believed to be correct at the time of going to press, but any information, specifications, products or services mentioned, and product I.D. shown may be modified, supplemented or withdrawn without further notice.
The Stylized i.Tech logos are trademarks owned by Hutchison Harbour Ring Enterprises Limited or its affiliates. All other trademarks or registered trademarks belong to their respective owners.

http://www.ittechdynamic.com
Printed in China 05/2007



20

21

22

23