

ww	w.	tuʻ	V.C	20	m

1.6 User Manual





Contents

Product Specifications	2
Clip Vibrate Overview	3
Getting Started	4
Charging Your Headset	4-5
Turning Your Headset On and Off	
Pairing Your Headset with a Mobile Phone	_
Pairing Your Headset with Two Mobile Phones (Multipoint)	
Using Your Headset	
Resetting Your Headset / Removing the Pairing History	
Troubleshooting	
Safety Information	
Care and Maintenance	
Declaration of Conformity	
Decidiation of comorning	17



Product Specifications

Bluetooth Specification: v2.0 class 2

Bluetooth Profiles Supported: Headset and Handsfree
Range of Frequency: 2.4GHz spectrum
Nominal Charging Time: Within 3 hours
Talk Time*: Up to 10 hours
Standby Time*: Up to 180 hours


Dimensions: 47 (L) x 18.5 (W) x 24.3 (H) mm

Weight: 19.5 grams

* may vary due to the user's habit, different modes of operation, and mobile phone settings.

2

Clip Vibrate Overview



- 1. Multi-function Button (MFB)
 - Power On / Off
 - Pair with mobile phone
 - Answer / End a call
 - Last number redial
 - Voice dialling
- 2. Volume Kev
 - Adjust volume
 - Reject / Transfer a call
 - Select a call alert mode
 - Reset the headset
- 3. Status Indicator
- 4. Built-in Rechargeable Battery
- 5. Built-in Microphone
- 6. USB Charging Socket
- 7. Speaker



Getting Started

To use your Clip Vibrate *Bluetooth* Clip headset ("headset"), please follow the steps below:

- 1. Ensure your headset is fully charged.
- 2. Pair your charged headset with a Bluetooth-enabled mobile phone.

Charging Your Headset

The headset comes with a built-in rechargeable battery. Prior to using the headset for the first time, it is recommended to fully charge the battery. Insert the charger's plug into the headset's USB charging socket (see fig.2) and plug the mains charger to an AC wall outlet.



• Use only the supplied charger to charge the headset.

A

Charging Your Headset (cont'd)

Status	Status Indicator (fig.1)	Audio from the headset
 Charging 	Solid Red	
Fully charged	Solid Blue	
Low battery	 Flashing Red 	a short beep every 1 minute
Out of battery	 The light turns off 	

- Charging indication will be delayed for a few seconds if the headset has not been used for a long time or the battery is drained.
- ♦ 3 hours are required to fully charge the headset.

Talk and Standby Time

A fully charged battery can offer up to 10 hours of talk time and up to 180 hours of standby time. The headset remains in standby mode after being turned on.



Turning Your Headset On and Off


To	Press and hold	Status Indicator (fig. 1)	
• Turn ON	 the MFB (fig.1) for 2 seconds until you hear a short beep 	• Flashing blue	
• Turn OFF	the MFB for 2 seconds until you hear a long beep	 Flashing red for 2 seconds and then the light turns off 	

- The headset remains in standby mode after being turned on, i.e. the status indicator flashes blue.
- If your headset is paired with your mobile phone, press the MFB once more after you
 turned on the headset to re-activate pairing and ensure the connection between the
 mobile phone and headset is resumed. For pairing, please refer to "Pairing Your Headset".
- If you do not plan to use the headset for a while, you are recommended to turn off the Bluetooth function of your mobile phone.

6

Pairing Your Headset with a Mobile Phone

The headset works with *Bluetooth*-enabled mobile phones only. Prior to using and pairing your headset for the first time, please check if your mobile phone is *Bluetooth*-enabled. This information will normally feature on the packaging or user guide that is provided with your mobile phone.



Pairing is only required the first time you use the headset with your mobile phone. Below are the pairing instructions for a typical *Bluetooth*-enabled mobile phone. The headset pairing procedure will vary depending on the model of your mobile phone. Please refer to your mobile phone user quide for pairing instructions.

- Place the headset and the mobile phone where they are no more than one metre apart.
- 2. Ensure the headset is off, i.e. the status indictor is unlit and should not be flashing.
- 3. Press and hold the MFB until the headset's status indicator flashes blue and red alternately.
- When you turn on your headset for the first time, the headset proceeds into pairing mode, i.e. the status indicator flashes blue and red alternately, so that you can immediately pair it with your mobile phone.



Pairing Your Headset with a Mobile Phone (cont'd)

- 4. Activate your mobile phone's *Bluetooth* function by referring to your mobile phone user guide for details.
- 5. Set the mobile phone to search for all *Bluetooth* devices within one metre range, and select "Clip Vibrate" from the list of devices shown.
- 6. Enter the passkey "0000" and press "OK" to pair your headset with the mobile phone. When the pairing is completed, the headset's status indicator will flash blue rapidly for five times followed by a long beep*.
- 7. If prompted by the mobile phone to connect, select "Yes" (this will vary between mobile phones).
- 8. Go back to your mobile phone's main menu. For certain mobile phone models, once the headset is activated a headset icon will be displayed on the screen.

You should now be able to make and receive calls using your headset.

- *If you are using your headset in a noisy environment, you are recommended to put on the earpiece so that the beep will be audible.
- If the pairing cannot be completed within three minutes after the pairing mode has been activated, the headset's status indicator will flash purple accompanied by three beeps. The headset will then turn off. Please repeat steps 2 to 8 above to pair the headset and the mobile phone again.

8

Pairing Your Headset with Two Mobile Phones (Multipoint)

Clip Vibrate supports a Multipoint function to allow simultaneous pairing of the headset with two mobile phones.

- Follow the pairing procedure as instructed in "Pairing Your Headset with a Mobile Phone" to pair the headset with the first mobile phone.
- 2. Repeat the pairing procedure for the second mobile phone.
- 3. On the first mobile phone's menu, activate its Bluetooth connection with the headset.

Using Your Headset

Answering a Call

When there is an incoming call, the status indicator will flash purple. Press the MFB once to accept the call, or answer the call via your mobile phone in the normal way.

 It is important that the headset is not clipped too low on your clothing in order for the microphone to clearly transmit your voice.

Answering a Second Call

This feature is only applicable if you have paired the headset with two mobile phones. When you are on the first call and there is a second call intended for your other mobile phone, first press the MFB once to terminate the first call, then press the MFB once again to answer the second call.



Using Your Headset (cont'd)

Ending a Call

Press the MFB once to end your call, or end the call via your mobile phone in the normal way. Incoming Call Alert

The headset default is both ringing the buzzer and vibrating mode simultaneously when there is an incoming call. You can select each one independently.

- Ensure the headset is turned on.
- Press and hold the volume key for 5 seconds. The status indicator will flash blue and purple alternately followed by a short beep.
- 3. Release the volume key. The headset will demonstrate 3 incoming call alert modes in sequence for your selection:

	incoming Call Alert Modes		
	Vibrator	Buzzer	
1.	ON	OFF	
2.	ON	ON	
3.	OFF	ON	

10

Using Your Headset (cont'd)

Incoming Call Alert (cont'd)

- 4. Press the volume key once to select your preferred mode within 5 seconds of the start of each demonstration. The headset will emit a long beep and the status indicator will flash purple twice. Your selection is confirmed. The headset will then return to standby mode, i.e. the status indicator will flash blue.
- If you fall to select your preferred mode within 5 seconds of the start of a demonstration, the headset will go to next demonstration.
- ♦ The new mode selection will replace the previous one automatically.
- Press and hold the volume key for 2 seconds at any time during the demonstrations to return to the standby mode without updating the current setting.
- ♦ The demonstration cycle will repeat continuously for 2 minutes. If you do not make a selection the headset will return to standby mode.

Adjusting the Volume

While speaking, press the volume key once to increase or decrease the volume by one level; press repeatedly until you reach the desired volume level.

You can also adjust the headset's volume on your mobile phone by pressing the volume key. Rejecting a Call (Handsfree Profile Applicable Only)

When there is an incoming call, press and hold the volume key to reject it.



Using Your Headset (cont'd)

Rejecting a Second Call (Handsfree Profile Applicable Only)

This feature is only applicable if you have paired the headset with two mobile phones. When you are on the first call and there is a second call intended for your other mobile phone, press and hold the volume key to reject the second call.

Transferring a Call (Handsfree Profile Applicable Only)

while speaking, press and hold the volume key for two seconds to transfer the call from your headset to mobile phone.

To transfer a call back to your headset during a call, press the MFB once.

Dialing from Your Mobile Phone

Simply make calls on your mobile phone in the normal way.

Voice Dialing from Your Headset (Handsfree Profile Applicable Only)

If your mobile phone is equipped with the voice dialing function, simply press the MFB on your headset, and when you hear a beep say the voice tag. The headset will always make the call from the last mobile phone used.

• You must record the voice tag (the person's name) into your mobile phone prior to using the voice dialing function on the headset. Please refer to your mobile phone user guide on how to record the voice tag.

12

Using Your Headset (cont'd)

Last Number Redialing from Your Headset (Handsfree Profile Applicable Only)

Two quick presses on the MFB will re-dial the last phone number used.

Resetting Your Headset / Removing the Pairing History

You may reset the headset to its default settings. Resetting will also remove the pairing settings of your headset with the mobile phone.

- Connect the supplied charger to your headset and then to AC power. The status indicator will stay red.
- Press and hold the volume key for ten seconds until the status indicator flashes purple and red alternately.
- 3. Release the volume key.
- Press and hold the volume key again until the status indicator flashes purple and then release the volume key.
- 5. The status indicator will stay red again and the headset is reset.

i.Tech *Bluetooth* headset is designed to work with *Bluetooth* devices. Due to large variability between different *Bluetooth* devices from different manufacturers, interoperability between the headset and all *Bluetooth*-enabled products is not guaranteed.



Troubleshooting

I can't hear anything in my headset.

- Ensure the headset is turned on and is properly charged.
- Ensure the headset is properly paired with the mobile phone.
- Make sure that the mobile phone is connected with the headset If it does not connect, either
 refer to the mobile phone's Bluetooth menu or by pressing the MFB once (see "Turning On the
 Headset" and "Pairing Your Headset with a Mobile Phone").

I can't connect my headset with mobile phone.

- Ensure your headset is turned off and is properly charged.
- Ensure the headset is properly paired with your mobile phone.
- Ensure your mobile phone's Bluetooth feature is activated. Please refer to your mobile phone
 user guide for specific instruction.
- Ensure the headset is within ten metres range of your mobile phone and there are no obstructions, such as walls or other electronic devices in between.

If the above steps do not solve your problem, please recharge the headset and remove your mobile phone's battery for a while.

I can't turn off the headset.

Recharge the headset for two seconds then disconnect the charger from the headset. The headset now turns off.

14

Safety Information

- Check and observe local laws regarding the use of a mobile phone and a headset while driving.
 If you use the headset while driving, ensure your full attention and focus. It is your responsibility to drive safely. Consider to pull off the road before making or answering a call.
- Never leave your headset above any air bag deployment area inside your car as serious injury
 may result when an air bag deploys.
- Never allow children to play with the headset small parts may be of choking hazard.
- Observe all signs and displays that require an electrical device or RF radio product to be switched off in designated areas. These could include hospitals, blasting areas, and potentially explosive atmospheres.
- Turn off your headset prior to boarding an aircraft. Do not use your headset inside an aircraft.
- To prevent damage to your hearing, please do not set the listening volume too high.
- Do not attempt to modify the headset.
- Never use the headset while taking a bath.
- Do not use the headset in a sauna or steam room.
- Do not keep the headset near a wash basin or other wet places.



Safety Information (cont'd)

- Do not use the headset outdoors in the rain.
- Do not use the headset in stormy weather.
- Do not clean the headset while it is being charged. Always disconnect the charger from the headset before cleaning.
- Do not attempt to force open the built-in battery.
- Dispose of the battery and the headset according to local regulations. Do not dispose of them
 as household waste.

FCC RF Radiation Exposure Statement:

This equipment compiles with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compilance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

16

Care and Maintenance

Headset

- Turn off your headset before placing it in your pocket or bag. If the MFB is accidentally
 depressed, your mobile phone may place an unintended call.
- Do not expose the headset to liquid, moisture or humidity, or rain as it is not waterproof.
- Do not use abrasive cleaners to clean the headset.
- Do not expose the headset to extremely high or low temperatures.
- Do not leave the headset in direct sunlight for an extended period of time.
- Do not leave the headset near open flames such as cooking burners.
- Do not dispose of the headset in a fire as it will result in explosion.
- Do not bring the headset into contact with any sharp objects as this will cause scratches and damages.
- Do not stick anything inside the headset as this may damage internal components.
- Do not attempt to disassemble the headset as it does not contain serviceable components.
- If you do not plan to use the headset for a long period, please store it in a dry place that is free
 from extreme temperatures and dust.



Care and Maintenance (cont'd)

- Only charge the headset's built-in battery in accordance with the instructions described in this
 user guide.
- Avoid charging the headset in extremely high or low temperatures.
- Do not connect the headset to the charger while on an active call.

Built-in Battery

- Do not attempt to replace the headset's battery as it is in-built and is not changeable.
- Dispose of the battery according to local regulations. Do not dispose of the battery as household waste.
- Charge the battery in accordance with the instructions supplied with this user guide.
- Use only the charger supplied by the headset's original manufacturer to charge the battery.
 Charger
- Use only the charger supplied by the headset's original manufacturer to charge the headset.
 Other chargers may look similar but using them could be dangerous and could damage the headset.
- Do not attempt to disassemble the charger as it may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the headset is subsequently used.
- Do not use the charger outdoors or in damp areas.

18

Declaration of Conformity

We, I.Tech Dynamic Limited, declare that the following product:

Product Name: I.Tech Clip Vibrate Model No.: C51-B07004-XX

is in conformity with the following essential requirements of Council Directive 1999/5/EC (referred to as R&TTE Directive): Article 3.1a, 3.1.b and 3.2. and the product is manufactured in accordance with Annex II of the above directive.

A copy of the Declaration of Conformity can be found at http://www.itechdynamic.com.



I.Tech declares under our sole responsibility that the headset is in conformity with the provisions of the following Council Directives: 1999/5/EC.

Notes on Environmental Protection

After the implementation of the European Directive 2002/96/EU in the national legal system, the following applies: Electrical and electronic devices must not be disposed of with domestic waste. Consumers are obliged by law to return electrical and electronic devices at the end of their service lives to the public collection points that are set up for this purpose or designated points of sale. However, such details are defined by the national law of the respective country. This symbol on the product, the instruction manual or the packaging indicates that the product is subject to these regulations. By recycling, reusing the materials, or other forms of utilizing old devices, you are making an important contribution in protecting our environment.



Dispose of the packaging and this product in accordance with the latest provisions.

20

Federal Communications Commission (FCC) Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

©2007 Hutchison Harbour Ring Enterprises Limited

All rights in this publication are reserved and no part may be reproduced without the prior written permission of the publisher. The contents of this publication are believed to be correct at the time of going to press, but any information, specifications, products or services mentioned, and product I.D. shown may be modified, supplemented or withdrawn without further notice.

The Stylized i.Tech logos are trademarks owned by Hutchison Harbour Ring Enterprises Limited or its affiliates. All other trademarks or registered trademarks belong to their respective owners.

http://www.ltechdynamic.com

Printed in China 09/2007