

www.tuv.com

1.5 User Manual



BlueBAND Sport

Bluetooth Stereo Headphones



Contents

Product Specifications	1
BlueBAND Sport Overview	2
Getting Started	2
Charging Your Headphones	3
Pairing Your Headphones with a <i>Bluetooth</i> Mobile Phone	4
Turning Your Headphones On and Off	5
Using Your Headphones	6-7
Resetting Your Headphones / Removing the Pairing History	8
Troubleshooting	9
Safety Information	10
Care and Maintenance	11-12
Declaration of Conformity	13
Federal Communications Commission (FCC) Statement	14

Product Specifications



<i>Bluetooth</i> Specification:	v2.0+EDR Class 2
<i>Bluetooth</i> Profiles Supported:	Headset, Handsfree, A2DP & AVRCP
Range of Frequency:	2.4GHz Spectrum
Operating Distance:	10 meters
Charging Time:	within 3 hours
Talk Time*:	Up to 11 hours
Music Playing Time*:	Up to 11 hours
Standby Time*:	Up to 200 hours
Dimensions:	90 (L) x 80 (W) x 118 (H) mm
Weight:	72.6 grams

* may vary due to users' operation mode and mobile phone settings

1

BlueBAND Sport Overview

1. Volume + / SRS Key
2. Status Indicator
3. Multi-function Button (MFB) / Play / Pause
4. Rewind ⏮
5. Fast Forward ⏭
6. Volume –
7. Microphone
8. USB Charging Socket (open the cover)



Getting Started

Before using your BlueBAND Sport ("headphones") for the first time, please ensure that

1. the headphones are fully charged;
2. the fully charged headphones must be paired and connected with a Bluetooth mobile phone.

2

Charging Your Headphones

The headphones come with a built-in rechargeable battery. Prior to using the headphones for the first time, you are recommended to fully charge the battery.



! Use only the supplied charger to charge the headphones.

Status	Status Indicator	Audio
• Charging	• Red light	
• Fully charged	• Blue light	
• Low battery	• Flashing red light	• a short beep every 1 minute
• Out of battery	• The light goes off	

- 3 hours are required to fully charge the headphones.
- Charging indication will be delayed for a few seconds if the headphones have not been used for a long time or the battery is drained.

3

Pairing Your Headphones with a *Bluetooth* Mobile Phone

Pairing is only required the first time you use the headphones. Please refer to your mobile phone user guide for pairing instructions.

- 1) Ensure the headphones are off.
- 2) To activate the pairing mode, press and hold the headphones' MFB for 8 seconds without releasing your finger until its status indicator flashes blue and red light alternately.
- 3) Activate your mobile phone's *Bluetooth*, search *Bluetooth* devices, select "BlueBAND Sport" and enter the password "8888".
- 4) When the pairing is completed, the headphones' status indicator will flash blue light rapidly for five times.

If the pairing cannot be completed within 3 minutes after the pairing mode has been activated, the headphones' status indicator will flash purple rapidly for five times and then turns off. Repeat steps 1 to 4 to pair both devices again.

Turning Your Headphones On and Off

Function	Button	Audio	Status Indicator
Turn on	Press and hold the MFB for 2 seconds	a short beep	Flashing blue light for 3 times
<p>i When you turn on your headphones for the first time, the headphones automatically enter the pairing mode, i.e. the status indicator flashes blue and red alternately. This allows you to immediately pair your headphones and mobile phone. Please refer to "Pairing Your Headphones with a Bluetooth Mobile Phone".</p>			
Turn off	Press and hold the MFB for 2 seconds	a long beep	Red light for 2 seconds and then the light goes off

- If your headphones are paired with your mobile phone, press the MFB once more after you turned on the headphones to re-connect the mobile phone and headphones.
- If you do not plan to use the headphones for a while, you are recommended to turn off the **Bluetooth** function of your mobile phone.

5

Using Your Headphones

Call Functions

Function	Button	Audio	Status Indicator
Answer a call	Press the MFB once		Flashing purple light
End a call	Press the MFB once		Flashing blue light
Adjust Volume	Press the Volume + / Volume - once to increase / decrease by 1 step (Total 8 levels)		Flashing blue light
Voice Dialing	Press ▶▶ once	a short beep	Flashing blue light say the voice tag as soon as you hear the short beep and you must have recorded the voice tag into your mobile phone
Last No. Redial	Double click ▶▶		Flashing blue light
Call Waiting	Press the MFB once		
Call Reject	Press and hold either Volume Key for 2 seconds	a short beep	Flashing blue light
Call Transfer (headset to mobile phone)	While speaking, press and hold either Volume Key for 2 seconds		Flashing blue light
Call Transfer (mobile phone back to headset)	While speaking, press ▶▶ once		Flashing blue light

6

Using Your Headset (cont'd)

Music Playing Functions (A2DP and AVRCP Applicable Only)

Function	Button	Audio	Status Indicator
Disable SRS (the default is SRS ON)	When playing music, press and hold the Volume + for 2 seconds	a short beep	Flashing blue light once
Enable SRS	same as "above"	2 short beeps	Flashing blue light twice
Answer a call when playing music	Press the MFB once		Flashing purple light when there is a call
End a call and resume music	Press the MFB once		Flashing blue light*
Play	Press ▶▶ once		Flashing blue light*
Pause	Press ▶▶ once		Flashing blue light*
Fast Forward	Press and hold ▶▶▶		Flashing blue light*
Next Track	Press ▶▶▶ once		Flashing blue light*
Rewind	Press and hold ◀◀◀		Flashing blue light*
Replay	Press ◀◀◀ once		Flashing blue light*
Adjust Volume	Press the Volume + / Volume - once to increase / decrease by 1 level (Total 8 levels)		Flashing blue light*

*If SRS is enabled, the status indicator will flash blue light twice every time.

7

Resetting Your Headphones / Removing the Pairing History

You may reset the headphones to its default settings. Resetting will also remove the pairing settings of your headphones with the mobile phone.

1. Connect the supplied charger to your headset and then to AC power. The status indicator will stay red.
2. Press and hold the **Volume +** for 10 seconds until the status indicator flashes purple.
3. Release the **Volume +**.
4. Press and hold the **Volume +** again until the status indicator flashes purple and then release the **Volume +**.
5. The status indicator will stay red again and the headphones are reset.

LTech Bluetooth headset is designed to work with Bluetooth devices. Due to large variability between different Bluetooth devices from different manufacturers, interoperability between the headset and all Bluetooth-enabled products is not guaranteed.

8

Troubleshooting

I can't hear anything in my headphones.

- Ensure the headphones are turned on and are properly charged.
- Ensure the headphones are properly paired with the mobile phone.
- Make sure that the mobile phone is connected with the headphones - if it does not connect, either refer to the mobile phone's *Bluetooth* menu or by pressing the MFB once (see "Turning Your Headphones On and Off" and "Pairing Your Headphones with a *Bluetooth* Mobile Phone").

I can't connect my headphones with mobile phone.

- Ensure your headphones are turned on and are properly charged.
- Ensure the headphones are properly paired with your mobile phone.
- Ensure your mobile phone's *Bluetooth* feature is activated. Please refer to your mobile phone user guide for specific instruction.
- Ensure the headphones are within ten metres range of your mobile phone and there are no obstructions, such as walls or other electronic devices in between.

If the above steps do not solve your problem, please recharge the headphones and remove your mobile phone's battery for a while.

I can't turn off the headphones.

Recharge the headphones for two seconds then disconnect the charger from the headphones. The headphones now turn off.

9

Safety Information

- Check and observe local laws regarding the use of a mobile phone and headphones while driving. If you use the headphones while driving, ensure your full attention and focus. It is your responsibility to drive safely. Consider to pull off the road before making or answering a call.
- Never leave your headphones above any air bag deployment area inside your car as serious injury may result when an air bag deploys.
- Never allow children to play with the headphones - small parts may be of choking hazard.
- Observe all signs and displays that require an electrical device or RF radio product to be switched off in designated areas. These could include hospitals, blasting areas, and potentially explosive atmospheres.
- Turn off your headphones prior to boarding an aircraft. Do not use your headphones inside an aircraft.
- To prevent damage to your hearing, please do not set the listening volume too high.
- Do not attempt to modify the headphones.
- Never use the headphones while taking a bath.
- Do not use the headphones in a sauna or steam room.
- Do not keep the headphones near a wash basin or other wet places.
- Do not use the headphones outdoors in the rain.
- Do not use the headphones in stormy weather.
- Do not clean the headphones while they are being charged. Always disconnect the charger from the headphones before cleaning.
- Do not attempt to force open the built-in battery.
- Dispose of the battery and the headphones according to local regulations. Do not dispose of them as household waste.

10

FCC RF Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Care and Maintenance

headphones

- Turn off your headphones before placing it in your pocket or bag. If the MFB is accidentally depressed, your mobile phone may place an unintended call.
- Do not expose the headphones to liquid, moisture or humidity, or rain as it is not waterproof.
- Do not use abrasive cleaners to clean the headphones.
- Do not expose the headphones to extremely high or low temperatures.
- Do not leave the headphones in direct sunlight for an extended period of time.
- Do not leave the headphones near open flames such as cooking burners.
- Do not dispose of the headphones in a fire as it will result in explosion.
- Do not bring the headphones into contact with any sharp objects as this will cause scratches and damages.
- Do not stick anything inside the headphones as this may damage internal components.
- Do not attempt to disassemble the headphones as they do not contain serviceable components.
- If you do not plan to use the headphones for a long period, please store them in a dry place that is free from extreme temperatures and dust.

11

Care and Maintenance (cont'd)

- Only charge the headphones built-in battery in accordance with the instructions described in this user guide.
- Avoid charging the headphones in extremely high or low temperatures.
- Do not connect the headphones to the charger while on an active call.

Built-in Battery

- Do not attempt to replace the headphones' battery as it is in-built and is not changeable.
- Dispose of the battery according to local regulations. Do not dispose of the battery as household waste.
- Charge the battery in accordance with the instructions supplied with this user guide.
- Use only the charger supplied by the headphones' original manufacturer to charge the battery.

Charger

- Use only the charger supplied by the headphones' original manufacturer to charge the headphones. Other chargers may look similar but using them could be dangerous and could damage the headphones.
- Do not attempt to disassemble the charger as it may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the headphones are subsequently used.
- Do not use the charger outdoors or in damp areas.

12

Declaration of Conformity

We, i.Tech Dynamic Limited, declare that the following product:

Product Name: i.Tech BlueBAND Sport

Model No.: C51-B08003-XX

is in conformity with the following essential requirements of Council Directive 1999/5/EC (referred to as R&TTE Directive): Article 3.1.a, 3.1.b and 3.2. and the product is manufactured in accordance with Annex II of the above directive.

A copy of the Declaration of Conformity can be found at <http://www.itechdynamic.com>.

i.Tech declares under our sole responsibility that the headset is in conformity with the provisions of the following Council Directives: 1999/5/EC.

Notes on Environmental Protection

After the implementation of the European Directive 2002/96/EU in the national legal system, the following applies: Electrical and electronic devices must not be disposed of with domestic waste. Consumers are obliged by law to return electrical and electronic devices at the end of their service lives to the public collection points that are set up for this purpose or designated points of sale. However, such details are defined by the national law of the respective country. This symbol on the product, the instruction manual or the packaging indicates that the product is subject to these regulations. By recycling, reusing the materials, or other forms of utilizing old devices, you are making an important contribution in protecting our environment.

13

Federal Communications Commission (FCC) Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

15.21

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

15.105(b)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

14

www.tuv.com

©2008 Hutchison Harbour Ring Enterprises Limited

All rights in this publication are reserved and no part may be reproduced without the prior written permission of the publisher. The contents of this publication are believed to be correct at the time of going to press, but any information, specifications, products or services mentioned, and product I.D. shown may be modified, supplemented or withdrawn without further notice.

The Stylized i.Tech logos are trademarks owned by Hutchison Harbour Ring Enterprises Limited or its affiliates. All other trademarks or registered trademarks belong to their respective owners.



Dispose of the packaging and this product in accordance with the latest provisions.

<http://www.itchedynamic.com>



is a trademark of SRS Labs, Inc. WOW HD technology is incorporated under license from SRS Labs, Inc.

Printed In China

04/2008

