



# Hush

by **LOVENSE**

V 2.0

# English

## A MESSAGE FROM THE LOVENSE TEAM

Thank you for choosing LOVENSE!

Our dedicated team of software developers work hard to bring you the features you want and expect from a sex tech company... and it's mainly thanks to our customers. Our customers' feedback has allowed us to be one of the pioneers in the teledildonics industry.

Got feedback? We'd love to hear from you, too! Shoot us an e-mail at [app@lovense.com](mailto:app@lovense.com) and we'll pass on your suggestions to our software development team. Together, we can continue to improve our app and even create more innovative sex toys for years to come.

# GETTING STARTED

We strongly recommend viewing our online user guide for the most up to date set-up instructions. Please visit:


<http://www.lovense.com/guide>

If you're a cam model, in addition to viewing our regular guide, please visit this guide for using our chrome extension:


<http://www.lovense.com/cam-model/guide>

## Turn on/off:

Press down hard and hold for 3-5 seconds. It will vibrate for one second when turned on.




## Button modes:



## CHARGING

Turn off the device before charging. The cable can be plugged into any USB port or USB/AC power adapter to start charging. It will take approximately 1.5 hours to fully charge.

The indicator light will stay on while charging. Once it is fully charged the solid red light will turn off. If you're unsure whether it's fully charged, you can view the battery indicator in the app.



## CLEANING & CARE

- Clean your device before and after each use.
- Clean with warm water and a mild soap (or a sex toy cleaner).
- Dry thoroughly before storing.
- Keep away from extreme heat or cold.

## LUBRICANT

To avoid issues, **only use water-based lube**. DO NOT use silicone or oil-based lubricants.


Before insertion, generously apply lube to the product and yourself. Water based lube may dry out, so you may need to reapply.

We recommend using JO Anal H2O Lubricant for the best experience.

## USAGE TIP

To get the best connection range possible, the curved end of the base should be facing your back.

Additionally, the phone should be pointed in the general direction of the plug.




## Warning:


- If you are new to anal play, please research best practices to avoid any issues. Users of the Hush Plug use at their own risk; neither the manufacturer nor the retailer assumes responsibility or liability for this product.
- If you feel pain while inserting or during use, immediately stop using it.

# HOW TO CONNECT


- 1 Download our “Lovense Wearables” app:



- 2 Turn on Hush




- 3 Pair with your device





(Press down hard and hold for 3-5 seconds.)

## PAIRING WITH YOUR DEVICE

1. Press and hold Hush's button to turn on the toy. A light will flash to indicate it's on.
2. Click the  icon or go to "Account" → "My Toy".
3. Tap "+" to begin searching. After toy is found, tap "Done". The light will stay on to indicate it's connected. Your toy can now be controlled with your smartphone.

### Note:

- You only have to pair your toy once. Next time it should automatically connect with your smartphone.
- This icon  shows the signal of the connection. It will switch to this one  if it disconnects. If paired, it will automatically reconnect.





## CONNECTING WITH A PARTNER


1. Go to the “Long Distance” tab.
2. Tap “+” to add a contact. Enter their email and tap “Add”.
3. After your partner accepts the request, they will show up in this tab.

### Note:

- When messaging, press the  button to view control options.



- You have the ability to adjust settings for each partner. Click the  icon to adjust your preferences.



## TROUBLESHOOTING

For additional assistance, use the contact form at [lovense.com/contact](https://lovense.com/contact). Someone from the Lovense team will normally reply within 12-24 hours.

## SPECIFICATIONS

<b>Materials</b>	Body Safe Silicone
<b>Size</b>	Medium: 121 mm x 80 mm x 44.5 mm Small: 121 mm x 80 mm x 38 mm
<b>Weight</b>	Medium: 124 grams Small: 96 grams
<b>Charging</b>	Around 1.5 hours
<b>Use Time</b>	Up to 85 continuous minutes on the highest level. During normal use, it should last between 1.5 - 2 hours.
<b>Standby</b>	Up to 120 Hours

## WARRANTY TERMS AND CONDITIONS

LOVENSE warrants this product for a period of ONE (1) YEAR, after the date of original purchase, against defects due to faulty workmanship or materials. If you discover a defect and notify LOVENSE during the warranty period, LOVENSE will, at its discretion, replace the product free of charge.

The warranty covers working parts that affect the function of the product. It does NOT cover cosmetic deterioration caused by fair wear and tear or damage caused by accident, misuse or neglect. Any attempt to open or take apart the product (or its accessories) will void the warranty.

Claims under warranty must be supported by reasonable evidence that the date of the claim is within the warranty period. To validate your warranty, please contact us using the form at [lovense.com/contact](https://lovense.com/contact). Provide your order ID# (or receipt from an authorized reseller) with your email.

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.