



EC	REP
-----------	------------

Regulatory Affairs Representative
Welch Allyn Limited
Navan Business Park
Dublin Road
Navan, County Meath,
Republic of Ireland



Welch Allyn, Inc.
4341 State Street Road
Skaneateles Falls, NY
13153 USA
www.welchallyn.com

901047 CARDIOPULMONARY ECG SYSTEM

CE₀₂₉₇



US Federal law restricts this device to sale by or on the order of a physician.

Copyright

© Copyright 2019, Welch Allyn. All rights are reserved. To support the intended use of the product described in this publication, the purchaser of the product is permitted to copy this publication, for internal distribution only, from the media provided by Welch Allyn. No other use, reproduction, or distribution of this publication, or any part of it, is permitted without written permission from Welch Allyn. Welch Allyn assumes no responsibility for any injury to anyone, or for any illegal or improper use of the product, that may result from failure to use this product in accordance with the instructions, cautions, warnings, or statement of intended use published in this manual. Unauthorized copying of this publication may not only infringe copyright but also reduce the ability of Welch Allyn to provide accurate and up-to-date information to users and operators alike.

Welch Allyn®, CardioPerfect® Workstation and SpiroPerfect® are registered trademarks of Welch Allyn.

Software in this product is Copyright 2019, Welch Allyn. All rights are reserved. The software is protected by United States of America copyright laws and international treaty provisions applicable worldwide. Under such laws, the licensee is entitled to use the copy of the software provided on the original distribution medium. The software may not be copied, decompiled, reverse-engineered, disassembled or otherwise reduced to human-perceivable form. This is not a sale of the software or any copy of the software; all right, title and ownership of the software remains with Welch Allyn.

The information contained in this manual is subject to change without notice. All changes will be in compliance with regulations governing manufacture of medical equipment.

User responsibility

This product is designed to perform in conformity with the description thereof contained in this manual and accompanying labels and inserts, when assembled, operated, maintained and repaired in accordance with the instructions provided. A defective product should not be used. Parts that are broken, plainly worn, missing or incomplete, distorted or contaminated should be replaced immediately. Should any repair or replacement become necessary, we recommend that service be performed at the nearest approved service center. The user of the product shall have the sole responsibility for any malfunction, which results from improper use, faulty maintenance, improper repair, damage or alteration by anyone other than Welch Allyn or their authorized service personnel.

Accessories

The Welch Allyn warranty can only be honored if you use Welch Allyn approved accessories and replacement parts.

**Caution**

Use of accessories other than those recommended by Welch Allyn may compromise product performance.

Warranty, Service, and Spare Parts**Warranty**

All repairs on products under warranty must be performed or approved by Welch Allyn. Unauthorized repairs will void the warranty. In addition, whether or not covered under warranty, any product repair shall exclusively be performed by Welch Allyn certified service personnel.

Assistance and Parts

If the product fails to function properly or if assistance, service, or spare parts are required, contact the nearest Welch Allyn Technical Support Center.

Before contacting Welch Allyn it is helpful to attempt to duplicate the problem and to check all accessories to ensure that they are not the cause of the problem.

When calling, please be prepared to provide:

- Product name and model number and complete description of the problem
- The serial number of your product (if applicable)
- The complete name, address and phone number of your facility
- For out-of-warranty repairs or spare parts orders, a purchase order (or credit card) number
- For parts order, the required spare or replacement part number(s)

Repairs

If your product requires warranty, extended warranty, or non-warranty repair service, please call first the nearest Welch Allyn Technical Support Center. A representative will assist you troubleshooting the problem and will make every effort to solve it over the phone, avoiding potential unnecessary return.

In case the return cannot be avoided, the representative will record all necessary information and will provide a Return Material Authorization (RMA) number, as well as the appropriate return address. A Return Material Authorization (RMA) number must be obtained prior to any return.

Note

Welch Allyn does not accept returned products without an RMA.

Packing Instructions

If you have to return goods for service, follow these recommended packing instructions:

- Remove all hoses, cables, sensors, power cords, and ancillary products (as appropriate) before packing, unless you suspect they are associated with the problem.
- Wherever possible use the original shipping carton and packing materials.
- Include a packing list and the Welch Allyn Return Material Authorization (RMA) number.

It is recommended that all returned goods be insured. Claims for loss or damage to the product must be initiated by the sender.

Limited Warranty Statement

Welch Allyn, Inc. warrants that the Welch Allyn CardioPerfect Workstation computer-based product you have purchased meets the labeled specifications of the Product and will be free from defects in materials and workmanship that occur within 1 year after the date of purchase. Accessories used with the Product are warranted for 90 days after the date of purchase.

The date of purchase is: 1) the date specified in our records, if you purchased the Product directly from us, 2) the date specified in the warranty registration card that we ask you to send to us, or 3) if you don't return the warranty registration card, 120 days after the date on which the Product was sold to the dealer from whom you bought the Product, as documented in our records.

This warranty does not cover damage caused by: 1) handling during shipping, 2) use or maintenance contrary to labeled instructions, 3) alteration or repair by anyone not authorized by Welch Allyn, and 4) accidents.

You assume all responsibility for use of the Product with any hardware or software that does not meet the system requirements described in the Product documentation.

If a Product or accessory covered by this warranty is determined to be defective because of defective materials, components, or workmanship, and the warranty claim is made within the warranty period described above, Welch Allyn will, at its discretion, repair or replace the defective Product or accessory free of charge.

You must obtain a return authorization from Welch Allyn to return your Product before you send it to Welch Allyn's designated service center for repair.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. WELCH ALLYN'S OBLIGATION UNDER THIS WARRANTY IS LIMITED TO REPAIR OR REPLACEMENT OF PRODUCTS CONTAINING A DEFECT. WELCH ALLYN IS NOT RESPONSIBLE FOR ANY INDIRECT OR CONSEQUENTIAL DAMAGES RESULTING FROM A PRODUCT DEFECT COVERED BY THE WARRANTY.

**WARNING**

Power strips (multiple portable socket outlets) are not allowed for use in connecting the medical electrical equipment or any accessories to ground unless used in concert with a medical approved isolation transformer.

During defibrillation, the ECG signals displayed may show waveform artifacts and cannot be relied on as a true indication of the patient's physical condition.

Accessible metal parts, such as electrode terminations, should not come in contact with other electrically conductive parts, including earth ground.

Welch Allyn provides a number of high quality patient leads in varying termination styles. Use of these approved patient leads is required for electrical protection of the patient during cardiac defibrillation.

CardioPerfect devices are not intended for direct cardiac application.

An inoperable or damaged electrocardiograph can be identified by abnormal signals on the ECG waveforms. Abnormal signals are characterized by flat lines, excess noise, square waves or other non typical anomalies that appear on the ECG waveform. The electrocardiograph can be periodically tested by connecting the CardioPerfect to an ECG simulator. Follow manufacturer's instructions.

If there is a requirement for equipment to be connected to a personal computer or other non-medical rated equipment, it is the responsibility of the user to ensure that the electric power circuit to which the CardioPerfect system is connected includes an additional protective earth ground or an isolation transformer in order to satisfy the IEC 60601-1 safety standard.

Other medical equipment—including but not limited to defibrillators, ultrasound machines, pacemakers, and other stimulators—may be used simultaneously with the electrocardiograph. However, such devices may disturb the electrocardiograph signal.

The electrocardiograph has not been designed for use with high frequency (HF) surgical equipment and does not protect against hazards to the patient.

Fire and explosion hazard. Do not operate the electrocardiograph in the presence of a flammable anesthetic mixture with air, oxygen, or nitrous oxide; in oxygen-enriched environments; or in any other potentially explosive environment.

To prevent the spread of infection, take these precautions:

- Dispose of single-use components (for example, electrodes) after using them once.
- Regularly clean all components that come in contact with patients.
- Consult your facility's equipment cleaning procedures when

performing ECG testing on patients with open, infectious sores.

Ensure the location of the electrode and associated cables provides maximum separation away from all sources of high-frequency energy. The best way to ensure patient safety is to completely remove all electrodes and cables from the patient when exposed to high-frequency energy.

No modification of this equipment is allowed.

Table of Contents

1. GETTING STARTED	10
1.1. The Welch Allyn CardioPerfect resting ECG window	10
2. RECORDING ECGS	12
2.1. Record an ECG	12
2.2. Place electrodes on the patient	12
2.3. Create a new ECG	14
2.4. Select how you want to view leads	15
2.5. Set a rhythm strip	15
2.6. Turn pacemaker on and off	15
2.7. Apply an AC filter	15
2.8. Apply a muscle noise filter	16
2.9. Record an ECG	16
2.10. Recording rhythm ECGs	16
2.11. Cancel a recording	17
2.12. Pacemaker pulse detection	17
2.13. Signal quality indication	18
3. RECORDING ECGS FOR PEDIATRIC PATIENTS	19
4. VIEWING ECGS	21
4.1. View and edit ECG information	21
4.2. Views	22
4.3. Parameters	25
4.4. QTc	25
4.5. QT dispersion (optional)	26
4.6. Working with views	27
4.7. Zoom in and out on an ECG	27
4.8. Set chart speed and sensitivity	28
4.9. View one single complex or loop	28
4.10. Turn pacemaker on and off	28
4.11. Apply muscle noise filter	28
4.12. Apply AC filter	29
4.13. Apply baseline filter	29
4.14. Apply anti-aliasing	29
4.15. Make measurements	30
4.16. Compare ECGs	30
4.17. Display markers	31
5. INTERPRETING ECGS	32
5.1. About MEANS and PEDMEANS interpretation software	32
5.2. Edit and confirm an interpretation	33
5.3. View interpretation history	34
5.4. Reanalyze an ECG	34
6. PRINTING ECGS	35
6.1. Print an ECG	35

- 6.2. Automatically print an ECG35
- 7. MAINTAINING THE RECORDER 36**
 - 7.1. Clean the AM12 ECG Recorder36
 - 7.2. Cleaning the Patient cables and PC interface cables36
- 8. ACQUISITION MODULE 37**
 - 8.1. Lead Fail.....39
 - 8.2. ECG Collection Using the Acquisition Module.....39
 - 8.3. Connecting the Acquisition Module39
 - 8.4. Accessories39
- 9. CUSTOMIZING THE RESTING ECG SOFTWARE 40**
 - 9.1. General tab40
 - 9.2. Viewing tab41
 - 9.3. Printing tab41
 - 9.4. QT dispersion tab42
 - 9.5. Recorder Tab.....43
 - 9.6. Customize ecg.txt43
- 10. TROUBLESHOOTING 44**
- 11. FUNCTION KEYS 45**
- 12. BEFORE INSTALLING THE RESTING ECG SOFTWARE..... 46**
 - 12.1. Structure46
- 13. INSTALLING THE RESTING ECG MODULE..... 47**
 - 13.1. Connecting the AM1247
- 14. SAFETY AND PRECAUTIONS 48**
- 15. ELECTROMAGNETIC COMPATIBILITY (EMC) 51**

Welcome

Welcome to Welch Allyn CardioPerfect Resting ECG, a module of Welch Allyn CardioPerfect Workstation.

With the Welch Allyn CardioPerfect Resting ECG Module, you can record, view and interpret resting ECGs. You can also use it to print ECGs in various formats.

This manual contains specific information about the Resting ECG Module of Welch Allyn CardioPerfect Workstation. For all general information about the workstation software please refer to the Workstation manual, this includes:

- Creating and editing Patient cards
- General information about printing

For information about the ECG hardware and accessories please refer to the Pro Manual. For further information on installation and configuration please refer to the Installation manual. Detailed information on servicing is described in the Service and Advanced Installation manual.

Intended use

Using the optional ECG module and associated accessories, the user can acquire, view, store, and print ECG waveforms. The ECG module also provides optional algorithms (MEANS) to generate measurements, data presentations, graphical presentations, and interpretive statements on an advisory basis. These are presented for review and interpretation by the clinician.

Indications

Indications for electrocardiography range from routine screening of cardiac health in the physician office environment to directed diagnostic differentiation in a hospital cardiology department.

Contraindications

There are no known contraindications for the recording of a resting ECG.




Caution

A computer generated interpretation cannot replace sound medical reasoning by a trained professional. Therefore, a physician should always review the interpretation.

1. Getting started

1.1. The Welch Allyn CardioPerfect resting ECG window

This section will guide you around the various parts of Welch Allyn CardioPerfect Resting ECG module.



Title bar	The title bar displays the name of the program. The title bar contains three buttons that you can use to maximize, minimize and close the Workstation window.
Menu bar	Each menu in the menu bar contains a number of tasks that you can perform with Welch Allyn CardioPerfect. Sometimes, menus are gray. This means that you cannot access that functionality at that particular point, either because it is not available, or because you are not authorized to use it. Each module has its own menu bar.
Tool bar	The tool bar contains buttons that give you easy access to the most common tasks in Welch Allyn CardioPerfect.
Search area	The search area contains search and display functionality that lets you easily retrieve patients and tests. In the search area, you can find a patient, see which tests were recorded for that patient and see the kind of tests that were recorded. You can also create search patterns, an easy way of finding information that you need frequently.
Workspace	The workspace is the core part of Welch Allyn CardioPerfect. It displays the ECG in various formats. These formats, also called views, are each displayed on a separate tab. The workspace is the place where you view, compare and measure ECGs.
Parameters area	The parameters area contains some details of the ECG, such as the age and the heart rate of the patient, and the global measurements for the ECG (P duration, QRS duration, PQ duration, QT duration, corrected QT duration, P-axis, QRS-axis, T-axis and QTd or JTd duration).
Interpretation area	The Interpretation area contains the interpretation (either entered by the physician or generated by MEANS software). It displays the interpretation text and whether the interpretation has been confirmed.
Shortcut menu	In the workspace, you can use shortcut menus to access the most common tasks. You can access these by clicking on the workspace with your right mouse button.
Status bar	The status bar displays the name of the user that is currently logged on to Welch Allyn CardioPerfect.

2. Recording ECGs

2.1. Record an ECG

Welch Allyn CardioPerfect records ECGs quickly, easily and reliably. All you have to do is make sure the electrodes are placed correctly and switch on the AM12. Welch Allyn CardioPerfect takes care of recording, making a number of measurements and calculations, saving the recording, and providing a first interpretation.

To record an ECG, you need to follow these global steps. Each step is explained in more detail on the following pages.

1. Place electrodes on the patient.
2. Select or create a patient.
3. Create a new ECG. The Real-time monitor is displayed.
4. The Recorder will be switched on automatically. The Real-time monitor displays the ECG traces.
5. Select how you want to see leads and set a rhythm strip.
6. If necessary, apply an AC filter to remove possible noise that is due to AC mains interference.
7. In the Real-time monitor, wait until the signal is stabilized and click the Record button to start recording. The progress of the recording is shown in the gauge at the bottom of the window.
8. The Recorder will be switched off automatically. Welch Allyn CardioPerfect automatically saves the ECG and calculates the averaged complexes.
9. Disconnect the patient. The recorded ECG is automatically displayed.

2.2. Place electrodes on the patient

Important: Because Welch Allyn CardioPerfect is a 12 lead electrocardiograph all electrodes must be connected! Proper skin preparation (abrasion if necessary) and proper electrodes are very important for a good signal quality.



Important: When you connect the electrodes to the patient, make sure that the electrodes and their connectors (also the RL/N electrode) do not contact other conducting parts (including earth).

Extremity electrodes

The electrodes may be placed on any part of the arms or the legs as long as they are below the shoulders in the former and below the inguinal fold anteriorly and the gluteal fold posteriorly in the latter. Any other placement necessary by deformed or missing extremities must be noted on the record.

Precordial electrodes

Connect the precordial electrodes in the following positions:

AHA		IEC	
			
V1	Fourth intercostal space at the right border of the sternum.	C1	
V2	Fourth intercostal space at the left border of the sternum.	C2	
V3	Midway between locations V2 and V4.	C3	
V4	At the mid-clavicular line in the fifth intercostal space.	C4	
V5	At the anterior axillary line on the same horizontal level as V4.	C5	
V6	At the midaxillary line on the same horizontal level as V4 and V5.	C6	
RA	Right arm	R	
LA	Left arm	L	
RL	Right leg	N	
LL	Left leg	F	

Reusable Electrodes

Each electrode must be attached securely. The electrode paste, gel, or cream must cover an area the size of the electrode, but must not extend beyond it, especially on the chest.

Disposable Tab Electrodes

Disposable electrodes have conductive material on the adhesive side only. The electrode tab must be placed between (clip) or on (banana or pushbutton) the electrode adapter, and it must remain flat. Do not attempt to place the electrode adapter so close to the circular part of the electrode that the tab of the electrode is bent, or contact is made with the conductive gel. Gently tug on the electrode adapter to ensure that the electrode adapter is properly placed on the electrode. Good and accurate placement of each electrode on the first attempt is important. Each time an electrode is lifted off the skin and reattached, the adhesive gel becomes less effective.




Never mix reusable and disposable electrodes on the same patient.

2.3. Create a new ECG

To create a new test:

1. Select the patient. See the CPWS Workstation manual for details.
2. In the **File** menu, point to **New** and click **ECG**. The **New ECG** dialog box is displayed.



3. In the **New ECG** dialog box, select the Name and the **Specialty** of the **Referring physician** and/or the name of the **Ordering physician**, and select the lead set that you want to use for the ECG.
4. Click the **OK** button. The **Real-time monitor** is displayed. Here you can adjust your view settings and start recording the test.



5. The **Real-time monitor** displays the ECG traces.

2.4. Select how you want to view leads

Once you have created a new ECG, the Real-time monitor displays the ECG traces. Before you start the actual recording, you can select how you want to view the traces. Welch Allyn CardioPerfect offers three different views: 1x12, 2x6 and 4x3. In addition, you can set different chart speeds and different sensitivities.

To select a different view:

- In the **Real-time monitor**, select a view from the list. The new view is immediately displayed.

To select a different chart speed or sensitivity for the view:

- In the **Real-time monitor**, select a chart speed or sensitivity from the list. The speed and sensitivity are immediately displayed.

2.5. Set a rhythm strip

As a default, Welch Allyn CardioPerfect uses lead II as a rhythm strip, but you can set any lead as a rhythm strip.

To set another lead as a rhythm strip:

- In the Rhythm strip pane, select a lead from the list. The new lead is immediately used as a rhythm strip.

To set the speed and the sensitivity of the rhythm strip:

- In the Rhythm strip pane, select a speed and sensitivity. The new speed and sensitivity are immediately used.

2.6. Turn pacemaker on and off

ECG traces can contain artificial pacemaker signal indicators. You can remove this artificial pacer indicator by disabling the "Show Pacer" selection. To learn how, see Customizing the Resting ECG software on 40.

2.7. Apply an AC filter

ECG traces can contain noise that is due to AC mains interference. This makes the traces harder to read. You can filter out noise by applying an AC filter. When you apply a filter, the original ECG signal is not permanently changed. You only change the way it is displayed on the monitor. You can always restore the original signal.

To apply an AC filter:

- At the top of the Real-time monitor, click **AC filter**. Click again to switch the filter off.

2.8. Apply a muscle noise filter

Muscle noise in an ECG signal hides low amplitude signals that may be important for the interpretation of an ECG. You can remove this noise with a muscle noise filter.

To apply a muscle noise filter:

- At the top of the Real-time monitor, click **Muscle filter**. Click again to switch the filter off.

2.9. Record an ECG

You are now ready to record the ECG.

To record an ECG:

1. In the **Real-time monitor** wait until the signal is stabilized and click the **Record** button to start recording. The progress of the recording is shown in the gauge at the bottom of the window.
2. Next see §2.1 and follow steps 8-9.

Create a pretriggered recording

When you want to catch a particular event, such as arrhythmia, without having to record an entire ECG, you can use a pretriggered recording. When you start a pretriggered recording, it includes the five seconds before and after you clicked on the Record button. This means that when you see an event and click the Record button, your recording includes the event, five seconds before the event, and five seconds after the event.

The pretriggered option is also convenient when you have difficulties recording an ECG with clean traces, for example because the patient has muscle spasms. The pretrigger option helps define the 10 seconds of recording by already saving 5 seconds of possibly clean traces.

To create a pretriggered recording:

1. Create a new test. The Real-time monitor is displayed.
2. In the **Real-time monitor**, click the **Pretrigger** option.
3. Wait until you see the event that you want to record.
4. As soon as you see the event, click the **Record** button. Welch Allyn CardioPerfect will continue recording for five more seconds.
5. Next see §2.1 and follow steps 8-9.
6. The recorded ECG is automatically displayed, including the event that you wanted to capture.

2.10. Recording rhythm ECGs

The procedures for recording a rhythm ECG are almost identical to those for recording a regular ECG. If you need any detailed help with the steps that follow, please refer to section 2.1.

To record a rhythm ECG:

1. In the **Real-time monitor** wait until the signal is stabilized and click the **Rhythm** button to start recording. The progress of the recording is shown in the gauge at the bottom of the window.
2. Next see §2.1 and follow steps 8-9.

Capture an event

When you notice an event, like arrhythmia, during recording, you can capture this in the ECG. When you do this, a small exclamation mark is inserted at the place where the event occurred.

- To capture an event, click the **Event** button.

2.11. Cancel a recording

You can cancel a recording at any time in the recording process.

To cancel a recording:

- Click the **Cancel** button in the **Real-time monitor**. The recording is cancelled r. The test is not saved.


Tips for canceling a recording:

- When you have not yet recorded 10 seconds of regular ECG, you can also cancel the recording by clicking the **Record** button.
- You can choose to record a regular ECG or a rhythm ECG without leaving the real-time monitor.

2.12. Pacemaker pulse detection

The Welch Allyn CardioPerfect software is able to display pacemaker pulse spikes detected by the hardware. These spikes are marked with a symbol in the Real time monitor, in Review mode and on printouts.

When the Pacemaker pulse detection is on, the detected spikes are marked on the trace, as shown here. To learn how to disable this function to remove artificial pacemaker signal indicators, see Customizing the Resting ECG software on 40.



Pacemaker markers

2.13. Signal quality indication

If Welch Allyn CardioPerfect Workstation finds the signal from one of the channels to be erroneous, for example caused by a disconnected electrode, the monitor will display “Bad signal on...”. The trace shows square waves, see example below.



Please check the indicated electrodes/channels immediately!

The status information is saved with the test. Erroneous leads will show square waves on both the Review and the printout. Depending on the duration of the erroneous signal no interpretation or measurement will be possible and therefore will not be shown.

In the few moments between the lead disconnection and when the software detects the disconnection, pacemaker spikes may be erroneously detected. As a result, a group of pacemaker markers may be shown on the trace just before the square waves are shown. The pacemaker pulse detection will be suppressed as soon as the square waves are shown and will continue to be suppressed until the erroneous signal is corrected.

Leadoff, Framing Errors and DCOffset conditions:

If the application detects a Lead-off or other error within 10 seconds after you have started an ECG recording, the recording automatically restarts. In the case of a Leadoff condition, the ECG recording will not start until the signal is stabilized. The progress bar of the recording will remain at 0 until all the signals are of acceptable quality.

You can use the override button to disable the automatic restart.

Leadoff The Leadoff message displays in the workspace when an electrode is disconnected. The real-time monitor will display “Bad signal on...”. The trace shows square waves until the signal is stabilized.

3. Recording ECGs for pediatric patients

Pediatric Electrode Placement

CardioPerfect supports two lead sets for the recording and interpretation of pediatric electrocardiograms. Where anatomically feasible, the standard electrode placement described on page 12 may be used. For very small children, an alternative arrangement is described below, in which leads V3R and V7 replace V3 and V5.

Extremity electrodes

The electrodes may be placed on any part of the arms or the legs as long as they are below the shoulders in the former and below the inguinal fold anteriorly and the gluteal fold posteriorly in the latter. Any other placement necessary by deformed or missing extremities must be noted on the record.

Pediatric Precordial electrodes

Place the electrodes on the anatomical positions V3R, V1, V2, V4, V6 and V7, then attach precordial lead wires 1 through 6 from left to right.


Connect the precordial electrodes in the following positions:

AHA		IEC
V1	Fourth intercostal space at the right border of the sternum (V3R).	C1
V2	Fourth intercostal space, at the right sternal margin (V1).	C2
V3	Fourth intercostal space, at the left sternal margin (V2).	C3
V4	Fifth intercostal space, on the left mid-clavicular line (V4).	C4
V5	Left midaxillary line, at the horizontal level of V4 (V6).	C5
V6	Left posterior axillary line, at the horizontal level of V4 (V7).	C6
RA	Right arm	R
LA	Left arm	L
RL	Right leg	N
LL	Left leg	F

To select the pediatric lead set:

1. Place electrodes on the patient.
2. In Welch Allyn CardioPerfect, select or create a patient.

3. In the **File** menu, point to **New** and click **ECG**. The **New ECG** dialog box is displayed.




4. From the **Lead set** list, select **Pediatric** and click **OK**.
5. Follow the steps on page 14 to finish recording the ECG.


4. Viewing ECGs

To view an ECG:

1. Select a patient. The tests that have been recorded for that patient are listed in the test list



2. From the test list, click the ECG that you want to see. ECGs are indicated with a sign. Welch Allyn CardioPerfect is started automatically, and the test is displayed in the workspace.



4.1. View and edit ECG information

The Information window gives you all kinds of information about the ECG that you are currently viewing. You can see the name of the referring physician, the name of the technician that recorded the ECG and any comments that were entered. If you wish, you can add some comments.

To view ECG information:

- In the **Tools** menu, click **Information**. The **Information** window is displayed.




To add your comments:




1. Type your comments in the Information window.
2. Click **OK** to save your comments.

4.2. Views


Welch Allyn CardioPerfect offers various views on an ECG. Each view highlights a different aspect of the ECG. Each view is presented on a different tab in the workspace and has different functionality.

You can view at all twelve leads in two different formats (the traditional 4x3 format, and a convenient 2x6 format). You can also view the measurements that Welch Allyn CardioPerfect calculated, or display one single average complex. If you recorded a rhythm ECG, you can examine the entire recording.

	<p>4x3 view The 4x3 view displays a 12 lead-ECG strip of 2.5 seconds long. The leads are shown in a 4x3 configuration with a rhythm strip at the bottom of the view. View can be simultaneous or sequential.</p>
	<p>2x6 view The 2x6 view displays a 12 lead-ECG strip of 5 seconds long. The leads are shown in a 2x6 configuration. On the left, leads I through aVF are displayed; on the right, leads V1 till V6 are displayed. View can be simultaneous or sequential.</p>
	<p>Averages view The Averages view displays the averages of the dominant complexes for all 12 leads. You can also view a single average complex, display markers and compare complexes of other ECGs.</p>

 <table border="1"> <thead> <tr> <th>ECG</th> <th>246</th> <th>Averages</th> <th>Measurements</th> <th>Rhythm</th> <th>Old Rhythm Strip</th> <th>Vector</th> <th>P/R</th> </tr> </thead> <tbody> <tr> <td>Type</td> <td>1</td> <td>I</td> <td>II</td> <td>aVR</td> <td>aVL</td> <td>aVF</td> <td>V1</td> <td>V2</td> <td>V3</td> <td>V4</td> <td>V5</td> <td>V6</td> </tr> <tr> <td>QRS</td> <td>11</td> <td>49</td> <td>49</td> <td>49</td> <td>49</td> <td>49</td> <td>155</td> <td>155</td> <td>155</td> <td>49</td> <td>49</td> <td>49</td> </tr> <tr> <td>P</td> <td>98</td> <td>68</td> <td>35</td> <td>0</td> <td>44</td> <td>40</td> <td>81</td> <td>83</td> <td>14</td> <td>60</td> <td>41</td> <td>31</td> </tr> <tr> <td>Q</td> <td>0</td> <td>0</td> <td>26</td> <td>25</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>R</td> <td>0</td> <td>164</td> <td>273</td> <td>0</td> <td>0</td> <td>206</td> <td>0</td> <td>0</td> <td>0</td> <td>30</td> <td>179</td> <td>188</td> </tr> <tr> <td>S</td> <td>205</td> <td>269</td> <td>230</td> <td>46</td> <td>231</td> <td>2274</td> <td>505</td> <td>570</td> <td>1409</td> <td>2474</td> <td>2163</td> <td>1728</td> </tr> <tr> <td>ST</td> <td>493</td> <td>87</td> <td>0</td> <td>584</td> <td>1303</td> <td>0</td> <td>1307</td> <td>1990</td> <td>366</td> <td>202</td> <td>0</td> <td>0</td> </tr> <tr> <td>T</td> <td>0</td> <td>0</td> <td>0</td> <td>143</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>QT</td> <td>0</td> <td>0</td> <td>0</td> <td>143</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>QTc</td> <td>0</td> <td>0</td> <td>0</td> <td>143</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>STc</td> <td>302</td> <td>15</td> <td>47</td> <td>4</td> <td>40</td> <td>31</td> <td>57</td> <td>112</td> <td>32</td> <td>9</td> <td>21</td> <td>30</td> </tr> <tr> <td>STc1</td> <td>5</td> <td>18</td> <td>21</td> <td>12</td> <td>2</td> <td>36</td> <td>22</td> <td>45</td> <td>23</td> <td>4</td> <td>4</td> <td>5</td> </tr> <tr> <td>STc2</td> <td>29</td> <td>15</td> <td>47</td> <td>4</td> <td>40</td> <td>31</td> <td>57</td> <td>112</td> <td>32</td> <td>9</td> <td>21</td> <td>30</td> </tr> <tr> <td>STc3</td> <td>75</td> <td>44</td> <td>44</td> <td>53</td> <td>60</td> <td>4</td> <td>139</td> <td>260</td> <td>140</td> <td>60</td> <td>6</td> <td>15</td> </tr> <tr> <td>STc4</td> <td>59</td> <td>8</td> <td>51</td> <td>33</td> <td>95</td> <td>21</td> <td>112</td> <td>211</td> <td>58</td> <td>27</td> <td>12</td> <td>26</td> </tr> <tr> <td>STc5</td> <td>37</td> <td>95</td> <td>42</td> <td>25</td> <td>70</td> <td>7</td> <td>152</td> <td>304</td> <td>170</td> <td>87</td> <td>17</td> <td>7</td> </tr> <tr> <td>T</td> <td>299</td> <td>299</td> <td>44</td> <td>0</td> <td>200</td> <td>205</td> <td>288</td> <td>907</td> <td>616</td> <td>501</td> <td>202</td> <td>202</td> </tr> <tr> <td>Tc</td> <td>0</td> <td>0</td> <td>0</td> <td>398</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>Tc1</td> <td>5</td> <td>4</td> <td>2</td> <td>10</td> <td>4</td> <td>2</td> <td>14</td> <td>8</td> <td>14</td> <td>8</td> <td>5</td> <td>6</td> </tr> <tr> <td>Tc2</td> <td>10</td> <td>10</td> <td>4</td> <td>10</td> <td>16</td> <td>12</td> <td>2</td> <td>2</td> <td>10</td> <td>12</td> <td>16</td> <td>16</td> </tr> <tr> <td>Tc3</td> <td>0</td> <td>24</td> <td>30</td> <td>0</td> <td>0</td> <td>26</td> <td>0</td> <td>0</td> <td>0</td> <td>22</td> <td>26</td> <td>28</td> </tr> <tr> <td>Tc4</td> <td>20</td> <td>46</td> <td>48</td> <td>66</td> <td>20</td> <td>46</td> <td>26</td> <td>22</td> <td>34</td> <td>42</td> <td>44</td> <td>46</td> </tr> <tr> <td>Tc5</td> <td>48</td> <td>16</td> <td>0</td> <td>48</td> <td>52</td> <td>0</td> <td>50</td> <td>98</td> <td>40</td> <td>26</td> <td>0</td> <td>0</td> </tr> <tr> <td>Tc6</td> <td>0</td> <td>0</td> <td>0</td> <td>24</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>Tc7</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> </tbody> </table>	ECG	246	Averages	Measurements	Rhythm	Old Rhythm Strip	Vector	P/R	Type	1	I	II	aVR	aVL	aVF	V1	V2	V3	V4	V5	V6	QRS	11	49	49	49	49	49	155	155	155	49	49	49	P	98	68	35	0	44	40	81	83	14	60	41	31	Q	0	0	26	25	0	0	0	0	0	0	0	0	R	0	164	273	0	0	206	0	0	0	30	179	188	S	205	269	230	46	231	2274	505	570	1409	2474	2163	1728	ST	493	87	0	584	1303	0	1307	1990	366	202	0	0	T	0	0	0	143	0	0	0	0	0	0	0	0	QT	0	0	0	143	0	0	0	0	0	0	0	0	QTc	0	0	0	143	0	0	0	0	0	0	0	0	STc	302	15	47	4	40	31	57	112	32	9	21	30	STc1	5	18	21	12	2	36	22	45	23	4	4	5	STc2	29	15	47	4	40	31	57	112	32	9	21	30	STc3	75	44	44	53	60	4	139	260	140	60	6	15	STc4	59	8	51	33	95	21	112	211	58	27	12	26	STc5	37	95	42	25	70	7	152	304	170	87	17	7	T	299	299	44	0	200	205	288	907	616	501	202	202	Tc	0	0	0	398	0	0	0	0	0	0	0	0	Tc1	5	4	2	10	4	2	14	8	14	8	5	6	Tc2	10	10	4	10	16	12	2	2	10	12	16	16	Tc3	0	24	30	0	0	26	0	0	0	22	26	28	Tc4	20	46	48	66	20	46	26	22	34	42	44	46	Tc5	48	16	0	48	52	0	50	98	40	26	0	0	Tc6	0	0	0	24	0	0	0	0	0	0	0	0	Tc7	0	0	0	0	0	0	0	0	0	0	0	0	<p>Measurements view</p> <p>The Measurements view displays the measurements that were taken by the computer. These measurements include the values for several common parameters, such as Q, R and S amplitude and ST values. The amplitudes are expressed in microvolts. The durations are expressed in milliseconds. The measurements cannot be edited.</p>
ECG	246	Averages	Measurements	Rhythm	Old Rhythm Strip	Vector	P/R																																																																																																																																																																																																																																																																																																																																							
Type	1	I	II	aVR	aVL	aVF	V1	V2	V3	V4	V5	V6																																																																																																																																																																																																																																																																																																																																		
QRS	11	49	49	49	49	49	155	155	155	49	49	49																																																																																																																																																																																																																																																																																																																																		
P	98	68	35	0	44	40	81	83	14	60	41	31																																																																																																																																																																																																																																																																																																																																		
Q	0	0	26	25	0	0	0	0	0	0	0	0																																																																																																																																																																																																																																																																																																																																		
R	0	164	273	0	0	206	0	0	0	30	179	188																																																																																																																																																																																																																																																																																																																																		
S	205	269	230	46	231	2274	505	570	1409	2474	2163	1728																																																																																																																																																																																																																																																																																																																																		
ST	493	87	0	584	1303	0	1307	1990	366	202	0	0																																																																																																																																																																																																																																																																																																																																		
T	0	0	0	143	0	0	0	0	0	0	0	0																																																																																																																																																																																																																																																																																																																																		
QT	0	0	0	143	0	0	0	0	0	0	0	0																																																																																																																																																																																																																																																																																																																																		
QTc	0	0	0	143	0	0	0	0	0	0	0	0																																																																																																																																																																																																																																																																																																																																		
STc	302	15	47	4	40	31	57	112	32	9	21	30																																																																																																																																																																																																																																																																																																																																		
STc1	5	18	21	12	2	36	22	45	23	4	4	5																																																																																																																																																																																																																																																																																																																																		
STc2	29	15	47	4	40	31	57	112	32	9	21	30																																																																																																																																																																																																																																																																																																																																		
STc3	75	44	44	53	60	4	139	260	140	60	6	15																																																																																																																																																																																																																																																																																																																																		
STc4	59	8	51	33	95	21	112	211	58	27	12	26																																																																																																																																																																																																																																																																																																																																		
STc5	37	95	42	25	70	7	152	304	170	87	17	7																																																																																																																																																																																																																																																																																																																																		
T	299	299	44	0	200	205	288	907	616	501	202	202																																																																																																																																																																																																																																																																																																																																		
Tc	0	0	0	398	0	0	0	0	0	0	0	0																																																																																																																																																																																																																																																																																																																																		
Tc1	5	4	2	10	4	2	14	8	14	8	5	6																																																																																																																																																																																																																																																																																																																																		
Tc2	10	10	4	10	16	12	2	2	10	12	16	16																																																																																																																																																																																																																																																																																																																																		
Tc3	0	24	30	0	0	26	0	0	0	22	26	28																																																																																																																																																																																																																																																																																																																																		
Tc4	20	46	48	66	20	46	26	22	34	42	44	46																																																																																																																																																																																																																																																																																																																																		
Tc5	48	16	0	48	52	0	50	98	40	26	0	0																																																																																																																																																																																																																																																																																																																																		
Tc6	0	0	0	24	0	0	0	0	0	0	0	0																																																																																																																																																																																																																																																																																																																																		
Tc7	0	0	0	0	0	0	0	0	0	0	0	0																																																																																																																																																																																																																																																																																																																																		
	<p>Rhythm view</p> <p>When you have recorded a rhythm ECG, you can view the entire ECG in the Rhythm view. You can use the scroll bar to move through the ECG.</p> <p>The Rhythm view displays leads in different groupings, so that you can easily switch between the most common groups.</p>																																																																																																																																																																																																																																																																																																																																													
	<p>Old rhythm strip</p> <p>The Old rhythm strip view is only available for ECGs that were recorded with older versions of the Workstation software (software from before 2000). It displays the original II V2 rhythm strip.</p>																																																																																																																																																																																																																																																																																																																																													

	<p>Vector view (optional) The Vector view is only available if the vectorcardiogram option is enabled. It displays the results of an ECG in a vectorcardiogram.</p> <p>The left hand pane displays the reconstructed orthogonal x, y and z leads. The right hand side of the Vector view is divided into three windows.</p> <p>Window 1 displays the following loops:</p> <ul style="list-style-type: none"> • F: complete frontal loop • H: complete horizontal loop • R: complete right sagittal loop <p>Window 2 displays the following loops:</p> <ul style="list-style-type: none"> • Ft: frontal plane of the T wave • Ht: horizontal plane of the T wave • Rt: right sagittal plane of the T wave <p>Window 3 displays the following loops:</p> <ul style="list-style-type: none"> • Fp: frontal plane of the P wave • Hp: Horizontal plane of the P wave • Rp: Right sagittal plane of the P wave
	<p>R-R view (optional) R-R is the interval between two subsequent QRS complexes. The R-R view gives an overview of the heart rate variability. This view lists the number of intervals, the minimum, maximum and average number, and the standard deviation.</p> <ul style="list-style-type: none"> • The Trend graph displays the duration of the subsequent intervals. The x-axis lists the interval numbers. The y-axis displays the duration. • The Histogram graph displays the distribution of the intervals. The x-axis lists the duration (in ms, divided into bins of 8ms). The y-axis lists the number of intervals that falls in a particular bin.

 <table border="1" style="font-size: small; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th>Interval</th> <th>Time (s)</th> <th>RR (ms)</th> <th>HR (bpm)</th> </tr> </thead> <tbody> <tr><td>1</td><td>0.99</td><td>690</td><td>87</td></tr> <tr><td>2</td><td>1.9</td><td>910</td><td>66</td></tr> <tr><td>3</td><td>2.813</td><td>913</td><td>65</td></tr> <tr><td>4</td><td>3.71</td><td>897</td><td>67</td></tr> <tr><td>5</td><td>4.627</td><td>927</td><td>64</td></tr> <tr><td>6</td><td>5.59</td><td>953</td><td>63</td></tr> <tr><td>7</td><td>6.53</td><td>940</td><td>65</td></tr> <tr><td>8</td><td>7.44</td><td>910</td><td>66</td></tr> <tr><td>9</td><td>8.35</td><td>910</td><td>66</td></tr> <tr><td>10</td><td>9.25</td><td>910</td><td>66</td></tr> <tr><td>11</td><td>10.12</td><td>860</td><td>70</td></tr> <tr><td>12</td><td>10.928</td><td>808</td><td>74</td></tr> <tr><td>13</td><td>11.8</td><td>872</td><td>69</td></tr> <tr><td>14</td><td>12.704</td><td>904</td><td>66</td></tr> <tr><td>15</td><td>13.64</td><td>936</td><td>64</td></tr> </tbody> </table>	Interval	Time (s)	RR (ms)	HR (bpm)	1	0.99	690	87	2	1.9	910	66	3	2.813	913	65	4	3.71	897	67	5	4.627	927	64	6	5.59	953	63	7	6.53	940	65	8	7.44	910	66	9	8.35	910	66	10	9.25	910	66	11	10.12	860	70	12	10.928	808	74	13	11.8	872	69	14	12.704	904	66	15	13.64	936	64	<p>HRV view (optional) This tab shows the heart rate variability. Additional information is available upon request.</p> <p><i>Note: HRV option not sold in the US.</i></p>
Interval	Time (s)	RR (ms)	HR (bpm)																																																														
1	0.99	690	87																																																														
2	1.9	910	66																																																														
3	2.813	913	65																																																														
4	3.71	897	67																																																														
5	4.627	927	64																																																														
6	5.59	953	63																																																														
7	6.53	940	65																																																														
8	7.44	910	66																																																														
9	8.35	910	66																																																														
10	9.25	910	66																																																														
11	10.12	860	70																																																														
12	10.928	808	74																																																														
13	11.8	872	69																																																														
14	12.704	904	66																																																														
15	13.64	936	64																																																														

The view in the workspace can be used in for example a Word document. Right-click in the Workspace and select copy from the pop-up menu; paste the view in a document.

4.3. Parameters

The lower part of the workspace contains the Parameters pane. The Parameters pane contains global parameters that are determined from all leads. These parameters are:

- Patient age and heart rate
- P and PQ duration
- QRS duration
- QT, QTc and QTd duration
- P, QRS and T axis

4.4. QTc

The QT interval in an ECG is a good indicator of the repolarization. However, the QT depends heavily on the heart rate. To make a useful measurement, the QT is usually corrected.

Welch Allyn CardioPerfect offers three correction methods that can be used to derive the QTc parameter:

- Bazett:

$$QTc_B = \frac{QT}{\sqrt{RR}} = \frac{QT}{\sqrt{\frac{60}{HR}}} = QT \sqrt{\frac{HR}{60}}$$

- Fridericia:

$$QTc_F = \frac{QT}{\sqrt[3]{RR}} = \frac{QT}{\sqrt[3]{\frac{60}{HR}}} = QT \sqrt[3]{\frac{HR}{60}}$$

- Hodges:

$$QTc_H = QT + 1.75 * (HR - 60)$$

To select the QTc correction method:

1. In the **File** menu, click **Settings**. The **Settings** dialog box is displayed.
2. Click **ECG** and click on the **Viewing** tab.
3. Under **QTc method**, click the method that you want to use.
4. Click **OK** to save your changes.

4.5. QT dispersion (optional)

Note: *QT dispersion option not sold in the US.*

QT dispersion (QTd) is defined as the difference in duration between the longest QT interval and the shortest QT interval in any lead.

There are several ways of calculating the QT dispersion. These ways depend on:

- The reference point in the QRS complex from which the measurement should be started
- Whether the marker that indicates the reference point should be local or global. A local marker is one that is taken for each lead, and therefore differs for each lead. A global marker is one that is used for all leads, and therefore is the same for all leads.
- The number of leads that is used for calculation.

The QTd duration is calculated and displayed in the Parameters area of the view. You can specify a number of options that affect the calculation of the QTd duration.

To set QTd options:

1. In the **File** menu, click **Settings**. The **Settings** window is displayed.
2. Click **ECG** and click on the **QT dispersion** tab.
3. In the **QT dispersion** tab, select which reference point you want to use, and whether it should be local or global.
4. Select the number of leads you want to use, see section 8.1 for details.
5. Click **OK** to save your changes.

4.6. Working with views

There are a number of things you can do in a view. They fall apart in the following groups of actions:

Action	Function	Available in
Adjusting scales and magnitude of the view	Zoom in and out	4x3, 2x6, Averages, Rhythm, Old rhythm strip, Vector
	Reset zoom	4x3, 2x6, Averages, Rhythm, Old rhythm strip, Vector, R-R
	Set chart speed	4x3, 2x6, Averages, Rhythm, Old rhythm strip, Vector
	Set sensitivity	4x3, 2x6, Averages, Rhythm, Old rhythm strip, Vector
View one single average or loop	Enlarge	Averages, Vector
	Autosize	Vector
Improving signal quality	Apply muscle noise filter	4x3, 2x6, Averages, Rhythm, Vector
	Apply AC filter	4x3, 2x6, Averages, Rhythm, Vector
	Apply anti-aliasing	4x3, 2x6, Averages, Rhythm, Vector
Studying the ECG	Make measurements	4x3, 2x6, Averages, Rhythm, Vector
	Compare ECGs	Averages
	Display markers	Averages, Vector

On the next pages, each action is described in detail. Most of these actions are also available from the right-click menu.

4.7. Zoom in and out on an ECG

If you want to get a closer look at the traces, you can adjust the size of the leads with by zooming in and out of the ECG.

To see leads in more detail:

- In the **View** menu, click **Zoom in**.

To see a larger part of the ECG:

- In the **View** menu, click **Zoom out**.

To reset the zoom function and return to the standard lead size:

- In the **View** menu, click **Reset zoom**.

4.8. Set chart speed and sensitivity

Welch Allyn CardioPerfect offers a wide range of speed and sensitivity. You can adjust the scale of the ECG by adjusting the chart speed and the sensitivity.

To set the chart speed:


- In the **View** menu, point to **Chart speed** and select a value. The higher the chart speed, the more lead signal will be visible.

To set the sensitivity:

- In the **View** menu, point to **Sensitivity** and select a value. The lower the value, the lower the peaks in the lead signal will be.

4.9. View one single complex or loop

In the **Averages** view and the **Vector** view, you can view one single complex or loop.



To view a single complex or loop:

1. In the **Action** menu, click **Enlarge**. The first lead in an ECG (or the first loop in an VCG) is enlarged. With the autosize function, available from the right-click menu the selected loop will be shown as large as possible in the available space.
2. To enlarge another lead or loop, select it from the drop down in the upper left corner of the workspace.
3. To switch off the enlarge function, click **Enlarge** from the **Action** menu once more.

4.10. Turn pacemaker on and off

ECG traces can contain artificial pacemaker signal indicators. You can remove this artificial pacer indicator by disabling the "Show Pacer" selection. To learn how, see Customizing the Resting ECG software on page 40.

4.11. Apply muscle noise filter

Muscle noise in an ECG signal hides low amplitude signals that may be important for the interpretation of an ECG. You can remove this noise with a muscle noise filter.

To apply a muscle noise filter:

- In the **Action** menu, click **Muscle noise filter**.

4.12. Apply AC filter

ECG traces can contain noise that is due to AC mains interference. This makes the traces harder to read. You can filter out noise by applying an AC filter. When you apply a filter, you do not change the actual ECG signal. You only change the way it is displayed on the monitor. The ECG signal always keeps its original form.

To apply an AC filter while you view an ECG:

- In the **Action** menu, click **AC filter**.

4.13. Apply baseline filter

ECG traces can contain some baseline wander caused by movement. You can reduce this wander of the baseline by applying a baseline filter. When you apply the baseline filter you only change the display of the traces. The actual signal remains unchanged.

To apply a baseline filter while you view an ECG:

- In the **Action** menu, click **baseline filter**.

If accurate ST segment contours are required for ECGs, do not use the 0.5 Hz baseline wander filter. This filter suppresses baseline wander to the extent that it may alter the ST segment. Instead, configure your cardiograph to operate without the baseline wander filter. Regardless of the filter used, the rhythm characteristics of the ECG are accurately recorded and the filter settings do not affect the interpretation algorithm.

4.14. Apply anti-aliasing

When you view an ECG on a monitor, the signal can look ragged, especially when you zoom in on a complex. You can use anti-aliasing to make the signal look smoother. Anti-aliasing does not change the signal itself. It only affects how the signal is displayed on the monitor.



Before anti-aliasing



After anti-aliasing

To apply anti-aliasing:

- In the **View** menu, click **Anti-aliasing**.

4.15. Make measurements

In each view that displays leads, complexes or vectors, you can make measurements between two points.

To make a measurement between two points:

1. Move the crosshair pointer to the starting point of your measurement.
2. Double click on the starting point. Welch Allyn CardioPerfect inserts a mark.
3. Move the crosshair pointer to the end point of your measurement.
4. Double click on the end point. Welch Allyn CardioPerfect draws a line between the two points and displays the measured values.

To clear all measurements:


- In the **Action** menu, click **Refresh**.

4.16. Compare ECGs

If a patient has had several ECGs, Welch Allyn CardioPerfect can make a serial comparison of the average complexes of these ECGs. In such a comparison, the curves are superimposed in such a way that the starting points of the QRS complexes coincide. Serial comparison is only possible in the Averages tab.

To compare ECGs:

1. In the **Tools** menu, click comparison. The **Comparison** dialog box is displayed. This dialog box contains all other ECGs that have been recorded for this patient.



2. In the **Comparison** dialog box, select one or more ECGs to which you want to compare your ECG.
3. Click **OK**. The selected ECGs are now displayed.

4.17. Display markers

Markers are convenient reference points that mark global points in an average complex or vector. You can use a marker as a starting point for your observations or measurements. You can only view markers in the Average and Vector tabs.

Welch Allyn CardioPerfect inserts markers at the following points:

- Start P wave
- End P wave
- Start QRS complex
- End QRS complex
- End T wave

To display markers:


- In the **View** menu, click **Markers**. The markers are displayed.

Tips for displaying markers:

- You can set the color of the markers in the ECG settings.
- You can also use your right mouse menu for displaying markers.

5. Interpreting ECGs

When you view an ECG, the interpretation is shown in the lower right corner of the workspace. If you have the optional MEANS software installed on your computer, this software makes an initial interpretation for you. If not, this is where you can enter your own interpretation.



5.1. About MEANS and PEDMEANS interpretation software

MEANS is short for Modular ECG Analysis System. PEDMEANS is short for Pediatric Modular ECG Analysis System. They are ECG interpretation programs developed by the University of Rotterdam in the Netherlands, and they can be used to interpret ECGs that were recorded with Welch Allyn CardioPerfect.

MEANS and PEDMEANS use an algorithm that consists of signal processing, measurements, rhythm and contour classification. The adult algorithm is applicable to patient ages 18 and higher. The pediatric algorithm is applicable for ages 1 day through 17 years.

MEANS and PEDMEANS interpretations consist of

- A number of statements in different categories
- Reasoning supporting the statement
- A conclusion
- An indication of the severity of the ECG

Missing information

The MEANS algorithm uses the gender and the age of a patient to make a reliable interpretation. If this information is not present in the patient card, the following assumptions are made:

- The patient is male
- The patient is 35 years old

If these values are used, this is mentioned at the top of the interpretation.




Caution

A computer-generated interpretation cannot replace sound medical reasoning by a trained professional. Therefore, a physician should always review the interpretation.

5.2. Edit and confirm an interpretation

You can edit an interpretation in the Interpretation editor. In this editor, you can enter your own texts. Alternatively, you can use the statement tree to select and enter common interpretation statements. Until confirmed, the test will be labeled as *'Unconfirmed Interpretation'*.



To edit and confirm an interpretation manually:

1. In the **Tools** menu, click **Interpretation**. The Interpretation editor is displayed.
2. In the Interpretation display, at the pointer, start typing.
3. Click the **Confirm** button to save your comments and to return to the ECG.

To edit and confirm an interpretation with the statement tree:

1. In the **Tools** menu, click **Interpretation**. The Interpretation editor is displayed.
2. From the statement tree, click on one of the categories to display all possible statements for that category.
3. From a category, click on the statement that you want to include in the interpretation. The statement is added.
4. To delete a statement from the interpretation, select the statement text and press **BACKSPACE** to delete it.
5. Click the **Confirm** button to save your comments and to return to the ECG.


Tips for editing and confirming an interpretation:

- You can automatically insert the current date and time by clicking the **Date/time** button.
- You can clear the interpretation editor by clicking the **Clear** button.
- When you return to the ECG after confirming an interpretation, the interpretation header shows the date and time of confirmation and the name of the person that confirmed it.
- The statement tree can be changed. Please consult your system administrator or local

dealer for new or changed statements.

5.3. View interpretation history

When you change something in an interpretation, Welch Allyn CardioPerfect does not change the original interpretation but creates a new one. This way, you never lose any information. A copy of all interpretations is kept in the interpretation history.



To view the interpretation history:

1. In the **Tools** menu, click **History**. The **Interpretation history** window is displayed. The left-hand pane displays the interpretations sorted by date. The right-hand pane shows the content of each interpretation, plus the interpretation date, time and editor.
2. Click on a date to view an interpretation.

5.4. Reanalyze an ECG

When you have overwritten a MEANS interpretation with a manual interpretation, you can always get the MEANS interpretation back. To do this, you need to reanalyze the ECG.

To reanalyze an ECG:

- In the **Tools** menu, click **Reanalyze**. The original MEANS interpretation is placed back in the interpretation window.

6. Printing ECGs

6.1. Print an ECG

You can make a printout of each view in the ECG at any time between recording and interpretation. There are two ways of manually printing an ECG:

- One view: Welch Allyn CardioPerfect prints one view in the way it is displayed on the monitor.
- Selected formats: Welch Allyn CardioPerfect prints a number of views simultaneously.

Print formats

The resting ECG Module can print the following reports:

- 12 averages + 6 rhythm leads
- 2x6, all pages
- 2x6, two pages 50 mm/s
- 2x6
- 4x3, 25 mm/s
- 4x3, 50 mm/s
- 4x3 5 mm/mV
- 4x3 20 mm/mV
- Averages
- Large averaged complex
- Measurements
- OldRhythm
- Rhythm
- R-R
- Vectors
- HRV

Each report contains the view and a header that displays additional information.

Please refer to the Workstation manual for further information on printing ECGs.

6.2. Automatically print an ECG

Welch Allyn CardioPerfect can automatically print an ECG directly after recording and after confirming the interpretation. To automatically print an ECG, you need to enable automatic printing and select the ECG formats to be printed.

To enable automatic printing:

1. In the **File** menu, click **Settings**. The **Settings** dialog box is displayed.
2. Click ECG and click on the Printing tab.
3. In the Printing tab, click Print after recording and/or Print after interpretation confirmed.
4. Click OK to confirm.

7. Maintaining the Recorder

To keep your Welch Allyn AM12 Recorder in good working condition, do not expose the Recorder to temperatures lower than -20° C or higher than 60° C, at a maximum non-condensing humidity of 95%.

Warning

Keep the AM12 ECG Recorder, reusable electrodes, and the patient cable clean. Patient contact with contaminated equipment can spread infection.

The patient cables should be cleaned after each use and disinfected as needed.

Caution

Never immerse the AM12 ECG Recorder or the patient cable in liquid. Never autoclave or steam clean the AM12 ECG Recorder or the patient cable. Never pour alcohol directly on the AM12 ECG Recorder or the patient cable, and never soak any components in alcohol. If any liquid enters the AM12 ECG Recorder, remove the AM12 ECG Recorder from service, and have it inspected by a qualified service person before using it again.

7.1. Clean the AM12 ECG Recorder

Unless the AM12 ECG Recorder (the device itself rather than the cables and electrodes) comes in direct contact with a patient, it is acceptable to clean the device on a routine basis according to your facility's protocols and standards or local regulations. Patient contact with the device might require immediate cleaning.

The following agents are compatible with the AM12 ECG Recorder:

Clorox Healthcare® Bleach Germicidal Wipes (use according to instructions on product label), or a soft, lint-free cloth with a solution of Sodium Hypochlorite (10% household bleach and water solution) minimum 1:500 dilution (minimum 100 ppm free chlorine) and maximum 1:10 dilution as recommended by the APIC Guidelines for Selection and Use of Disinfectants

Caution

When cleaning the device, avoid using cloths or solutions that include quaternary ammonium compounds (ammonium chlorides) or glutaraldehyde-based disinfectants.

7.2. Cleaning the Patient cables and PC interface cables

When you use electrodes that need electrode gel, make sure that the cables and the non-disposable electrodes are cleaned regularly. Otherwise, the gel may build up on the wires.

Clean the cables

1. Slightly dampen a soft, clean cloth with lukewarm, soapy water or a neutral cleaner and

- clean the patient cable and PC USB interface cable.
2. Dry all cables with a clean, soft cloth or paper towel.
3. Wait at least 10 minutes before powering on the AM12 ECG Recorder again.

Disinfect the cables

For disinfecting the exterior surfaces of the cables and lead wires, wipe the exterior using: Clorox Healthcare® Bleach Germicidal Wipes (use according to instructions on product label), or a soft, lint-free cloth with a solution of Sodium Hypochlorite (10% household bleach and water solution) minimum 1:500 dilution (minimum 100 ppm free chlorine) and maximum 1:10 dilution as recommended by the APIC Guidelines for Selection and Use of Disinfectants



Caution

Do not use these agents for routine cleaning of the cables. Alcohol can cause the plastic to become brittle and may cause the cable to fail prematurely.


Inspecting the equipment

Perform the following inspections daily:

- Check for cracks or breaks in the PC USB interface cable, the patient cable, the patient electrodes, and the AM12 ECG Recorder.
- Check for bent or missing pins on all cables.
- Check all cable and cord connections; reseat if any connectors are loose.

8. Acquisition Module

AM12 with Lead Wires



The AM12 is available for a traditional wired connection with direct USB connection and 40,000 Hz ECG acquisition. The 12-Lead ECG button can be used to acquire a 12-lead ECG at the patient's side.

AM12 Specifications

FEATURE	SPECIFICATION*
Instrument Type	12-lead USB-connected ECG acquisition module
Input Channels	12-lead signal acquisition and transmission
ECG Leads Transmitted	I, II, III, aVR, aVL, aVF, V1, V2, V3, V4, V5, and V6
Lead Set	RA, LA, RL, LL, V1, V2, V3, V4, V5, and V6 (R, L, N, F, C1, C2, C3, C4, C5, and C6) with detachable lead wires
Sampling Rate	40,000 samples/second/channel acquisition; 1,000 samples/second/channel transmitted for analysis
Resolution	1.875 μ V/LSB
User Interface	Two-button operation: ECG and Rhythm; Rhythm button captures Rhythm ECG
Defibrillator Protection	Complies with AAMI standards and IEC 60601-2-25
Recovery time after defibrillation	100% gain accuracy after 5 seconds
Operation	Continuous
Special Functions	LED indication of power status, operating mode, and lead fail
Device Classification	Type CF, USB powered
Weight	16.2 oz (460 g) including lead wires
Dimensions	4.45 x 4.25 x 1.1" (11.3 x 10.8 x 2.79 cm)
Storage Temperature	-20° to +50° C (-4° to 122° F)
Transport Temperature	-20° to +49° C (-4° to 120° F)
Relative Humidity	15 to 95% (non-condensing)
Altitude	Operate normally and prolonged storage up to 3000m

Medical Device Directive

The AM12 complies with the Medical Device Directive 93/42/EEC and carries the CE mark accordingly.

Declaration of Conformity available upon request.

*Specifications subject to change without notice

8.1. Lead Fail

In the software, lead failure is represented as a square wave being presented on the lead that has failed. On the acquisition module, lead fail is indicated using LEDs located on the front of the AM12. A yellow LED indicates a lead fail condition is present in one or more leads. A solid green LED indicates proper lead connection in all leads.

8.2. ECG Collection Using the Acquisition Module

ECG acquisition can be performed at the AM12 acquisition module. Select the 12-Lead ECG button on the AM12™ to capture 10 seconds of ECG (see also §2.9). For a rhythm recording, press the Rhythm button; press again to stop (see also §2.10).

8.3. Connecting the Acquisition Module

The AM12 connects to a USB port on the PC for signal acquisition. The CardioPerfect Workstation software will automatically detect the AM12 once it's connected to the USB port.

8.4. Accessories

AM12 Accessories

Part Number	Description
9293-046-62	RPLCE LD SET WAM/AM12 LIMBS BANA AHA GRY
9293-046-63	RPLCE LD SET WAM/AM12 LIMBS BANA IEC GRY
9293-046-64	RPLCE LD SET WAM/AM12 V1-V3 BANA AHA GRY
9293-046-65	RPLCE LD SET WAM/AM12 C1-C3 BANA IEC GRY
9293-046-66	RPLCE LD SET WAM/AM12 V4-V6 BANA AHA GRY
9293-046-67	RPLCE LD SET WAM/AM12 C4-C6 BANA IEC GRY
9293-047-62	RPLCE LD SET WAM/AM12 LIMBS CLIP AHA GRY
9293-047-63	RPLCE LD SET WAM/AM12 LIMBS CLIP IEC GRY
9293-047-64	RPLCE LD SET WAM/AM12 V1-V3 CLIP AHA GRY
9293-047-65	RPLCE LD SET WAM/AM12 C1-C3 CLIP IEC GRY
9293-047-66	RPLCE LD SET WAM/AM12 V4-V6 CLIP AHA GRY
9293-047-67	RPLCE LD SET WAM/AM12 C4-C6 CLIP IEC GRY

Electrodes

Part Number	Description
108071	Tab Electrode Case/5000
108070	Snap Electrode Case/300

9. Customizing the Resting ECG software

You can customize the Welch Allyn CardioPerfect software to your own preferences. The features that you can customize are located in the ECG settings (**File > Settings**).

9.1. General tab

In the **General** tab, you can configure a number of common options that are used by Welch Allyn CardioPerfect.

The **General** tab contains the following options:

Default chart speed	From this list, you can select the default monitoring chart speed. Possible values are 5, 10, 12.5, 25, 50, 100 mm/sec.
Default sensitivity	From this list, you can select the default monitoring sensitivity. Possible values are 5, 10 or 20 mm/mV.
Extremity lead order	With this option you can choose from two different lead orders: Standard (aVL, I, -aVR, II, aVF, III) and Cabrera (I, II, III, aVR, aVL, aVF).
Maximum recording length	The maximum number of seconds for a rhythm recording.
Anti-alias monitor	If this option is selected, your monitor is anti-aliased, so that the curves of the ECG signal appear smoother.
Show new ECG dialog	If this option is selected, the New ECG dialog box is displayed when you start a new ECG. Otherwise, you are taken straight to the Real-time monitor to start recording. See page 14 for more details.
Ask for lead set on pediatric patients	If this option is selected and you select a pediatric patient, Welch Allyn CardioPerfect will ask you whether you want to use a pediatric lead set.
Show Pacer	By disabling this setting, you can remove artificial pacemaker signal indicators. For example, see Pacemaker pulse detection on page 17.
Amplitude unit	The unit in which the amplitude is displayed. This can be either micro volts or millimeters.
Muscle filter frequency	This setting will affect the high cutoff frequency that is used by the muscle filter.

9.2. Viewing tab

In the **Viewing** tab you can configure the settings that determine how the ECGs will be displayed on the screen.

The **Viewing** tab contains the following options:

- | | |
|--|---|
| QTc method (Bazett, Hodges, Fridericia) | With this option you can set the method that should be used to correct the measured QT. |
| AC filter mode | With this option you can set the mode of the AC mains filter. |
| Appearance | Here, you can specify individual colors for the background, grid lines, grid dots, trace, begin and end of the QRS complex, the markers, the T wave and the font that is used in the ECG. |
| Color schemes | This list lets you choose from a number of predefined color formats. |
| Grid style | From this list you can select the style of the grid in which the ECG is displayed. You can either leave out the grid, use lines to represent the grid, or display a full grid. |

9.3. Printing tab

In the **Printing** tab, you can configure automatic printing and selected formats. The **Printing** tab contains the following options:

- | | |
|--|--|
| Default report templates | From this list of templates, you can select the formats that are printed when automatic printing is enabled. These formats are also printed when you click Print selected formats in the ECG window. |
| Grid | From this list, you can select the grid style in which the selected formats should be printed. |
| Print after recording | If this option is selected, the ECG is automatically printed when the recording has finished. Welch Allyn CardioPerfect prints the formats that you selected in the Default report templates area. |
| Print after interpretation is confirmed | If this option is selected, the ECG is automatically printed when the interpretation of the ECG has been confirmed. Welch Allyn CardioPerfect prints the formats that you selected in the Default report templates area. |
| Print calibration pulse | If this option is selected, the calibration pulse will be printed. |

9.4. QT dispersion tab

The QT dispersion tab is only visible when you have purchased the QT dispersion software. Use the QT dispersion tab to set your preferences for the calculation of the QT dispersion.

Note: QT dispersion option not sold in the US.

The **QT dispersion** tab contains the following options:

- Reference point** In the Reference point area, you can specify from which reference point in the QRS complex the measurement should be started, and whether that reference point should be the same for all leads (global), or whether it should be set for each lead (local).
- Leads** In the Leads area, you can specify the number of leads you want to use in calculating the QT dispersion.

Reference point

If you select...	Then...
<i>Local Q</i>	Reference point is local Q point.
<i>Local J</i>	Reference point is local J point.
<i>Global Q</i>	Reference point is global Q point.
<i>Global J</i>	Reference point is global J point.

Leads

If you select...	The leads that are used are...
6	6 precordial leads
8	The shortest peripheral lead The mean of all other peripheral leads
10	6 precordial leads All peripheral leads except the shortest and the longest one.
12	All 12 leads.

9.5. Recorder Tab

In the **Recorder** tab, you can configure your Welch Allyn AM12 Acquisition Module. You can only access this tab when you have administrator rights or when the software security is switched off.

The **Recorder** tab contains the following options:

Model	Use the AM12.
Port	<p>The communication port of the PC to which the recorder is connected. This is typically the USB port.</p> <p>When operating in a thin-client environment, the application displays an additional option, called PerfectLink™. This option allows the use of the AM12 Recorder with a USB cable in thin client environments.</p>
AC filter (Hz)	The frequency that is filtered by the AC mains filter. This can be either 50 or 60 Hz.

9.6. Customize ecg.txt

You can customize the statements that are used in the Comment editor according to your own preferences. Please refer to the Workstation manual for further instructions.

10. Troubleshooting

In this chapter, some known problems and possible solutions are described.

Some buttons or menu entries are inactive

- This is probably caused by the fact that your user role does not allow you to perform the actions of those buttons or menu entries.

Test recovery

To recover a test after the database connection has been lost:

If during the test the connection to the database is lost, for example because of a loose network cable, the test will be saved in a file called "Emergency saved resting ECG #x.MDW" (x stands for a number, which is automatically generated) in the database folder named in the error message. After the database connection has been restored, this file can be imported into the database by using the import function in the Workstation (File – Import, browse to the folder and select the correct file).

Technical Support

If you have a technical question that you cannot answer with the provided tools, please contact our Installation & Support department or contact your local distributor.

When you contact the Installation & Support department via phone, e-mail or fax, please provide the following information:

- Your name, company name, address, phone number, fax number and e-mail address.
- Product serial number.
- Exact product name and version number.
- Type of operating system.
- Type of installation (network or standalone).
- A copy of the Technical Support Form.
- Complete description of the problem and the steps to reproduce it. If applicable we would also like to have the exact error message.

To print the Technical support form:

1. In the **Help** menu, click **Information**.
2. Click on the **Registration** tab.
3. Click on the **Support...** button. The Welch Allyn CardioPerfect support form is now printed and saved as file MDW.txt in the MDW installation directory. You can fax the printout or e-mail the file.

11. Function keys

The Welch Allyn CardioPerfect module is, just like all Windows applications, designed for working with the mouse. However, there might be situations in which working with the keyboard can be quicker. Therefore, a number of functions within the Welch Allyn CardioPerfect module can also be selected directly using the keyboard. Here is a list of all available keyboard shortcuts in this module; for a more general function key description please refer to the Workstation manual:

Viewing	
Key	Function
[SHIFT]+[CTRL]+[E]	Starts a new Resting ECG recording.
[CTRL]+[I]	Opens the Interpretation window
[CTRL]+[H]	Opens the Interpretation History
[CTRL]+[DOWN]	Zooms out.
[CTRL]+[UP]	Zooms in.
[CTRL]+[E]	Enlarge average complex or vector loop.
[CTRL]+[M]	Activates the markers (only active in the 'Averages' and 'Vector' tab).
[CTRL]+[R]	Activates the refresh functionality, which clears all user made measurements.

Real time monitor	
Key	Function
F2	Start/stop test
[Esc]	Exit the recording.
F12	Starts a long recording (In Real Time Monitor).
[INS]	Inserts an event in the recording (Real-time monitor only)

12. Before installing the Resting ECG software

In this chapter, you will find information about the structure of the Welch Allyn CardioPerfect resting ECG software.

12.1. Structure

The workstation consists of two elements:

- Hardware: the recorder and the interface to the computer.
- Software: the Resting ECG module that runs in the Welch Allyn CardioPerfect Workstation.

The recorder must be connected to the computer that runs the module.

Software

The Resting ECG module is automatically installed with Welch Allyn CardioPerfect Workstation. For instructions on how to install and configure Welch Allyn CardioPerfect Workstation, please refer to the Installation manual.

Hardware

The AM12 uses a USB cable to communicate with the computer.

13. Installing the Resting ECG Module

Before you can start recording ECGs, you need to:

- Install the hardware
- Install the drivers
- Configure the software

13.1. Connecting the AM12

Please run the software installation prior to inserting the USB-Interface into a USB socket of your computer.

To set up your computer for use of the USB Interface:

1. Connect the AM12 to the USB port of the computer.

To configure Welch Allyn CardioPerfect Workstation:

1. Start Welch Allyn CardioPerfect Workstation and log in as Administrator.
2. In the **File** menu, click **Settings**, click ECG, and click on the **Recorder** tab.
3. In the **Model** list, select **AM12**.
4. From the **Port** list, select **USB** (This is the default setting after a new installation)

14. Safety and precautions

Conventions



WARNING -

Warning statements describe conditions or actions that can result in personal injury or loss of life.









CAUTION -

Caution statements describe conditions or actions that can result in damage to the equipment or software.

NOTE -

Notes contain additional information on cardiograph usage.

	Attention (Caution, Warning, Danger, Important, Note, Refer to Accompanying Documentation)
	Caution
	Warning
	Ingress Protection (ordinary)
	Serial Number
	Reference Number
	Defibrillation-Proof Type CF applied part
	Manufacture Date YYYY-MM-DD

	CE Mark for Class Is, Im, IIa, IIb & III
	Temperature Range
	Reorder Number
	Dispose of this product and its accessories according to local regulations. Do not dispose of as unsorted municipal waste. For more specific disposal or compliance information, go to www.welchallyn.com/weee or contact Welch Allyn Technical Support at www.welchallyn.com/about/company/locations.htm .
	Consult operating instructions/directions for use (DFU). A copy of the DFU is available on this website. A printed copy of the DFU can be ordered from Welch Allyn for delivery within 7 calendar days.
	Global Trade Item Number

Electromagnetic Compatibility

When using the AM12 cardiograph, electromagnetic compatibility with surrounding devices should be considered and evaluated. The AM12 cardiograph complies with IEC 60601-1-2 limits for EMC.

General Safety and Precautions tips



Radio Frequency (RF) interference between the cardiograph and any existing RF transmitting or receiving equipment at the installation site, including electrosurgical equipment, in close proximity to the cardiograph should be evaluated before the equipment is operated as they may seriously degrade performance.

The AM12 Cardiograph is susceptible to interference from RF energy sources (lowered RF immunity) which exceed the IEC 60601-1-2 limits, such as power line bursts, other medical devices, cellular products, information technology equipment and radio/television transmission.

To reduce EMC interference the cardiograph shall be separated from the emitting source as much as possible. If assistance is needed, call

your local Welch Allyn service representative.

Artifact on the ECG caused by electromagnetic interference should be evaluated by a physician or physician authorized personnel to determine if it will negatively impact patient diagnosis or treatment.

Like all electronic devices, this cardiograph is susceptible to electrostatic discharge (ESD). Electrostatic discharge typically occurs when electrostatic energy is transferred to the patient, the electrodes, or the cardiograph. ESD may result in ECG artifact that may appear as narrow spikes on the cardiograph display or on the printed report. When ESD occurs, the cardiograph's ECG interpretation may be inconsistent with the physician's interpretation.

Welch Allyn assumes no liability for failures resulting from RF interference between Welch Allyn medical electronics and any radio frequency generating equipment when these levels exceed those established by applicable standards.

Patient and Operational Safety

The cardiograph isolates all connections to the patient from electrical ground and all other conductive circuits in the cardiograph. This reduces the possibility of hazardous currents passing from the cardiograph through the patient's heart to ground. To ensure the patient's safety and your own please observe the following:

Any system components (e.g. treadmill, personal computer, ergo meter) that require to be connected to an outlet socket shall use only grounded power cords (three-wire power cords with grounded plugs). Also make sure the outlet accepts the plug and is grounded. **Never** adapt a grounded plug to fit an ungrounded outlet by removing the ground prong or ground clip.

Multiple portable outlet sockets shall not be placed on the floor. Multiple portable outlet sockets or extension cord shall not be connected to the system. Do not connect items which are not part of the system. The use of multiple (non-) medical electrical equipment connected to the same patient may pose a safety hazard due to the summation of leakage currents from each instrument. Any combination of (non-) medical electrical equipment should be evaluated by local safety personnel before put into service. Multiple portable outlet sockets use without an isolation transformer is disapproved unless casual access for additional equipment is impeded or prevented.

Patient cable and Interface cable



The patient cable supplied with the AM12 cardiograph is an integral part of the cardiograph's safety features. Using any other patient cable may compromise defibrillation protection as well as cardiograph performance. The patient cable should be routed away from power cords and any other electrical equipment. Failure to do so can result in AC power line frequency interference on the ECG trace.

 **Warning**

Do not touch the patient, patient cable, PC interface cable or cardiograph during defibrillation. Death or injury may occur from the electrical shock delivered by the defibrillator. It is recommended to check the patient cable and PC interface cable for damage prior to the use of the system. If damage exists do not use the cable, contact your local Welch Allyn Sales Office or your authorized Welch Allyn dealer or distributor to have the cable replaced.

15. Electromagnetic Compatibility (EMC)

Electromagnetic Compatibility

Electromagnetic compatibility with surrounding devices should be assessed when using the device.

An electronic device can either generate or receive electromagnetic interference. Testing for electromagnetic compatibility (EMC) has been performed on the device according to the international standard for EMC for medical devices (IEC 60601-1-2). This IEC standard has been adopted in Europe as the European Norm (EN 60601-1-2).

The device should not be used adjacent to, or stacked on top of other equipment. If the device must be used adjacent to or stacked on top of other equipment, verify that the device operates in an acceptable manner in the configuration in which it will be used.

Fixed, portable, and mobile radio frequency communications equipment can affect the performance of medical equipment. See the appropriate EMC table for recommended separation distances between the radio equipment and the device.

The use of accessories, transducers, and cables other than those specified by Welch Allyn may result in increased emissions or decreased immunity of the equipment.

Emissions and immunity information

Guidance and Manufacturer’s Declaration: Electromagnetic Emissions

The equipment is intended for use in the electromagnetic environment specified in the table below. The customer or the user of the equipment should ensure that it is used in such an environment.

Emissions test	Compliance	Electromagnetic environment - guidance
RF emissions CISPR 11	Group 1	The equipment uses RF energy only for its internal function. Therefore, its RF emissions are very low and not likely to cause any interference in nearby electronic equipment.
RF emissions CISPR 11	Class A	The equipment is suitable for use in all establishments other than domestic and those directly connected to the public low-voltage power supply network that supplies buildings used for domestic purposes.
Harmonic emissions	Complies	

IEC 61000-3-2

Voltage fluctuations/
flicker emissions

Complies

IEC 61000-3-3

Guidance and Manufacturer's Declaration: Electromagnetic Immunity

The equipment is intended for use in the electromagnetic environment specified in the table below. The customer or the user of the equipment should ensure that it is used in such an environment.


Emissions test	Compliance	Compliance level	Electromagnetic environment - guidance
Electrostatic discharge (ESD) IEC 61000-4-2	±6 kV contact ± 8 kV air	± 6 kV contact ± 8 kV air	Floors should be wood, concrete or ceramic tile. If floors are covered with synthetic material, the relative humidity should be at least 30%.
Electrical fast transient/burst IEC 61000-4-4	±2 kV for power supply lines ±1 kV for input/output lines	± 2 kV for power supply lines ±1 kV for input/output lines	
Surge IEC 61000-4-5	± 1 kV differential mode ± 2 kV common mode	± 1 kV differential mode ± 2 kV common mode	
Voltage dips, short interruptions and voltage variations on power supply input lines IEC 61000-4-11	<5% UT (>95% dip in UT) for 0.5 cycle 40% UT (60% dip in UT) for 5 cycles	<5% UT (>95% dip in UT) for 0.5 cycle 40% UT (60% dip in UT) for 5 cycles	
Power frequency(50/60Hz)magnetic field	3 A/m	3 A/m	Power frequency magnetic fields should be at levels characteristic of a typical location in a typical commercial or hospital environment.

Note: UT is the AC Mains voltage prior to application of the test level.

Guidance and Manufacturer's Declaration: Electromagnetic Immunity

The equipment is intended for use in the electromagnetic environment specified in the table below. The customer or the user of the equipment should ensure that it is used in such an environment.

Emissions test	IEC 60601 test level	Compliance level	Electromagnetic environment - guidance
Conducted RF IEC 61000-4-6	3 Vrms 150 kHz to 80 MHz	3 Vrms 150 kHz to 80 MHz	Portable and mobile RF communications equipment should be used no closer to any part of the equipment, including cables, than the

			recommended separation distance calculated from the equation applicable to the frequency of the transmitter.
Radiated RF IEC 61000-4-3	3 V/m 80 MHz to 2.5 GHz	3 V/m 80 MHz to 2.5 GHz	Recommended separation distance
			$d = \left[\frac{3.5}{3V_{rms}} \right] \sqrt{P}$ $d = \left[\frac{3.5}{3V/m} \right] \sqrt{P}$ <p style="text-align: right;">80 MHz to 800 MHz</p> $d = \left[\frac{7}{3V/m} \right] \sqrt{P}$ <p style="text-align: right;">800 MHz to 2.5 GHz</p>
			of the transmitter in watts (W) according to the transmitter manufacturer and d is the recommended separation distance in meters (m).
			Field strengths from fixed RF transmitters, as determined by an electromagnetic site survey ^a , should be less than the compliance level in each frequency range ^b .
			Interference may occur in the vicinity of equipment marked with the following symbol:
			

^aField strengths from fixed transmitters, such as base stations for radio (cellular/cordless) telephones and land mobile radios, amateur radios, AM and FM radio broadcast, and TV broadcast cannot be predicted theoretically with accuracy. To assess the electromagnetic environment due to fixed RF transmitters, an electromagnetic site survey should be considered. If the measured field strength in the location in which the equipment is used exceeds the applicable RF compliance level above, the equipment should be observed to verify normal operation. If abnormal performance is observed, additional measures may be necessary, such as reorienting or relocating the equipment.

^bOver the frequency range 150 kHz to 80 MHz, field strengths should be less than [3] V/m.

Recommended separation distances between portable and mobile RF communications equipment and the equipment

The equipment is intended for use in the electromagnetic environment in which radiated RF disturbances are controlled. The customer or the user of the equipment can help to prevent electromagnetic interference by maintaining a minimum distance between portable and mobile RF communications equipment (transmitters) and the equipment as recommended in the table below, according to the maximum output power of the communications equipment.

Rated max. output power of transmitter (W)	Separation distance according to frequency of transmitter (m)	
	150 KHz to 800 MHz	800 MHz to 2.5 GHz
	$d = 1.2 \sqrt{P}$	$d = 2.3 \sqrt{P}$
0.01	0.1m	0.2m
0.1	0.4m	0.7m
1	1.2m	2.3m
10	4.0m	7.0m
100	12.0m	23.0m

For transmitters rated at a maximum output power not listed above, the recommended separation distance d in meters

(m) can be estimated using the equation applicable to the frequency of the transmitter, where P is the maximum output power rating of the transmitter in watts (W) according to the transmitter manufacturer.

Note 1: At 800 MHz, the separation distance for the higher frequency range applies.

Note 2: These guidelines may not apply in all situations. Electromagnetic propagation is affected by absorption and reflection from structures, objects, and people.

Index

12 lead-ECG	22	Edit ECG information.....	21
2x6 view	22	Electrode placement.....	12
4x3 view	22	End	31
AC filter	12, 29	P.....	31
Apply	29	QRS	31
AC mains interference	12, 15, 16, 29	Enlarge	28
Action menu.....	15, 16, 28, 29, 30	Enter IRQ	43
Anti-aliased.....	29, 40	Event	17
Apply AC filter.....	15, 29	Capture	17
Apply anti-aliasing	29	Events button	12, 16
Ask for leadset.....	40	Extremity leadorder	40
Automatically print an ECG	35	File menu.....	25
Averages	28, 30, 31	Filter.....	12
Averages view	22	Fridericia.....	25, 41
AVF	22	General settings	40
Bazett.....	25, 41	Global J	42
Cabrera.....	40	Global Q	42
Calculating.....	26, 42	History	34
QT	26, 42	Hodges	25, 41
Cancel recording	17	Information	21
Capture an event.....	17	Information window	21
Chart speed	28	Interpretation	33, 34
Compare ECGs	30	Interpreting ECGs.....	32
Comparison dialog.....	30	IRQ	43
Complex	28	J... ..	42
Confirm button.....	33	Leads.....	42
Confirm interpretation	33	Leadset.....	40
CPCOM	43	Local J	42
CPCOM PCI	43	Local Q	42
Create	16	Loop.....	28
Pre-triggered recording.....	16	Make measurements.....	30
Create a new patient	14	Manually print	35
Curves	40	Markers	31
Customize Cardio Perfect.....	40	MEANS.....	32
Date/time button	33	MEANS Interpretation software.....	34
Default report template	41	Measurements.....	30
Delete measurements	30	Measurements view	23
Display ECG traces	15	Muscle noise filter.....	16, 28
Display markers.....	31	Old rhythm strip view.....	23
ECG	12, 28, 29, 32, 34, 35	Open.....	27, 35
Automatical print	35	ECG	27, 35
Compare	30	P.....	31
Interpreting.....	32	End.....	31
Open	27, 35	Start	31
Reanalyze	34	pacemaker signal indicators.....	15, 17, 28, 40
Record	12, 15	Parameters	25, 26
Record rhythm	16	Patient	14
View	29	Create new	14
ECG settings	40	Place electrodes.....	12
General tab	40	Plane	24
Printing tab.....	41	Precordial leads.....	26
QT dispersion tab.....	42	Pre-triggered recording	16
Recorder tab	43	Pre-triggered recording	16
Viewing tab	41	Print	35
Ecg.txt.....	43	ECG	35

Resting ECG Module - User Manual

Print settings.....	41	Sensitivity	28
Printing	35	Set	15
Q.....	42	Chart speed	28
QRS	26, 31, 41, 42	Rhythm strip.....	15
Complex.....	42	Sensitivity.....	28
End.....	31	Set QTd options	26
Start.....	31	Shortcut keys.....	45
QT.....	25, 26, 42	Show Pacer	40
Calculating	26, 42	Start.....	31
Dispersion settings.....	42	P.....	31
QT dispersion.....	26	QRS	31
QTc correction method	25	Tools menu.....	21, 33, 34
QTd	26	Traces	15
QTd options	26	USB	43
QT dispersion settings.....	26	V1	22
Real-time monitor	12, 15, 16, 17, 40	V6	22
Reanalyze ECG.....	34	Vector	28, 31
Record	12, 15, 16	Vector view.....	24
ECG	12, 15, 16	View.....	15, 21, 28, 29, 32, 34
Record button	16, 17	2x6	22
Recorder settings	43	4x3	22
Reference point	42	Averages.....	22
Refresh	30	Complex.....	28
Remove measurements	30	ECG	15, 29, 32
Repolarization.....	25	ECG information	21
Reset zoom	27	Interpretation history	34
Rhythm	16	Leads	15
Rhythm button	16	Loop	28
Rhythm ECG	16	Measurements.....	23
Rhythm strip	15	Old rhythm strip	23
Rhythm view	23	Rhythm	23
Right sagittal plane.....	24	R-R.....	24
R-R view	24	Vector	24
Sagittal plane.....	24	View menu.....	28, 31
Select.....	25	View settings	41
QTc correction method	25	Zoom	27