




Safetystay P1097: For aluminium awning and casement windows.

Operation: Stainless steel arms limit window opening to approximately 100mm.

Application:

- Safetystays are designed to allow safer ventilation when house is occupied. When house is unoccupied, windows should be deadlocked with an appropriate Yale window lock
- Enables windows to comply with New Zealand Building Code clause F4 - Safety from Falling

Screw and Rivet Guide



*Screw model numbers shown are Yale numbers.



SAFETYSTAY SAFER WINDOW VENTILATION

PROFESSIONAL SERIES

CONTENTS

- 2 x Safetystays - non handed
- 4 x Packers
- 4 x 6g 8mm pan head screws
- 4 x 6g 12.5mm pan head screws
- 4 x 6g 25mm pan head screws
- 2 x 8g 12.5mm countersunk screws
- 2 x 8g 14.5mm countersunk screws
- 2 x 8g 25mm countersunk screws

TOOLS REQUIRED

-  Drill
-  2.5mm drill bit
-  3.5mm drill bit
-  4.1mm drill bit
-  Pozi screwdriver
-  Tape measure

P1097C

SAFETY STAY

SAFER WINDOW
VENTILATION

PROFESSIONAL
SERIES

SAFER VENTILATION

Suitable for aluminium



Suitable
for awning



Suitable
for casement



Provides
child safety



Deters
unlawful entry



Easy
install



Instructions
included



The world's favourite lock
www.yalelock.co.nz

ASSA ABLOY New Zealand
6 Armstrong Road, Albany,
Auckland 0632, New Zealand
Quality, ISO 9001
Environmental, ISO 14001
For customer feedback:
nzsales@assaabloy.com

An ASSA ABLOY Group brand


ASSA ABLOY



Safetystay

The safety window stay

Components




Note: Safetystays do not come in a LH and RH pair. They are reversible.

1

- For safety and security we recommend that two stays be fitted to each window for safety and best resistance to forced entry.

Note: There is a wide variation of aluminium window types incorporating differing shapes and thicknesses of aluminium material.




Awning Windows

2 Determine if packers are required

- Hold the Safetystay in position (stop must face towards the frame) on the window.
- Check if the Safetystay arms will clear the upstands on both the window sash and window frame.
- Packers are required if the Safetystay makes contact with any part of the window sash and/or frame.

Note: We supply 4 packers that enable this model to be fitted to Fisher, Rylock and Lyte brand aluminium windows. Most other brands of windows do not require packers.




An ASSA ABLOY Group brand

3

Fitting sash plate

- Select fixing position for sash plate as close to base and as far forward as practical.
- Mark hole positions and drill two 2.5mm diameter holes.
- To ensure screws will clear glass line avoiding damage to the glass during fixing, insert small diameter nail to establish if there is sufficient clearance between screw and glass.
- Fix sash plate in position with 8mm screws. Use the 12.5mm screws if packers are being used.



5


Fitting Safetystay to other side of window

- Follow steps 1-4 to install the Safetystay on the other side of the window.

Note: Fit at same height as the first one.



A long nose extension for the rivet gun is sometimes required. If unavailable, take one rivet head off its nail and slide it onto another complete rivet (see diagram below) and use with rivet gun in normal way. This will enable the rivet to reach into the required position within the sash plate.




6

Fitting additional screws and rivets


- For additional strength drill a 3.5mm hole through the two bearing holes (ensuring screws will clear glassline) and fix frame and sash plates with 8 gauge countersunk screws.

Note: Use a hacksaw to cut screw to appropriate size if you have to reduce the screw length when fitting.



Installing Safetystays

Follow instructions as per awning windows but fit at top and bottom of windows on the opposite side to the window hinges.



ASSA ABLOY

4

Fitting frame plate

- Mark the position for frame plate at same height as for sash plate.
- Mark hole positions and drill two 2.5mm diameter holes and fix frame plate in position with the 25mm long screws whether packers are being used or not.

Note: When fitting frame plate next to a window with a fixed (non opening) sash it may be necessary to reduce the length of the 25mm screw - use a hacksaw to cut screw to appropriate size

IMPORTANT

Safetystays can be fitted to all windows in your home. However we recommend not fitting Safetystays to one window in each room to allow exit in emergencies. Guardian Securistays are recommended for this emergency window as it can be readily released from the inside only.