

# Keysight M8085A Plugins for MIPI Receiver Test Solutions

Installation  
Guide

# Notices

© Keysight Technologies 2019

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies as governed by United States and international copyright laws.

## Trademarks

MIPI™ C-PHY™ and MIPI™ D-PHY™ are registered trademarks of the MIPI™ Alliance.

## Manual Part Number

M8085-91050

## Manual Edition

Edition 3.1, July 2019

Keysight Technologies Deutschland GmbH  
Herrenberger Strasse 130,  
71034 Böblingen, Germany

## Technology Licenses

The hard ware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

## U.S. Government Rights

The Software is “commercial computer software,” as defined by Federal Acquisition Regulation (“FAR”) 2.101. Pursuant to FAR 12.212 and 27.405-3 and Department of Defense FAR Supplement

(“DFARS”) 227.7202, the U.S. government acquires commercial computer software under the same terms by which the software is customarily provided to the public. Accordingly, Keysight provides the Software to U.S. government customers under its standard commercial license, which is

embodied in its End User License Agreement (EULA), a copy of which can be found at <http://www.keysight.com/find/sweula>. The license set forth in the EULA represents the exclusive authority by which the U.S. government may use, modify, distribute, or disclose the Software. The EULA and the license set forth therein, does not require or permit, among other things, that Keysight: (1) Furnish technical information related to commercial computer software or commercial computer software documentation that is not customarily provided to the public; or (2) Relinquish to, or otherwise provide, the government rights in excess of these rights customarily provided to the public to use, modify, reproduce, release, perform, display, or disclose commercial computer software or commercial computer software documentation. No additional government requirements beyond those set forth in the EULA shall apply, except to the extent that those terms, rights, or licenses are explicitly required from all providers of commercial computer software pursuant to the FAR and the DFARS and are set forth specifically in writing elsewhere in the EULA. Keysight shall be under no obligation to update, revise or otherwise modify the Software. With respect to any technical data as defined by FAR 2.101, pursuant to FAR 12.211 and 27.404.2 and DFARS 227.7102, the U.S. government acquires no greater than Limited Rights as defined in FAR 27.401 or DFAR 227.7103-5 (c), as applicable in any technical data.

## Warranty

THE MATERIAL CONTAINED IN THIS DOCUMENT IS PROVIDED “AS IS,” AND IS SUBJECT TO BEING CHANGED, WITHOUT NOTICE, IN FUTURE EDITIONS. FURTHER, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, KEYSIGHT DISCLAIMS ALL WARRANTIES, EITHER EXPRESS OR IMPLIED WITH REGARD TO THIS MANUAL

AND ANY INFORMATION CONTAINED HEREIN, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. KEYSIGHT SHALL NOT BE LIABLE FOR ERRORS OR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, USE, OR PERFORMANCE OF THIS DOCUMENT OR ANY INFORMATION CONTAINED HEREIN. SHOULD KEYSIGHT AND THE USER HAVE A SEPARATE WRITTEN AGREEMENT WITH WARRANTY TERMS COVERING THE MATERIAL IN THIS DOCUMENT THAT CONFLICT WITH THESE TERMS, THE WARRANTY TERMS IN THE SEPARATE AGREEMENT WILL CONTROL.

## Safety Notices

### CAUTION

A CAUTION notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a CAUTION notice until the indicated conditions are fully understood and met.

### WARNING

A WARNING notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a WARNING notice until the indicated conditions are fully understood and met.

# Contents

## 1 Installation Requirements

**Prerequisites** 6

**License Requirements** 7

## 2 Installation Steps

## 3 Accessing the Plugins for MIPI Receiver Test Solutions

## 4 Contact Information



# 1 Installation Requirements

This document describes the installation procedure for Keysight M8085A Plugins for MIPI Receiver Test Solutions. After successful installation, you will be able to access the following plugins:

- MIPI C-PHY and D-PHY Editor—Enables the user to set the DUT and test configuration.
- MIPI C-PHY and D-PHY CTS—Supports the MIPI C-PHY and MIPI D-PHY signal generator configurations for single and multi-lane testing with the Test Automation Software.

## Prerequisites

The following are the prerequisites for installing Keysight M8085A Plugins for MIPI Receiver Test Solutions:

- The M8085A Plugins for MIPI Receiver Test Solutions must be installed separately. You must ensure that the system must have the Keysight M8070B software (version 6.0.100.2 or later) installed on it.
- Installer for M8085A Plugins, which is either available on CD or can be downloaded from Keysight web page: [www.keysight.com](http://www.keysight.com).
- Licenses for M8085A Plugins for MIPI Receiver Test Solutions. See “License Requirements”.

## License Requirements

- Keysight M8070B System Software Version: 6.0.100.2 or later with options M8070B-OTP or M8070B-ONP.
- [Table 1](#) lists the licenses required for the respective plugins:

**Table 1 Licenses required for D-PHY and C-PHY Plugins**

Plugins	Licenses
D-PHY Editor	M8085A-DT1, M8085A-DN1, or M8085A-DD1, in combination with M8085DUEA-1TP, M8085DUEA-1NP, M8085DUCA-1TP, or M8085DUCA-1NP as an upgrade option OR M8085DE1A-TP, M8085DE1A-1NP, or M8085DE1A-TRL
D-PHY Editor	M8085A-CT1, M8085A-CN1, or M8085A-CDF1, in combination with M8085CUCEA-1TP, M8085CUEA-1NP, M8085CUCA-1TP, or M8085CUCA-1NP as upgrade option OR M8085CE1A-1TP, M8085CE1A-1TP, or M8085CE1A-TRL
D-PHY CTS	M8085A-DTA, -DNA, or -DDA in combination with M8085DUCA-1TP or 1NP as upgrade option M8085DC1A-1TP, -1NP or -TRL
C-PHY CTS	M8085A-CTA, -CNA, or -CDA in combination with M8085CUCA-1TP or 1NP as upgrade option M8085CC1A-1TP, -1NP or -TRL





## 2 Installation Steps

Follow the given steps to install Keysight M8085A Plugins for MIPI Receiver Test Solutions on your system.

- 1 Double-click the installer file. This installer file will be available either on CD or Web.



The following window is displayed as shown in [Figure 1](#).




Figure 1 MIPI Plugin Setup Wizard

- 2 Click **Next**. The License Agreement of the MIPI plugin setup is displayed as shown in [Figure 2](#).




Figure 2 MIPI Plugin Setup License Agreement window

- 3 Read all the terms and conditions of the **License Agreement** carefully.
- 4 Select **I accept the terms of the License Agreement**.
- 5 Click **Next**. The following window is displayed as shown in [Figure 3](#).




Figure 3 MIPI Plugin Setup select components window

- 6 Select the type of installation (**Full** or **Custom**).
- 7 Click **Next**. The following window is displayed as shown in [Figure 4](#).




Figure 4 MIPI Plugin Setup select install location window

- 8 Click **Browse** to select the destination folder where the software must be installed.
- 9 Click **Install**. The following window is displayed as shown in [Figure 5](#).




Figure 5 MIPI Plugin Setup installation status window

- 10 Once the installation is complete, the following window is displayed as shown in [Figure 6](#).




Figure 6 M8085A Plugins installation completion window

- 11 Click **Finish** to complete the installation of Keysight M8085A Plugins for MIPI Receiver Test Solutions.

# 3 Accessing the Plugins for MIPI Receiver Test Solutions

Follow the steps to access an installed Plugin through Keysight M8070B system software:

- 1 Launch M8070B system software user interface.
- 2 From the **Application** menu, select one of the following plugins:




Figure 7 Selecting M8085A Plugin from the Application menu

### 3 Accessing the MIPI Receiver Test Solutions Plugins

- MIPI D-PHY Editor Plugin: The default user interface is displayed as shown in [Figure 8](#).




Figure 8 MIPI D-PHY Editor Plugin User Interface

- MIPI D-PHY CTS Plugin: The default user interface is displayed as shown in [Figure 9](#).




Figure 9 MIPI D-PHY CTS Plugin User Interface

- MIPI C-PHY Editor Plugin: The default user interface is displayed as shown in Figure 10.




Figure 10 MIPI C-PHY Editor User Interface



- MIPI C-PHY CTS Plugin: The default user interface is displayed as shown in Figure 11.




Figure 11 MIPI C-PHY CTS User Interface

For complete details on how to operate the MIPI D-PHY Editor Plugin user interface, refer to the *MIPI D-PHY Editor User Guide*.

For complete details on how to operate the MIPI D-PHY CTS Plugin user interface, refer to the *MIPI D-PHY Receiver Test Configuration User Guide*.

For complete details on how to operate the MIPI C-PHY Editor Plugin user interface, refer to the *MIPI C-PHY Editor User Guide*.

For complete details on how to operate the MIPI C-PHY CTS Plugin user interface, refer to the *MIPI C-PHY Receiver Test Configuration User Guide*.

# 4 Contact Information

For more information on Keysight Technologies' products, applications or services, please contact your local Keysight office. The complete list is available at: [www.keysight.com/find/contactus](http://www.keysight.com/find/contactus).





