



Mi 23.8" Desktop Monitor 1C

User Manual



Product Overview

Read this manual carefully before use,
and retain it for future reference.



Accessories



AC Adapter×1



User Manual×1



Warranty Notice×1



HDMI Cable×1



Stand×1



L-shaped Screwdriver×1



Stand Screw×2




Base×1




Base Screw×1

Installation

1. Install the stand onto the back of the monitor, then fix firmly with the stand screws.



2. Connect the stand to the base, then tighten the base screw securely.




3. Adjust the angles forward or backward based on your needs.

Forward 5°




Backward 15°



Note: When adjusting the angles, it is recommended to use one hand to hold down the base and use the other hand to adjust the monitor. Otherwise, the monitor may fall down.

How to Use

Port Description



1. Power Port:

Input

2. HDMI Port:

Version: 1.4

Output Device: Computer, DVD player, camera, etc.

Signal Formats: 480i, 480p, 720p, 1080i, 1080p

Maximum Refresh Rate: 1080p/60 Hz

3. VGA Port:

Output Device: Computer, DVD player, etc.

Maximum Refresh Rate: 1080p/60 Hz

4. Security Slot:


Suitable for 3 × 7 mm cable lock (not included and sold separately).

Note: When the AC adapter or HDMI cable is damaged, it must be replaced with a genuine AC adapter or HDMI cable purchased from the manufacturer or after-sales service department.

How to Use

Button Description

5-way Navigation Button



Turning On/Off

Press the middle of the 5-way navigation button



Turn the monitor on

Press and hold the middle of the 5-way navigation button for 2 seconds



Turn the monitor off

Indicator Status



Dimmed Off






Lit On












Blinking In sleep mode

5-way Navigation Button Instructions

Operation	Result	
	When menu is not displayed on the monitor	When menu is displayed on the monitor
Press right 	Open menu	Switch between menu options/Select
Press up/down 		Switch between menu or submenu options/Adjust values
Press left 		Return

How to Use

Menu Description

MI Monitor		Standard Mode
 Brightness	80 <div><div></div></div>	
 Contrast		
 Color Temp		
 Smart Modes		
 Input		
 Settings		
<div><div> Back</div><div> Enter/Select</div><div> Move/Adjust</div></div>		

Main Menu	Submenu	Description	Adjustable Range	Default
Brightness	0-100	Adjust the monitor's brightness	0-100	80
Contrast	Adjust	Adjust the monitor's contrast	0-100	75
	DCR	Dynamic contrast function	On/Off	Off
Color Temp	Standard	Set to the standard color temperature	Only one color temperature can be selected at a time	Standard
	Cool	Set to the cool color temperature		
	Warm	Set to the warm color temperature		
	Custom	Manually adjust RGB color temperature		
Smart Modes	Standard Mode	Set to standard mode	Only one display mode can be selected at a time	Standard Mode
	ECO Mode	Set to eco mode		
	Game Mode	Set to game mode		
	Movie Mode	Set to movie mode		
	Low Blue Light Mode	Set to low blue light mode		
Input	VGA	Set to VGA signal source	Only one signal source can be selected at a time	/
	HDMI	Set to HDMI signal source		
Settings	Language	Select the menu language	English/Español/Русский/ Français/Italiano/ Deutsch/Polksi/한국어	English
	Overdrive	Decrease the monitor's response time	Off/Level 1/Level 2/ Level 3	Off
	Image Auto-adjust	Adjust the image automatically when using the VGA signal source	/	/
	Color Auto-adjust	Adjust the color automatically when using the VGA signal source	/	/
	Information	Display monitor related information	/	/
	Reset	Restore the monitor to the factory settings	OK/Cancel	Cancel

Precautions

- Do not use this monitor in damp or humid environments such as bathrooms, kitchens, basements, or near swimming pools.
- Make sure the monitor is placed on a stable surface. When the monitor falls down or is knocked over, it may cause personal injuries or damage.
- Store and use the monitor in a cool, dry, ventilated place. Keep the monitor away from radiation and heat sources. Do not cover or block the heat dissipation vents on the back of the monitor.
- Do not place the monitor on a bed, sofa, or blanket, etc.
- The monitor's operating voltage range is indicated on a label on the back of the monitor. If you are unsure what voltage your power supply is, please contact the monitor's distributor or local power company.
- When you do not plan to use the monitor for a long period of time, unplug it from the electrical outlet so as to prevent possible damage from power surges or lightning strikes.
- Do not overload electrical outlets, as this may cause a fire or an electric shock.
- Do not insert any foreign objects into the monitor, as this may cause a short circuit which can lead to a fire or an electric shock.
- Do not attempt to disassemble or repair the monitor yourself. If the monitor is not functioning properly, please contact our after-sales service department for assistance.
- Do not excessively pull, twist, or bend the AC adapter's cord.
- There is polarizer attached to the screen (not the protective film), please do not tear it off. Any damage caused by the user will void the warranty.

Troubleshooting

Issue	Possible Cause	Solutions
Unable to turn on	No power	<ul style="list-style-type: none">· Make sure the AC adapter is plugged in properly.· Press the middle of the 5-way navigation button.
Image is dark	Brightness/ Contrast not adjusted properly	<ul style="list-style-type: none">· Adjust the brightness and contrast.
Image is jittery or rippled	Interference	<ul style="list-style-type: none">· Keep the monitor away from electronic devices that may cause electrical interference.
Indicator is lit, but no image	No signal	<ul style="list-style-type: none">· Turn on the computer.· Make sure the computer's graphics card is working properly.· Make sure the HDMI or VGA cable is properly plugged in.
Monitor displays: Out of range	Resolution is incorrect	<ul style="list-style-type: none">· Use the specified recommended resolution settings.
The image is not in the middle or out of range when using the VGA signal source	Image is not adjusted	<ul style="list-style-type: none">· Select the Image Auto-adjust from the menu to adjust the image.

Specifications

Model	RMMNT238NF
Input	12 V \equiv 2 A
Rated Power	24 W Max.
Screen Size	23.8"
Viewable Image Size (Diagonal)	60.5 cm
Dot Pitch	0.275 × 0.275 mm
Brightness	250 cd/m ² (TYP)
Contrast	1000:1 (TYP)
Color Gamut	16.7 M
Aspect Ratio	16:9
Response Time	6 ms (GTG)
Maximum Resolution	1920 × 1080
Recommended Resolution	1920 × 1080
Item Dimensions	539.2(L)×181.2(W)×419.5(H) mm
Net Weight	2.7 kg
Operating Temperature	0°C to 40°C
Operating Humidity	20–90% RH
Atmospheric Pressure	86–106 kPa

External AC Adapter Specifications

Model identifier	BLJ24W120200P-V
Input voltage	100-240 V AC
Input AC frequency	50/60 Hz, 0.6 A
Output voltage	12.0 V DC
Output current	2.0 A
Output power	24.0 W
Average active efficiency	86.20%
Efficiency at low load (10 %)	76.80%
No-load power consumption	0.1 W
Manufacturer	Zhongshan Baolijin Electronic Co.,Ltd.

Regulatory Compliance Information

WEEE Disposal and Recycling Information



All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.

EU Declaration of Conformity



The manufacturer hereby, declares that this equipment is in compliance with the applicable Directives and European Norms, and amendments. The full text of the EU declaration of conformity is available at the following internet address:
<http://www.mi.com/global/service/support/declaration.html>

Eye Health

To avoid eyestrain, or neck, arm, elbow, and shoulder pain caused by using the computer for a long time, please follow the suggestions listed below:

- Keep the monitor at a distance of 20–28 inches (approx. 50–70 cm) from your eyes.
- Blink more often to relieve eye fatigue when staring at the monitor.
- Give your eyes a 20-minute break after using the monitor for two hours.
- Take your eyes off the monitor and look at something a certain distance away for at least 20 seconds.
- Stretch your body to help relieve tension on the neck, arms, back, and shoulders.

Low Blue Light Description

In recent years, eye damage caused by blue light has attracted more and more attention. In general, the wavelength of blue light is 400–480 nm, and the wavelength of harmful blue light is 415–455 nm. This monitor has a function to help reduce your exposure to the blue light emission. You can enable the low blue light mode via the settings menu.

Xiaomi Communications Co., Ltd.

Address: #019, 9th Floor, Building 6, 33 Xi'erqi Middle Road, Haidian District,
Beijing, China, 100085

For further information, please go to www.mi.com

Importer:

Beryko s.r.o.

Na Roudné 1162/76, 301 00 Plzeň

www.beryko.cz