


DF57 Series Mating / Unmating Operation Instruction (For DF57 series)


Mating


①By positioning the convexity of the socket sides to the header concavity, align the centers of the socket and the header in pitch direction.

②Slightly press the socket down at cable side to tilted angle.

○Press down at the lever side with stabilizing the cable side to insert. Mating completes.










Unmating

Thook the lever with finger nail.





③Lift up to the upper direction and positive lock is released. Removal completes.



жs	DRAWING NO.	EDC-344747-10-00	
	PART NO.	DF57AH-6S-1.2C(10	3)
	CODE NO.	CL666-0111-2-10	<u>2</u> /2