




# VEATOOL

## Wireless Earbuds

### User Manual

#### Product Display



#### Earphones Specification

Bluetooth Version: V5.0	Working Frequency: 2.402GHz-2.480GHz
Bluetooth Distance: > =10M	Waterproof Rating: IPX5
Battery: Polymer Battery 3.7V, 50mAh	Charging Box: 3.7V,500mAh
Charging Time: 1H for Earphones, 1H for Charging Case	
Playing Music/Call Time: 5 Hours (depends on music style and volume)	
Supporting Protocol: A2DP 1.3/AVRCP 1.6/AVDTP 1.3/AVCTP 1.4/GAVDP 1.3/HFP 1.7 HSP 1.2/SPP 1.2/GATT 1.0	

#### Product Display

1.Power on: Open Lid and earbuds boost up automatically, or long press MFB for 3s, there is a “power on”prompt tone.

2.Power off: Put back to case and close lid, earbuds are automatically off, or long press MFB for 5s, there is a “power off”prompt tone.

3.Single Click: Left earbuds (L) Volume Down, Right earbuds (R) Volume Up. There is a beep at maximum or minimum volume.

4.Double Click: Play/Pause; Answer Call/Hang up Call; Reject call when on calling mode.

5.Triple Click: Left earbuds (L) Skip Back, Right earbuds(R) Skip forward.

6.Voice Assitance: Long press Left(L) for 2s to wake up Siri with a beep, Long press for 2s to exit Siri with

a beep.

7.Game Mode: Long press Right (R) for 2s, prompt “Beep Game mode”to enter game mode; Long press for 2s, prompt “Music mode”to enter music mode.

8.Factory Reset: Earbuds on and unconnected, quickly click MFB for 5 times to clear pairing data, both earbuds LED lights are on, automatically off after 3s. Put earbuds back to charging case, close lid, open lid and connect again.

#### Bluetooth Pairing Instructions

1.L&R earbuds Pairing: Left and Right earbuds auto pair, Masterearbud quickly flash when pairing succeeded, slave earbud light goes off.

2.Connect to device: both earbuds light go off when connected to device. Search for bluetooth name “VEATOOL MD012”,click and connected.

3.Automatically connect back: After the first connection is successful, earbuds will connect to the last paired phone by default.

#### Indicator Light Display

1.Power on: Indicator lights flash 3 times.

2.Power off: Indicator lights flash 1 time.

3.Un-connected: master earbuds light flash 1 time per seconds.

4.Game mode: both earbuds lights are on and do breathing effect.

5.Low Battery Warning: indicator light flash 1 time per 3 seconds.

6.Charge the Case: <25% battery, first segment indicator flashes; 25%-50% battery,second segment indicator flashes; 50%-75% battery, third segment

indicator flashes; 75%-100% battery, forth segment indicator flashes; Full battery, all lights always on.

7.Case charge the earbuds: open lid and case light indicator is on for 60s; close lid(with earbuds inside), earbud’s led light is on when charging, goes off when full battery, light is off when earbud is not inside.

#### Notes on Charging

1.After using for a period of time, the contacts are oxidized, earbuds cannot be charged or turned on. First, use alcohol and cloth to clean the contacts and the two thimbles in the charging compartment to solve the problem.

2.When you put the earbuds back into the charging case, they will turn off and start charging; if you take it out again, they will automatically turn on and pair with each other automatically.

## Maintenance:

a.The recommended operating temperature range is: 0-35 degrees; excessive cold, overheating, or high temperature environments will reduce battery life and affect product performance.

b.Do not use under thunderstorms.

c.After a long period of non-use, please charge it before use.

d.Please use a dry soft cloth to clean the earbuds.

e.If there is water or sweat at the notch, wipe it with a dry cloth, it will not affect normal use.

## Notes on Charging

Bluetooth earphones	X2
Charging case	X1
Charging Cable	X1
Spare ear caps	X2
User Manual	X1

## Common Problem

1.The earbuds cannot be paired with the mobile phone.Please check whether the earbuds are in pairing or back-to-back mode, and check the mobile phone Bluetooth search function.

2.The earbuds cannot be turned on.Please check if the earbuds are fully charged and charge them.

3.Can I replace the battery of earphone?  
No, these earbuds use the non-removable battery.

4.Can I use the earbuds while driving?  
You can use earbuds while driving, while driving and minimize the volume.

5.The earbuds are disconnected from the phone.The efective distance of these earbuds are 10 meters indoors. If the distance between the mobile phone and the earbud exceeds 10 meters or there are multiple obstacles, the earbud and the mobile phone will be disconnected. Please keep the earbud within the efective distance.

6.After the earbuds are connected to a computer or mobile phone, hear different sounds?Because Bluetooth is a wireless technology, it is very sensitive to objects between the earbuds and the connected device.Please check whether there is metal or other objects in the connection range that affect the connection.

7.After the Bluetooth earbuds are connected to the

mobile phone, can the earphone be used to control the applications on the mobile phone?The software settings of device applications may be different, so that the functions of individual applications do not support the earphone controlling.

## Safety Problem:

1.keep this product away from high temperature areas.

2.Please try to use qualified chargers and charging cables, and try to avoid using high current and voltage fast charging devices to charge this product.

3.The waterproof grade of this product is IPX5, please choose the appropriate scene to use this product.

4.Do not disassemble or refit the earbuds for any reason, it make broken or born the earbuds, Please send it to sales agency to repair.

5.Pls put the items and accessories to the places which can not be touched by kids or pets to avoid any unexpected accidents.

6.Earbuds and charging case are with built in rechargeable battary,can not be dis-assembled ,Pls make sure the earbuds and case are fully charged before using it for first time.

## Customer Sopport

Customer Service Email : Amazon@veatool.cn  
Office Web: veatool.cn

No matter the product is lost, outdated, broken or you just don't like this product, please contact our customer service Amazon@veatool.cn , she will do her best to give you a satisfactory answer.

