

HARMONICS® LAMINATE INSTALLATION INSTRUCTIONS

General


Harmonics® floors use Uniclic® technology, a revolutionary system for installing laminate floors without using glue. The planks can be clicked together simply, thanks to the ingenious shape of the tongue and groove.

Large, easy-to-read instructions are available at www.Harmonics-Flooring.com and 1-888-459-9220.

Uniclic® is unique because you can install the planks in two different ways:

Method A (Angle-In installation method):

Position the plank to be installed at an angle of 20 to 30° to the plank already installed. Move the plank gently up and down while exerting forward pressure. The planks will automatically click into place. You can either insert the tongue into the groove, or the groove on to the tongue. The tongue into the groove is the easiest method. (See diagrams 1A – 1B – 1C.)



Method B (Flat installation method):

With Uniclic® you can also tap the planks into each other without lifting. For this method you must use the special Uniclic® tapping block. The planks should not be joined with a single tap and the tapping block should be sitting flat on the floor. To avoid damaging the planks you must tap them together gradually. (See diagrams 2A – 2B.) Use this method only in cases where you are unable to use the Angle-In method (see below). The rest of your floor should be installed using the Angle-In method.



Tools for installing the floor

For best results, it is essential that you follow the installation instructions exactly. Besides the regular tools for installing laminate floors (i.e. hammer, saw, pencil, measure) you will also need the following accessories;

- Installation kit (pull bar, tapered spacers (1-8 mm / 0.039" - 0.315") and Uniclic®-adapted tapping block)
- Moisture barrier
- Maintenance products

The use of accessories other than Harmonics® accessories might cause damage to the Harmonics® floor. In such a case, the guarantee provided by Harmonics® Flooring will be void. We recommend using only Harmonics® accessories as these have been specially designed and tested for use with Harmonics® flooring planks. It will generally be necessary to saw some flooring planks during installation. To obtain a clean cut, the pattern side should face down when you use a jigsaw, saber saw or circular handsaw and up when you use a handsaw, table saw or a crosscut saw.

10 focus points

1. Thanks to the Uniclic® system, the floor floats and is installed without glue. You can walk on the floor during and immediately after installation.
2. Harmonics® flooring allows you to choose where you want to begin. Think about what will be the easiest way to install the floor. We will demonstrate the installation for right-handed people, from left to right. You can work in the other direction if you want.
3. Make sure the planks are mixed sufficiently when you install them so that you do not end up with too many identical, light or dark planks next to each other.
4. Inspect all planks in daylight before and during installation. Defective planks must never be used.
5. The floor should preferably be installed parallel to how the light enters the room. The ideal conditions are 15-20°C (59-68°F) at a relative humidity of 50-60%.
6. Under normal conditions, Harmonics® flooring requires no acclimation period. Normal conditions are defined as a difference of no more than 25°F and 20% relative humidity between the stocking/transportation environment of the flooring and the final installation environment of the flooring. Outside of normal conditions, let the planks acclimate for 48 hours in the unopened packaging at the normal room temperature in the middle of the room where the floor is to be installed. Allow air space between packages.
7. Room humidity and temperature can vary according to the season, so it is vital that the floor is able to expand and contract. For this reason, make sure you leave a minimum expansion joint of 8 to 10mm (5/16" to 3/8") on all sides of the floor, around pipes, thresholds, under doors and around any fixed /stationary objects (floor vents, kitchen islands, etc.).
8. Large rooms must have expansion joints every 13m (40 feet) width-wise to the planks and every 13m (40 feet) length-wise. Also provide expansion joints between different rooms and hallways (e.g. under the door). Expansion joints can be finished by means of a molding that is attached to the subfloor.
9. Ensure the end joints of the planks in two successive rows are never in line. Always ensure that the joints are staggered by at least 15cm / 6 inches.
10. We recommend you purchase a few extra cartons of flooring. This will be useful to you if you damage pieces, miscalculate the size of the room or mis cut some pieces. This also will help you if your floor needs a repair but your product is no longer manufactured.

Preparing the room

- Check that the doors can still open and close after the floor with underlayment has been installed (minimum +1cm (3/8")).
- Check whether the old molding can be removed. You can also leave the wall base and finish the floor with new molding.
- Make sure the subfloor is flat. Any unevenness greater than 2mm (1/16") over the length of 1 meter (40") must be smoothed out. It is vital that you use an underlayment or leveling compound to smooth any unevenness in the base floor.
- Harmonics® flooring with underlayment already attached to the flooring plank requires the use of a moisture barrier (included in the Harmonics Installation kit) over concrete and wooden subfloors. (This is current policy (required over both concrete & wood))
- Make sure the subfloor is clean and dry.
- Flooring may be installed over radiant heating systems following special installation instructions. For more information please call 1-888-459-9220.

CONCRETE SUBFLOOR:

New Construction:

- A new concrete floor must dry at least 1 week per 1cm (3/8") thickness up to 4cm (1-1/2"). Sub-floors thicker than 4cm (1- 1/2") require twice as much drying time. For example, a 6cm (2- 1/2") concrete sub-floor must dry for at least 8 weeks.
- The moisture content must be less than 2.5% (CM method) or less than 5 lbs/24 hours per 1000sqft (Calcium chloride method ASTM 1869).

Renovation:


- Remove any damp-porous floor covering (carpet, needle felt, etc.) first.

WOODEN SUBFLOOR


- Remove any existing damp-porous floor covering first.
- Make sure the sub-floor is stable. Nail down any loose parts and apply a leveling layer if necessary.
- Install the Harmonics® planks crosswise to the direction of the existing sub-floor.
- It is necessary that the crawl space under the plank floor be sufficiently ventilated. Remove any obstacles and provide sufficient ventilation (minimum 4cm (1-1/2") of total ventilation holes per meter (40") of floor). The moisture content of the wood may not exceed 12%.

Installing the floor


- First install the moisture barrier, per width and gradually as you progress. For concrete subfloors, let the moisture barrier run up the wall a bit before cutting to size. A molding will be attached to this later. (See diagram 3A.) For wooden subfloors, cut the moisture barrier 1 inch from the wall.



















- Begin the first row with a whole plank. First saw off the tongue on both the long and the short sides. (See diagram 3B.)




- Put the plank with the sawn off sides against the walls. Put spacers from the installation kit between the planks and the wall. This will ensure that your expansion joint is wide enough: 8 to 10mm (5/16" to 3/8"). (See diagram 3C.)



- The diagrams below indicate where the Harmonics® planks are clicked together by angling up and down or where they are tapped together flat. Follow the diagrams precisely. (See diagrams 4.1 through 4.16.)



- In places where it is too difficult to install the Harmonics® planks with the tapping block (e.g. against the wall), you can tap them together using the pull bar and a hammer. (See diagrams 5A – 5B - 5C.)



- There must be an 8 to 10mm (5/16" to 3/8") expansion joint between the last row and the wall. Keep this in mind when sawing the last row of planks.


INSTALLATION OF HARMONICS® IN WET AREAS

Since prolonged water exposure could damage your laminate flooring, the following installation recommendations should be closely followed to validate your residential water warranty. Wet areas would include, but are not limited to, bathrooms, powder rooms, kitchens, mud rooms, foyers, and laundry rooms. Harmonics® flooring is not recommended for extremely humid applications such as in saunas or swimming pool areas. The water warranty excludes all products thinner than 8mm (not including pad attached) and does not apply to beveled edge products when used in bathrooms. An expansion area of 8 to 10mm (5/16" – 3/8") must be provided around all vertical obstructions including walls, permanent cabinets, pipes etc. All perimeter expansion areas must be completely filled in with a water repellent silicone sealant (not included in the Harmonics® installation kit, but available from Harmonics Customer Service). When applying sealant, it is helpful to first apply a strip of masking tape parallel to and approximately 1mm (1/32") from the edge of the flooring. Then fill the expansion area with sealant, remove any excess with a plastic scraper or putty knife, then remove the tape. Let dry for 24 hours before exposure to water.

Pipes

In rows where there is a pipe, make sure the pipe falls exactly in line with the short side of two planks. Take a drill bit with the same diameter as the pipe plus 20mm (3/4") for the expansion.

Click the planks together on the short side and drill a hole in the center of the joint between the two planks. Now you can install the planks in the floor. (See diagrams 6A-6B-6C.)




Under Doorframes

When sawing the planks, ensure that the expansion joint under the door is at least 10mm (3/8"). If you cannot lift the plank, use an adapted tapping block or pull bar and hammer to tap the planks together with the planks flat on the floor. (See diagrams 7A-7B.)



Finishing

- Remove all spacers.
- Install the molding on the plastic membrane that runs up the wall from under the floor. Never attach the molding to the floor. This method allows the floor to expand and contract under the molding. (See diagram 8A.)



- For a perfect finish around pipes, use rosettes or flexible silicone caulking.
- In places where profiles or skirting cannot be placed, fill expansion gaps with flexible silicone caulking.
- Color-matched caulking is available through 1-888-459-9220.

Precautions

- Protect furniture and chair legs with proper felt or rubber caps.
- Avoid bringing dirt, water and sand indoors by providing a suitable floor mat at all outside doors.
- Furniture on casters/wheels must use soft rubber wheels that are suitable for laminate floor and/or use a suitable protective mat.
- Ensure that humidity in the room is always at least 50%. Use a humidifier if you need to.
- Wipe up spills immediately. Do not allow liquids to stand on the floor.

Maintenance

- Never use wax polish, oils, soap, detergents, shine enhancers or varnish on the floor.
- Sweep floor regularly to remove dust or debris that can harm wood and laminate flooring.
- For dry maintenance, we recommend using a micro-fiber duster or vacuum cleaner with a soft bristle brush.
- For slightly damp maintenance, we recommend using an appropriate laminate flooring cleaning product, which you spray directly and lightly on the micro-fiber duster (see instructions). Always wipe dry immediately until no more moisture is visible on the floor. The use of other cleaning products might damage your floor. For beveled edge products, we strongly recommend dry cleaning only.
- A warranty approved maintenance kit is available through the Harmonics toll-free customer service line: 1-888-459-9220
- Do not use any type of cleaning machine such as spray mops, steam mops or power cleaners.
- Wet maintenance is absolutely forbidden. Remove any standing water immediately.
- To remove stubborn stains carefully, we recommend using an acetone based fingernail polish remover.
- Never use scouring products! Spot and stain remover is available through 1-888-459-9220.
- In case your floor needs repair, a tool is available called Unifix which allows the damaged floor plank to be easily removed in minutes without replacing the entire floor. For Unifix to work properly the required expansion gap must be in place around the room's perimeter and extra flooring should be available for use in the repair. Contact Harmonics Customer Service 1-888-459-9220. Enjoy your floor.

ATTN: INSTALLERS Caution: Wood Dust

Sawing, sanding and machining wood products can produce wood dust. Airborne wood dust can cause respiratory, skin and eye irritation. The International Agency for Research on Cancer (IARC) has classified wood dust as a nasal carcinogen in humans.

Proposition 65 Warning

Produces wood dust when cut. Wood dust is known to California to cause cancer.

Precautionary Measures: Power tools should be equipped with a dust collector. If high dust levels are encountered use an appropriate NIOSH designated dust mask. Avoid dust contact with skin and eyes. First Aid Measures in case of irritations: In case of irritation flush eyes and skin with water for at least 15 minutes. For questions please contact Technical Services at: 1-888-387-9882, option 1.

IMPORTANT HEALTH NOTICE FOR MINNESOTA RESIDENTS ONLY:

THESE BUILDING MATERIALS EMIT FORMALDEHYDE. EYE, NOSE, AND THROAT IRRITATION, HEADACHE, NAUSEA AND A VARIETY OF ASTHMALIKE SYMPTOMS, INCLUDING SHORTNESS OF BREATH, HAVE BEEN REPORTED AS A RESULT OF FORMALDEHYDE EXPOSURE. ELDERLY PERSONS AND YOUNG CHILDREN, AS WELL AS ANYONE WITH A HISTORY OF ASTHMA, ALLERGIES, OR LUNG PROBLEMS, MAY BE AT GREATER RISK. RESEARCH IS CONTINUING ON THE POSSIBLE LONG-TERM EFFECTS OF EXPOSURE TO FORMALDEHYDE. REDUCED VENTILATION MAY ALLOW FORMALDEHYDE AND OTHER CONTAMINANTS TO ACCUMULATE IN THE INDOOR AIR. HIGH INDOOR TEMPERATURES AND HUMIDITY RAISE FORMALDEHYDE LEVELS. WHEN A HOME IS TO BE LOCATED IN AREAS SUBJECT TO EXTREME SUMMER TEMPERATURES, AN AIR-CONDITIONING SYSTEM CAN BE USED TO CONTROL INDOOR TEMPERATURE LEVELS. OTHER MEANS OF CONTROLLED MECHANICAL VENTILATION CAN BE USED TO REDUCE LEVELS OF FORMALDEHYDE AND OTHER INDOOR AIR CONTAMINANTS. IF YOU HAVE ANY QUESTIONS REGARDING THE HEALTH EFFECTS OF FORMALDEHYDE, CONSULT YOUR DOCTOR OR CALL LOCAL HEALTH DEPARTMENT. WARNING! DO NOT MECHANICALLY CHIP OR PULVERIZE EXISTING RESILIENT FLOORING, BACKING, LINING FELT, ASPHALTIC "CUTBACK" ADHESIVES OR OTHER ADHESIVES. PREVIOUSLY INSTALLED RESILIENT FLOORING MAY CONTAIN EITHER ASBESTOS FIBERS OR CRYSTALLINE SILICA. THE PRODUCTS IN THIS BOX DO NOT CONTAIN ASBESTOS.

Avoid creating dust. Inhalation of such dust is a cancer and respiratory tract hazard. Smoking by individuals exposed to asbestos fibers greatly increases the risk of serious bodily harm. Unless positively certain that the product is a non-asbestos containing material, you must presume it contains asbestos. Regulations may require that the material be tested to determine asbestos content and may govern the removal and disposal of material. See current edition of the Resilient Floor Covering Institute (RFCI) publication "Recommended Work Practices for Removal of Resilient Floor Coverings" for detailed information and instructions on removing all resilient covering structures.

Full warranty text is available at www.Harmonics-Flooring.com and through 1-888-459-9220.

For service under this warranty please contact HARMONICS® at (1-888-459-9220) or at www.Harmonics-Flooring.com or mail in proof of purchase and description of claim to:

HARMONICS®,

1000 Cal Oak Road,

Oroville, CA 95965.

www.harmonics-flooring.com